

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Lasko](#) /

› [Lasko Portable Electric 1500 Watt Ceramic Tower Space Heater with Remote \(Model 5160\) - User Manual](#)

Lasko 5160

Lasko Portable Electric 1500 Watt Ceramic Tower Space Heater with Remote

Model: 5160

INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your Lasko Portable Electric 1500 Watt Ceramic Tower Space Heater, Model 5160. Please read all instructions carefully before use and retain this manual for future reference.





Image: The Lasko 5160 Ceramic Tower Heater, black in color, shown with its accompanying remote control. The heater features a tall, slender design with a digital display at the top and a wide heat output grille.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These include:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner.
- Do not use outdoors.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has an automatic overheat protection feature. If the heater overheats, it will automatically shut off.
- The exterior of the heater remains cool to the touch during operation, enhancing safety.

Safety Comes Standard



Image: The Lasko 5160 heater positioned in a living room setting with a child and adult. Overlays highlight "Overheat Protection", "Child/Pet-Safe Exterior", and "Non-Combustible Heating Unit" to emphasize safety features.

PACKAGE CONTENTS

Verify that all components are present:

- Lasko Ceramic Tower Heater (Model 5160)
- Remote Control
- User Manual (this document)

SETUP

1. **Placement:** Place the heater on a firm, level surface. Ensure there are no obstructions to the air intake or exhaust. Maintain a minimum distance of 3 feet (0.9 meters) from walls, furniture, and curtains.
2. **Power Connection:** Plug the power cord directly into a 120V AC wall outlet. Do not use extension cords or power strips.
3. **Remote Control Batteries:** Install 2 AAA batteries (not included) into the remote control, observing polarity.

Designed For Convenience



REMOTE WITH
DIGITAL CONTROLS



BUILT-IN CARRY
HANDLE



LIGHTWEIGHT
6 LB DESIGN



Image: A hand demonstrating the use of the built-in carry handle on the Lasko 5160 heater, highlighting its portability. The remote control is also visible.

OPERATING INSTRUCTIONS

Control Panel and Remote Control

The heater can be operated using the digital controls on the unit's top panel or with the included remote control. The functions are identical.



Image: A close-up view of the Lasko 5160 heater's digital control panel, showing buttons for power, oscillation, timer, and temperature adjustment, along with the digital temperature display.





Image: A detailed view of the Lasko 5160 remote control, featuring buttons for power, oscillation, timer, and temperature adjustment.

Functions:

- **Power ():** Press to turn the heater ON or OFF.
- **Heat Settings ():** Cycle through High (1500W), Low (900W), and Auto modes.
- **Adjustable Thermostat (+/-):** Set your desired temperature. The heater will cycle ON/OFF to maintain the set temperature.
- **Oscillation ():** Activates or deactivates the widespread oscillation feature, distributing heat across a wider area.
- **Timer ():** Program the heater to run for a set duration (up to 8 hours) before automatically shutting off.

Instant, Customizable Comfort



PROGRAMMABLE
8 HOUR TIMER



ONE TOUCH
OSCILLATION CONTROL



PROGRAMMABLE
THERMOSTAT



2 QUIET HEAT
SETTINGS



Image: The Lasko 5160 heater's digital display showing "72" degrees, with icons indicating timer and oscillation functions. Text highlights "Programmable 8 Hour Timer", "One Touch Oscillation Control", "Programmable Thermostat", and "2 Quiet Heat Settings".

Heat Every Corner

Evenly warms large rooms with widespread oscillation and ceramic heating technology



Image: The Lasko 5160 heater operating in a living room, illustrating its widespread oscillation feature by showing heat radiating across the room. Text states "Heat Every Corner" and "Widespread Oscillation".

MAINTENANCE

Regular cleaning is recommended to maintain optimal performance.

- **Cleaning:** Always unplug the heater before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Air Intake/Exhaust:** Use a vacuum cleaner with a brush attachment to remove dust and lint from the air intake and exhaust grilles.
- **Storage:** When not in use, store the heater in a cool, dry place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit; Overheat protection activated; Tip-over switch activated.	Ensure the heater is plugged into a working 120V outlet. Check circuit breaker. Allow heater to cool down for 10 minutes. Place heater on a firm, level surface.

Problem	Possible Cause	Solution
Heater blows cold air.	Thermostat set too low; Heater in Fan Only mode (if applicable).	Increase the set temperature. Ensure the heater is in a heat mode (High, Low, or Auto).
Oscillation not working.	Oscillation feature is turned off.	Press the oscillation button on the control panel or remote to activate.

SPECIFICATIONS

Brand: Lasko

Model: 5160

Power Output: 1500 Watts (High), 900 Watts (Low)

Voltage: 120 Volts

Amperage: 12.5 Amps

Heating Element: Ceramic

Special Features: 2 Heat Settings, Adjustable Thermostat, Auto-Off Timer (8-hour), Widespread Oscillation, Multi-Function Remote Control

Product Dimensions: 8.5"D x 7.25"W x 23"H

Item Weight: 6.16 pounds

Indoor/Outdoor Usage: Indoor only

Recommended Uses: Home, Office, Bedroom, Living Room

Heating Coverage: Up to 300 square feet

WARRANTY

This Lasko heater is covered by a **3-year limited warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship. For full warranty details and terms, please refer to the official Lasko website or contact customer support.

CUSTOMER SUPPORT

For technical assistance, warranty claims, or general inquiries regarding your Lasko product, please contact Lasko Customer Service:

Website: www.lasko.com

Phone: Refer to the Lasko website for current contact numbers.

Email: Refer to the Lasko website for current contact email.

Please have your model number (5160) and purchase date available when contacting support.

	Lasko CT16670 Electronic Ceramic Tower Heater with Remote Control: User Manual & Safety Guide Comprehensive instruction manual for the Lasko CT16670 Electronic Ceramic Tower Heater. Includes safety guidelines, operating instructions, troubleshooting, maintenance, and warranty information.
	Lasko CT32791 Ceramic Tower Heater with Remote Control: Instruction Manual This instruction manual provides detailed information on the Lasko CT32791 Ceramic Tower Heater with Remote Control, covering safety precautions, assembly, operation, maintenance, troubleshooting, and warranty information.
	Lasko Whole Room Ceramic Heater with Remote Control Instruction Manual This instruction manual for the Lasko Whole Room Ceramic Heater (Model CC20150) provides comprehensive guidance on operation, safety, maintenance, and troubleshooting. Learn about Auto Eco™ technology, manual and remote controls, and warranty information.
	Lasko CT14101 Electronic Ceramic Tower Heater - User Manual and Safety Instructions Comprehensive user manual and safety instructions for the Lasko CT14101 Electronic Ceramic Tower Heater, covering operation, maintenance, troubleshooting, and warranty information.
	Lasko Digital Ceramic Tower Heater with Remote Control Instruction Manual Instruction manual for the Lasko Digital Ceramic Tower Heater with Remote Control (Model CT30754C/CT30754CEF). Covers safety, operation, assembly, maintenance, troubleshooting, and warranty.
	Lasko Ceramic Tower Heater CT24950 Instruction Manual Comprehensive instruction manual for the Lasko CT24950 Ceramic Tower Heater with Remote Control. Includes safety guidelines, assembly, operation, maintenance, troubleshooting, and warranty details for residential use.


Documents - Lasko – 5160

[\[pdf\]](#) User Manual Instructions

operating manual OPERATING MANUAL This Heater is intended for use as supplemental MODELO 5160 SAVE THESE INSTRUCTIONS ALWAYS PLUG HEATERS DIRECTLY INTO A WALL IMPORTANT heat residential only 046013407801 oper prod 2242981612 lowes operatingguides assetserver net Assets Lasko i sears s d mp tc 10071501

MODELO **5160** IMPORTANT INSTRUCTIONS OPERATING MANUAL DIGITAL CERAMIC TOWER HEATER with REMOTE CONTROL MODEL **5160** This Heater is intended for use as supplemental heat. This Heater is for residential use only. It is not intended to be used in commercial, industrial or agricultural settings. GARANTA ...

lang:es score:42 filesize: 1.43 M page_count: 6 document date: 2013-02-26





[\[pdf\]](#) User Manual Warranty

5160 SS PKG 14 ai Carla Capone assetserver net assets lasko spec Lasko User Manual ||| Ceramic Tower HEATER with Remote Control YEARS QUALITY-COMFORT DURABILITY Ceramic Tower HEATER wi ... e Fully Assembled 3-Year Limited Warranty Remote Control: Requires 2 AAA Batteries not included **5160** Digital Ceramic Tower Heater with Remote Control SAFETY Safe Ceramic Comfort for Your Home C...


lang:en score:38 filesize: 4.2 M page_count: 2 document date: 2014-03-26



[\[pdf\]](#) User Manual

5160 Ins 5160ES RevF indd sac Download the manual for product Manuals IM lasko 2022 05 ||| CONTROL REMOTO Todas las funciones realizadas con el Control Remoto operan del mismo modo que los co ... NIBLES AL CONSUMIDOR PARA SU INSTALACION O REEMPLAZO. El manual imprimi en la China Rev. F 5/22 8 **5160ES** Used for Model: **5160** Digital Ceramic Tower Heater with Remote Control Instruction Manual Si...

lang:es score:38 filesize: 1.11 M page_count: 4 document date: 2022-05-11




[\[pdf\]](#) User Manual Instructions Catalog

Tower 23 in 1500 Watt Electric Ceramic Oscillating Space Heater with Digital Display and Remote Control Use Care Manual Lasko 5160 046013764713 0046013764713 1000994505 955964ab c528 417f a56c a9058dd920c2 images thdstatic catalog Images 95 |||

MODELO **5160** IMPORTANT INSTRUCTIONS OPERATING MANUAL DIGITAL CERAMIC TOWER HEATER with REMOTE CONTROL MODEL **5160** This Heater is intended for use as supplemental heat. This Heater is for residential use only. It is not intended to be used in commercial, industrial or agricultural settings. GARANTA ...


lang:es score:31 filesize: 1.22 M page_count: 6 document date: 2012-01-16



[Global Express Guaranteed Service Guide - International Shipping Policies](#)

Comprehensive guide detailing policies, regulations, and procedures for Global Express Guaranteed (GXG) international expedited delivery services offered by the United States Postal Service in partnership with FedEx Express. Covers shipping requirements, prohibited items, insurance, and form instructions.

lang:en score:25 filesize: 19.87 M page_count: 1159 document date: 2012-06-12



[\[pdf\]](#) User Manual

5160_Lasko_Ceramic_Tower_Heater_User_Manual lasko uploads 2018 03

MANTENIMIENTO MODELO 5160 Para reducir el riesgo de choque eléctrico e incendio por favor obedezca las siguientes instrucciones. Limpiar el Calefactor regularmente ayudar a mantener su eficiencia. - Siempre desconecte el cable eléctrico antes de mover, reparar o limpiar. - NUNCA coloque el Calefactor...

lang:es score:23 filesize: 1.16 M page_count: 6 document date: 2020-10-20

[\[pdf\]](#)

5160 Ins 5160ES RevF indd sac Digital Ceramic Tower Heater with Remote Control Instructioncambiar de °F a °C con el control remoto 1 El requiere 2 baterías AAA 5 Vcc no incluidas No mezcle viejas y nuevas mezcle 1d33fZDUZc0A1Hm3w4meo55XPwpprIJURefireplacestore files Manuals

1d33fZDUZc0A1Hm3w4meo55XPwpprIJUR srsItid

AfmBOoFuWNAge7iKabrZ7laViNaSzby9fuDxl6ZXnylod1uA 1FZUq4 mezcle efireplacestore

1FZUq4efireplacestore AfmBOorWR eqILTvP3h5VWZ0cucm9Ke6KhJalZ6O7EdzqbP7C3PZIYSn

eqILTvP3h5VWZ0cucm9Ke6KhJalZ6O7EdzqbP7C3PZIYSnefireplacestore AfmBOorw

WxjV0kOOkcXSw4fIyAIO630 cCoVwT5iS4o5B96bQZ3GskM mezcle v1efireplacestore

cCoVwT5iS4o5B96bQZ3GskMefireplacestore AfmBOorXBdkRABXaDHhmTIEGXGjDJu

iK7XqXC2e15KOMAA7GpailapRN AfmBOoqel2fuPPLoyXRRNUXSEDr53FaUN0NZApiz4SkSIXv29qT4

gkYefireplacestore ||| ||| CONTROL REMOTO Todas las funciones realizadas con el Control Remoto

operan del mismo modo que los controles manuales, excepto que usted no puede cambiar de F a C con el control remoto. 1. El control requiere 2 baterías AAA de 1.5 Vcc no incl ||| CONTROL REMOTO Todas

las funciones realizadas con el Control Remoto operan del mismo modo que los controles manuales,

excepto que usted no puede cambiar de F a C con el control remoto. 1. El control requiere 2 baterías AAA

de 1.5 Vcc no incl ||| CONTROL REMOTO Todas las funciones realizadas con el Control Remoto operan

del mismo modo que los controles manuales, excepto que usted no puede cambiar de F a C con el

control remoto. 1. El control requiere 2 baterías AAA de 1.5 Vcc no incl ||| CONTROL REMOTO Todas las

funciones realizadas con el Control Remoto operan del mismo modo que los controles manuales,

excepto que usted no puede cambiar de F a C con el control remoto. 1. El control requiere 2 baterías AAA

de 1.5 Vcc no incl

CONTROL REMOTO Todas las funciones realizadas con el Control Remoto operan

del mismo modo que los co ... NIBLES AL CONSUMIDOR PARA SU INSTALACIÓN O

REEMPLAZO. El manual imprimir en la China Rev. F 5/22 8 **5160ES** Used for Model:

5160 Digital Ceramic Tower Heater with Remote Control Instruction Manual Si...

lang:es score:21 filesize: 1.11 M page_count: 4 document date: 2022-05-11



HEATERPATENTLIST.xlsx gsw lasko 2021 07 |||

[pdf]

HEATERPATENTLIST.xlsx gsw lasko 2021 07 |||

Uploaded to www.laskoproducts.com/patent : 2021.07.01 Heaters Notice to User:
This list associates ... gal rights associated with the property. MODEL # 100 101 102 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
lang:en score:11 filesize: 39.72 K page_count: 5 document date: 2021-06-29

HEATERPATENTLIST.xlsx gsw Heaters lasko 2018 09 |||

[pdf]

HEATERPATENTLIST.xlsx gsw Heaters lasko 2018 09 |||

Uploaded to www.laskoproducts.com/patents : 2018.09.04 Heaters Notice to User:
This list associate ... gal rights associated with the property. MODEL # 100 101 102 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
lang:en score:11 filesize: 28.1 K page_count: 5 document date: 2018-09-04

HEATERPATENTLIST.xlsx gsw lasko uploads 2021 01

[pdf]

HEATERPATENTLIST.xlsx gsw lasko uploads 2021 01

Uploaded to www.laskoproducts.com/patent : 2021.01.04 Heaters Notice to User:
This list associates ... gal rights associated with the property. MODEL # 100 101 102 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
lang:en score:11 filesize: 38.63 K page_count: 5 document date: 2021-01-04

HEATERPATENTLIST.xlsx gsw View lasko 2020 02 |||

[pdf]

HEATERPATENTLIST.xlsx gsw View lasko 2020 02 |||

Uploaded to www.laskoproducts.com/patent : 2020.03.02 Heaters Notice to User:
This list associates ... gal rights associated with the property. MODEL # 100 101 102 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5365 5367 5369 5369 5397 5400 5409 5429 5435 5521 5530 5536 5536 5538 5540 ...
lang:en score:11 filesize: 38.43 K page_count: 5 document date: 2020-02-28

HEATERPATENTLIST.xlsx gsw View lasko 2021 11 |||

[pdf]

HEATERPATENTLIST.xlsx gsw View lasko 2021 11 |||

Uploaded to www.laskoproducts.com/patent : 2021.11.02 Heaters Notice to User:
This list associates ... gal rights associated with the property. MODEL # 100 101 102 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
lang:en score:11 filesize: 39.38 K page_count: 5 document date: 2021-11-02

HEATERPATENTLIST.xlsx gsw Heaters lasko 2021 09 |||

[pdf]

HEATERPATENTLIST.xlsx gsw Heaters lasko 2021 09 |||

Uploaded to www.laskoproducts.com/patent : 2021.09.01 Heaters Notice to User:
This list associates ... gal rights associated with the property. MODEL # 100 101 102 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
lang:en score:11 filesize: 39.67 K page_count: 5 document date: 2021-08-31

HEATERPATENTLIST.xlsx gsw HEATERPATENTLIST-008 lasko uploads 2020 11

[pdf]

HEATERPATENTLIST.xlsx gsw HEATERPATENTLIST-008 lasko uploads 2020 11
 Uploaded to www.laskoproducts.com/patent : 2020.11.02 Heaters Notice to User:
 This list associates ... gal rights associated with the property. MODEL # 100 101 102
 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369
 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
 lang:en score:11 filesize: 38.61 K page_count: 5 document date: 2020-10-29

HEATERPATENTLIST.xlsx gsw Heaters heater patent list lasko 2018 03

[pdf]

HEATERPATENTLIST.xlsx gsw Heaters heater patent list lasko 2018 03
 Uploaded to www.laskoproducts.com/patents : 2018.03.01 Heaters Notice to User:
 This list associate ... gal rights associated with the property. MODEL # 100 101 102
 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369
 5397 5400 5409 5429 5435 5521 5530 5536 5538 5540 5564 5565 5568 ...
 lang:en score:10 filesize: 27.38 K page_count: 5 document date: 2018-03-01

HEATERPATENTLIST.xlsx gsw Heater Patent List Intellectual Property lasko IP


[pdf]

HEATERPATENTLIST.xlsx gsw Heater Patent List Intellectual Property lasko IP
 Uploaded to www.laskoproducts.com/patent : 2022.09.01 Heaters Notice to User:
 This list associates ... gal rights associated with the property. MODEL # 100 101 102
 103 106 1004 1012 4775 5115 5126 5132 **5160** 5165 5307 5309 5365 5367 5369
 5397 5400 5435 5521 5530 5536 5538 5540 5564 5565 5568 5571 5572 ...
 lang:en score:10 filesize: 37.99 K page_count: 5 document date: 2022-08-29

HEATERPATENTLIST.xlsx gsw Heaters Intellectual Property Lasko Products v 1677703318 cdn shopify

[pdf]

HEATERPATENTLIST.xlsx gsw Heaters Intellectual Property Lasko Products v 1677703318 cdn shopify
 s files 1 0415 4009 2054
 Uploaded to www.laskoproducts.com/patent : 2023.03.01 Heaters Notice to User:
 This list associates ... rcing any and all legal rights associated with the property.
 MODEL # 100 101 102 103 106 1004 1012 **5160** 5165 5397 5400 5435 5586 5588
 5592 5840 5841 5842 5848 5868 6050 6101 6221 6451 6462 8101 8132 ...
 lang:en score:10 filesize: 30.12 K page_count: 4 document date: 2023-03-01



[pdf] Warranty Catalog

Michael Morrison Portable Electric Oscillating Ceramic Tower Space Heaters 2 Count Warranty Lasko
 LKO 5160 5307 193802301458 0193802301458 1008464907 b2143b2a c240 401f 8081 82126cb15882
 images thdstatic catalog Images b2
 Warranty: <https://www.lasko.com/resources/warranties/> ...
 lang:en score:9 filesize: 37.4 K page_count: 1 document date: 2022-08-19

Keystone 65 HMO
Provider/Pharmacy Directory

Keystone 65 Basic, Liberty, Preferred, and Select HMO Plans

This directory is current as of December 2022. This directory provides a list of Keystone 65 Basic, Keystone 65 Liberty, Keystone 65 Preferred, and Keystone 65 Select current network providers. This directory is for Bucks, Chester, Delaware, Montgomery, and Philadelphia counties in Pennsylvania.

To access Keystone 65 HMO's online provider directory, you can visit [themidstate.com](https://www.themidstate.com). For any questions about the information contained in this directory, or for more recent information or other questions, please call our Member Help Team at **1-800-645-9965**, seven days a week, 9 a.m. to 9 p.m. TTY/VOIC users should call **711**. Please note that on weekends and holidays from April 1 through September 26, your call may be sent to voicemail.

Changes to our pharmacy network may occur during the benefit year. An updated Provider/Pharmacy Directory is posted on our website at [themidstate.com](https://www.themidstate.com). You may also call our Member Help Team for updated provider information.

This document may be available in alternate formats, such as braille, large print, or audio. To receive this information in an alternate format, please call our Member Help Team at **1-800-645-9965**. TTY/VOIC users should call **711**.

Y0041, R3952, K3, C, 23, 108986

[\[pdf\]](#)

2022 Keystone 65 HMO Provider Pharmacy Directory 2023 KS65 Basic Liberty Preferred Select

Medicare West Penn Ave RAMOS LYSETTE E MD F Spanish Castilian Has evening 6008 Lansdale PA

19446 1001 S Valley Forge Rd Po Box 90 Homa George R ks65 hmo directory ibxmedicare s members

guides and forms |||

Keystone 65 HMO Provider/Pharmacy Directory Keystone 65 Basic, Liberty,

Preferred, and Select HMO PI ... der SACRED HEART PEDIATRIC ASSOCIATES

450 West Chew Street, Suite 202 Allentown, PA 18102 610 776-**5160** Unger, Andrew,

MD M Patients Birth to 18 SHHS SACRED HEART MEDICAL ASSOCIATES 450

West Chew S...

lang:en score:9 filesize: 8.53 M page_count: 1360 document date: 2022-11-30