

Barbie My Secret Diary

Barbie My Secret Diary with Special Invisible Ink Pen User Manual

Model: My Secret Diary

INTRODUCTION

Welcome to the world of Barbie secrets! This manual provides comprehensive instructions for using your Barbie My Secret Diary, which comes with a special invisible ink pen. Keep your thoughts, dreams, and adventures safe and private. The unique pen allows you to write messages that can only be revealed with its special light.



Image 1: The Barbie My Secret Diary with its special invisible ink pen.

SETUP

Before you begin using your secret diary, please follow these steps to ensure proper functionality of the invisible ink pen.

Unboxing

Carefully remove the diary and the special pen from their packaging. Inspect both items for any visible damage.

Battery Installation/Replacement for the Invisible Ink Pen

The invisible ink pen requires batteries for its light function. Battery replacement should always be performed by an adult.

1. The pen uses 3 AG3/LR41 type batteries (1.5V x 3 = 4.5V).
2. To access the battery compartment, press the top part of the pen cap and gently pull it off.
3. Carefully remove any spent batteries.

4. Insert new batteries, ensuring the correct polarity (+/-) is observed.
5. Replace the pen cap securely.

Important Battery Safety Information:

- Rechargeable batteries must not be recharged.
- Do not mix different types of batteries or new and used batteries.
- Batteries must be inserted with the recommended or similar type.
- Spent batteries must be removed from the product promptly.
- Battery terminals must not be short-circuited.
- Do not dispose of batteries in common household waste. Dispose of them at an appropriate recycling facility.



Image 2: Back cover detailing safety warnings and battery replacement instructions.

OPERATING INSTRUCTIONS

Using your Barbie My Secret Diary is simple and fun!

Writing Secret Messages

1. Open your Barbie My Secret Diary to any page.
2. Use the invisible ink pen to write your secret messages, draw pictures, or record your thoughts. The ink will be invisible under normal light.

Revealing Secret Messages

1. To reveal what you have written, locate the small light emitter on the cap of the invisible ink pen.
2. Press the button on the pen cap to activate the light.
3. Shine the light directly onto the page where you wrote your secret message. The invisible ink will glow, making your writing visible.



Image 3: Example of internal diary pages, including 'About Me' sections.

MAINTENANCE

To ensure the longevity of your Barbie My Secret Diary and pen, follow these maintenance tips:

- **Diary Care:** Keep the diary away from moisture and direct sunlight to prevent damage to the pages and cover.
- **Pen Care:** Always replace the pen cap when not in use to prevent the ink from drying out and to protect

the light emitter.

- **Cleaning:** Wipe the diary cover and pen with a soft, dry cloth if they become dirty. Do not use abrasive cleaners or solvents.
- **Storage:** Store the diary and pen in a cool, dry place when not in use.

TROUBLESHOOTING

If you encounter any issues with your Barbie My Secret Diary, refer to the following common solutions:

- **Pen not writing:** Ensure the pen cap is fully removed. If the ink appears dry, gently press the tip on a scrap piece of paper a few times. If the issue persists, the ink may be depleted.
- **Light not working:** Check the batteries in the pen. Refer to the 'Battery Installation/Replacement' section for instructions. Ensure the batteries are inserted with correct polarity.
- **Writing not visible:** Make sure you are shining the pen's light directly onto the invisible ink. Ensure the room is not too brightly lit, as strong ambient light can make the invisible ink harder to see even with the pen's light.

SPECIFICATIONS

Feature	Detail
Product Name	Barbie My Secret Diary with Special Pen
Model	My Secret Diary
ISBN-10	8538071734
ISBN-13	978-8538071730
Item Weight	4.6 ounces (130 grams)
Dimensions	6.14 x 0.55 x 7.8 inches (15.6 x 1.4 x 19.8 cm)
Pen Battery Type	3 x AG3/LR41 (1.5V each)
Recommended Age	3+ years
Language (Product Edition)	Portuguese

SAFETY INFORMATION

WARNING: NOT RECOMMENDED FOR CHILDREN UNDER 3 (THREE) YEARS DUE TO SMALL PARTS THAT CAN BE SWALLOWED OR INHALED AND FUNCTIONAL SHARP POINTS.

Always supervise young children when they are using the diary and pen. Ensure all battery safety guidelines are followed as outlined in the 'Setup' section.

WARRANTY


This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. Please retain your proof of purchase for any warranty claims. Specific warranty details may vary by region and retailer. For more information, please contact your point of purchase.

SUPPORT


For further assistance or inquiries regarding your Barbie My Secret Diary, please refer to the contact information provided by your retailer or the product packaging. Online resources and FAQs may also be available on the official Barbie website.

Related Documents - My Secret Diary

	<p>Kristi Yamaguchi Barbie Podcast Activity Guide: Dreaming on Ice</p> <p>An activity guide from the Barbie Dream Gap Project featuring Kristi Yamaguchi, focusing on learning from failure, building confidence, and resilience through engaging exercises and discussions.</p>
	<p>Barbie Queen of the Prom Board Game Rules and Instructions</p> <p>Official rules and instructions for the Barbie Queen of the Prom board game by Mattel. Learn how to play, game components, and winning conditions.</p>
	<p>HMD Barbie Phone User Guide</p> <p>This user guide provides comprehensive instructions for the HMD Barbie Phone, covering setup, basic functions like calls, contacts, and messages, personalization options, camera usage, Bluetooth connectivity, and safety information.</p>
	<p>HMD Barbie Phone User Guide</p> <p>User guide for the HMD Barbie Phone, covering setup, features, safety information, and troubleshooting.</p>
	<p>Guide d'utilisation du HMD Barbie Phone</p> <p>Ce guide complet fournit des instructions détaillées pour l'utilisation du HMD Barbie Phone, couvrant la prise en main, les appels, les messages, la personnalisation, l'appareil photo, le Bluetooth, l'horloge, l'agenda, la calculatrice, la réinitialisation et les informations de sécurité.</p>

<div></div> <div>HMD Barbie Phone Benutzerhandbuch</div> <div><small>August 2003 01 16 11 17</small></div>	<div>HMD Barbie Phone User Manual</div> <div>This user manual provides comprehensive instructions for the HMD Barbie Phone, covering setup, basic operations, personalization, camera usage, Bluetooth connectivity, clock, calendar, calculator functions, and safety guidelines.</div>
---	--

Documents - Barbie – My Secret Diary



[pdf] User Manual Quick Start Guide Warranty

73029 manual qxd Tony TM FEATURES FLOWER LIGHTS PEN CLIP During this 90 day warranty period the game will either be repaired or replaced at our option without charge to purchaser when returned prepaid with proof of date purchase Radica USA Ltd 13628 A Beta Road Dallas Texas 75244 Please remove batteries and wrap unit carefully before shipping include a brief I3029 service mattel instruction sheets

E TM Do not dispose of batteries in fire. Batteries might leak if improperly installed, or explode if recharged, disassembled or heated. FEATURES FLOWER LIGHTS - Secures the lid of **My Secret Diary**TM to keep your thoughts safe. FLOWER PEN - The flower on the pen is the magical key Wave the flower...

lang:en score:31 filesize: 63.33 K page_count: 2 document date: 2003-03-06