

Raffi 011661807723

Raffi: The Singable Songs Collection CS Audio CD Manual

Model: 011661807723

1. INTRODUCTION

Welcome to the instruction manual for **Raffi's The Singable Songs Collection CS**. This collection features three classic audio CDs: *Singable Songs for the Very Young*, *More Singable Songs*, and *Corner Grocery Store*. Designed for young children and families, these albums offer a joyful blend of traditional and original songs. This manual provides essential information for setting up, operating, and maintaining your audio CD set.



Image 1.1: The album cover for Raffi's The Singable Songs Collection CS, featuring artwork from the three included CDs. This collection brings together over 50 musical tracks for family enjoyment.

2. SETUP

To begin enjoying **The Singable Songs Collection CS**, follow these simple steps:

1. **Unpack the Collection:** Carefully remove the three audio CDs from their packaging.
2. **Select a CD:** Choose one of the three discs you wish to play.
3. **Insert into Player:** Open the disc tray or slot of your compatible audio CD player (e.g., home stereo, car CD player, portable CD player, computer with CD drive). Insert the chosen CD with the label side facing up.
4. **Close Tray/Slot:** Close the disc tray or allow the player to draw the disc in.

Ensure your audio player is connected to a power source and appropriate speakers or headphones for sound output.

3. OPERATING INSTRUCTIONS

Once the CD is loaded, you can control playback using your audio player's functions:

- **Play:** Press the **PLAY** button to start playback from the beginning of the disc or the current track.
- **Pause:** Press the **PAUSE** button to temporarily stop playback. Press **PLAY** again to resume.

- **Stop:** Press the **STOP** button to end playback and reset the disc to the beginning.
- **Skip Tracks:** Use the **NEXT** (>>|) or **PREVIOUS** (|<<<) buttons to navigate between songs.
- **Fast Forward/Rewind:** Hold down the **FAST FORWARD** (>>>) or **REWIND** (<<<) buttons to scan through a track.
- **Volume Control:** Adjust the volume using your player's dedicated volume controls.

A lyric book is often included with Raffi's collections. Refer to it for song lyrics and sing-along enjoyment.

4. MAINTENANCE AND CARE

Proper care will ensure the longevity and optimal performance of your audio CDs:

- **Handling:** Always hold CDs by their edges or by placing a finger through the center hole. Avoid touching the shiny playback surface.
- **Cleaning:** If a CD becomes dirty or smudged, gently wipe it with a soft, lint-free cloth (e.g., microfiber) from the center outwards. Do not use abrasive materials or harsh chemical cleaners.
- **Storage:** Store CDs in their original jewel cases or protective sleeves when not in use. Keep them away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Prevent scratches by handling discs carefully and storing them properly. Scratches can lead to playback errors.

5. TROUBLESHOOTING

If you encounter issues during playback, consider the following common solutions:

Problem	Possible Cause	Solution
CD does not play or is not recognized.	Disc inserted incorrectly, dirty disc, incompatible player, or player malfunction.	Ensure the disc is inserted label-side up. Clean the disc gently. Try the CD in another player to rule out player issues.
Audio skips or stutters.	Scratched or dirty disc, or player vibration.	Clean the disc carefully. Inspect for deep scratches. Ensure the player is on a stable surface.
No sound.	Volume too low, speakers disconnected, or player audio settings.	Increase volume. Check speaker connections. Verify player's audio output settings.

If problems persist after attempting these solutions, consult your audio player's manual or contact the player's manufacturer for further assistance.

6. SPECIFICATIONS

- **Product Title:** The Singable Songs Collection CS
- **Artist:** Raffi
- **Format:** Audio CD
- **Number of Discs:** 3
- **Model Number:** 011661807723

- **Manufacturer:** Rounder
- **Original Release Date:** 1996
- **Language:** English
- **Product Dimensions:** 5.08 x 5.67 x 1.14 inches
- **Item Weight:** 7.41 ounces
- **ASIN:** B0000003IO

7. SUPPORT

For questions regarding the content of **The Singable Songs Collection CS** or general inquiries about Raffi's music, please refer to official Raffi resources or the record label, Rounder.

For issues related to the physical product (e.g., damaged discs upon arrival), please contact your retailer within their specified return period. For this product, a 30-day return/replacement policy is typically offered by retailers.