

Vanguard 1978597

Alisha Audio CD User Manual

Model: 1978597

INTRODUCTION

This manual provides essential instructions for the proper use and care of your Alisha Audio CD. Please read this guide thoroughly to ensure optimal performance and longevity of your product.

SETUP

To set up your Alisha Audio CD for playback, follow these steps:

1. **Unpack:** Carefully remove the Audio CD from its packaging.
2. **Inspect:** Check the disc surface for any visible scratches, dust, or smudges.
3. **Insert:** Open the disc tray of your compatible CD player (e.g., home stereo, car CD player, computer CD/DVD drive). Place the CD with the label side facing up onto the spindle.
4. **Close:** Gently close the disc tray.

OPERATING

Once the CD is loaded, you can begin playback:

1. **Power On:** Ensure your CD player is powered on.
2. **Play:** Press the "Play" button on your CD player or its remote control. The first track will typically begin playing automatically.
3. **Track Selection:** Use the "Next Track" or "Previous Track" buttons to navigate between songs.
4. **Pause/Stop:** Use the "Pause" button to temporarily stop playback and "Stop" to end playback.
5. **Volume Control:** Adjust the volume using your CD player's or amplifier's volume controls.

MAINTENANCE

Proper care will extend the life of your Audio CD:

- **Handling:** Always hold the CD by its edges or by placing a finger through the center hole. Avoid touching the playing surface.
- **Cleaning:** If the disc is dirty, gently wipe it with a soft, lint-free cloth. Wipe from the center outwards in a straight line, not in a circular motion. Do not use abrasive cleaners or solvents.
- **Storage:** Store the CD in its original jewel case or a protective sleeve when not in use to prevent scratches and dust accumulation. Keep it away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Bending:** Do not bend the disc, as this can cause irreparable damage.

TROUBLESHOOTING

If you encounter issues during playback, consider the following:

- **Disc Not Playing:**
 - Ensure the disc is inserted correctly with the label side up.
 - Check if the disc is clean and free of smudges or scratches. Clean if necessary.
 - Verify that your CD player is functioning correctly with other discs.
- **Skipping or Stuttering:**
 - Clean the disc thoroughly as described in the Maintenance section.
 - Check for deep scratches on the playing surface. Severe scratches may prevent proper playback.
 - Ensure the CD player is on a stable surface to prevent vibrations.
- **No Sound:**
 - Check the volume level on your CD player and amplifier.
 - Ensure all audio cables are securely connected.

SPECIFICATIONS

Detailed information regarding the Alisha Audio CD:

- **Artist:** Alisha
- **Format:** Audio CD
- **Manufacturer:** Vanguard
- **Item Model Number:** 1978597
- **ASIN:** B000000EM3
- **Number of Discs:** 1
- **Language:** English
- **Product Dimensions:** 5.6 x 0.4 x 4.9 inches; 4 ounces
- **Date First Available:** November 3, 2006
- **Total Time:** 40:49
- **Audio:** STEREO

Tracklist



This image displays the back cover of the Alisha Audio CD, detailing the tracklist, song durations, and associated music publishers. It also includes copyright information and the UPC barcode.

1. **All Night Passion** - original version 6:48 (*Rick Tarbox; Starbo Music/ASCAP*)
2. **Stargazing** - extended dance mix 5:48 (*Jimmy Halperin; Jackaroe Music Publishers/Baby Raquel Music/Singapore Transformations/ASCAP*)
3. **Baby Talk** - extended dance mix 6:45 (*Greg Brown-Logankoya; Hub Music/MCA Music/ASCAP*)
4. **Too Turned On** 6:18 (*Alexandra Forbes; Jackaroe Music Publishers/Baby Raquel Music Inc./ASCAP*)
5. **Boys Will Be Boys** 3:33 (*Peggy Stanziale-Andrea La Russo; Jackaroe Music Publishers/Baby Raquel Music/Purple Traffic Inc./Topaz Star Music Inc./ASCAP*)
6. **One Little Lie** 4:32 (*Kirsty MacColl-Simon Climie; Chrysalis Music*)
7. **All Night Passion** - extended dance mix 7:05 (*Rick Tarbox; Starbo Music/ASCAP*)

WARRANTY INFORMATION

This Audio CD is a physical media product. For information regarding potential defects in manufacturing, please refer to

the retailer's return policy or contact the manufacturer, Vanguard, directly. Specific warranty details are not provided in this manual.

SUPPORT

For further assistance or inquiries, please contact the retailer where the product was purchased. Manufacturer contact information for Vanguard Records can typically be found on their official website or through general online search.

© 1986, 1985 Vanguard Records. All rights reserved. Unauthorized duplication is a violation of applicable laws.
Printed in U.S.A.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question