Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Virgin /
- Massive Attack Mezzanine Audio CD User Manual

Virgin 2132406

Massive Attack Mezzanine Audio CD User Manual

Model: 2132406

1. Introduction

Welcome to the user manual for the Massive Attack Mezzanine Audio CD. This guide provides comprehensive information to help you understand, use, and maintain your audio CD, ensuring a high-quality listening experience. Please read through this manual carefully to familiarize yourself with the product and its care requirements.

2. PRODUCT OVERVIEW

The 'Mezzanine' Audio CD is the critically acclaimed third studio album by the English trip-hop group Massive Attack, originally released in 1998. Known for its dark, atmospheric soundscapes and intricate production, it features iconic tracks such as 'Angel', 'Risingson', and 'Teardrop'. This Audio CD format provides a high-fidelity physical medium for enjoying the album.



This image displays the album cover for the 'Mezzanine' Audio CD. It features a striking black and white design with a large, detailed image of an insect, characteristic of the album's dark and intricate aesthetic.

3. SETUP: PLAYING THE AUDIO CD

To enjoy your 'Mezzanine' Audio CD, follow these simple steps:

- 1. **Select a Compatible Player:** Ensure you have an audio CD player, car CD player, computer with a CD-ROM drive, or a compatible game console.
- 2. Open the Disc Tray: Gently press the eject button on your CD player to open the disc tray.
- 3. **Insert the CD:** Hold the CD by its edges to avoid touching the playing surface. Place the CD into the disc tray with the label side facing upwards.
- 4. Close the Disc Tray: Gently push the tray back into the player or press the eject button again.
- 5. Start Playback: Your player should automatically begin playing the CD, or you may need to press the 'Play' button.

4. OPERATING: HANDLING AND STORAGE

Proper handling and storage are crucial for preserving the quality and longevity of your Audio CD.

- **Handling:** Always hold the CD by its outer edges or by placing a finger through the center hole. Avoid touching the shiny playing surface, as fingerprints and oils can affect playback quality.
- **Storage:** Store the CD in its original jewel case or a protective sleeve when not in use. This protects it from dust, scratches, and environmental damage.
- Environmental Conditions: Keep the CD away from direct sunlight, extreme temperatures, and high humidity. Excessive heat can warp the disc, and humidity can promote mold growth.
- Avoid Bending: Do not bend or flex the CD, as this can cause irreparable damage to the disc's data layer.

5. Maintenance: Cleaning the Disc

If your CD accumulates dust or fingerprints, follow these steps for safe cleaning:

- 1. Use a Soft, Lint-Free Cloth: A microfiber cloth or a soft cotton cloth is ideal.
- Clean from Center Outwards: Gently wipe the playing surface in straight lines from the center hub towards the outer edge. Do not wipe in circular motions, as this can create circular scratches that are more likely to cause playback issues.
- 3. **Dampen if Necessary:** For stubborn smudges, slightly dampen the cloth with water or a specialized CD cleaning solution. Never use abrasive cleaners, solvents, or harsh chemicals.
- 4. Dry Thoroughly: Ensure the CD is completely dry before reinserting it into a player.

6. TROUBLESHOOTING: PLAYBACK ISSUES

If you encounter problems playing your 'Mezzanine' Audio CD, consider the following common issues and solutions:

Problem	Possible Cause	Solution
Disc skips or stutters	Dust, fingerprints, or minor scratches on the playing surface.	Clean the disc using the method described in Section 5. Inspect for deep scratches.
Disc does not play	Disc inserted incorrectly, severe damage, or player malfunction.	Ensure the disc is inserted label-side up. Check for visible damage. Try the disc in another player to rule out player issues.
Sound quality is poor	Dirty disc, faulty cables, or player settings.	Clean the disc. Check audio cables connecting your player to the amplifier/speakers. Adjust player's audio settings if applicable.

7. Specifications

Key technical specifications for the Massive Attack Mezzanine Audio CD:

• ASIN: B000006045

Item Model Number: 2132406

• Product Dimensions: 5.87 x 5.63 x 0.43 inches

• Item Weight: 3.67 ounces

• Number of Discs: 1

• Label: Virgin

Manufacturer: VirginLanguage: English

• Date First Available: December 13, 2006

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or product support, please refer to the documentation provided by your retailer at the time of purchase. As this is an Audio CD, specific warranty terms typically relate to manufacturing defects. For general inquiries about the album or artist, please refer to official Massive Attack resources or the record label, Virgin Records.

© 2024 Virgin Records. All rights reserved.

Related Documents - 2132406



Virgin Media TV 360 Icon Guide

A comprehensive guide to the icons used on the Virgin Media TV 360 interface, explaining their meaning and function.



Virgin Media Flex Icon Guide

A comprehensive guide to understanding the icons used on Virgin Media's Flex service, explaining their meaning and function for users.



Virgin Organic Rosehip Oil Material Safety Data Sheet (MSDS) - Purefx

Material Safety Data Sheet (MSDS) for Virgin Organic Rosehip Oil from Purefx. Provides information on identification, hazards, composition, first aid, fire-fighting, accidental release, handling, storage, exposure controls, physical and chemical properties, stability, toxicology, ecology, disposal, transport, and regulatory information.



Samsung Galaxy Ring Android Smartphone User Guide

This comprehensive user guide provides detailed instructions for setting up, operating, and troubleshooting the Samsung Galaxy Ring Android Smartphone. Learn about its features, connectivity options, and essential functions for Virgin Mobile users.



Apricot Kernel Oil - Virgin Safety Data Sheet

Safety Data Sheet for Apricot Kernel Oil - Virgin by Bulk Naturals Wholesale LLC. Provides information on identification, hazards, composition, first aid, fire-fighting, accidental release measures, handling and storage, exposure controls, physical and chemical properties, stability, toxicology, ecology, disposal, transport, and regulatory information.



Bell and Virgin Plus Extended Warranty Program for Smartphones

Information on Bell and Virgin Plus's extended warranty programs for smartphones, covering accidental damage, liquid damage, and defects beyond the manufacturer's warranty. Details on enrollment, monthly fees, replacement fees, and eligible devices.