

Lime B0000071LX

User Manual: Lime 3 Audio CD

Model: B0000071LX | Brand: Lime

INTRODUCTION

This manual provides essential information for the proper use and care of your Lime 3 Audio CD. This product is an Audio CD featuring music by the artist Lime, specifically their third album. Please read this manual thoroughly to ensure optimal enjoyment and longevity of your product.




Figure 1: Front cover artwork of the Lime 3 Audio CD. The image depicts a stylized green soda can with "Lime 3" written on it, held by a hand with red nail polish, set against a blue background with a yellow polka-dotted pattern visible at the bottom.

SETUP

To begin using your Lime 3 Audio CD, follow these simple steps:

1. **Unpack the CD:** Carefully remove the Audio CD from its packaging. Avoid touching the playing surface (the shiny side) of the disc.
2. **Prepare your CD Player:** Ensure your Audio CD player is clean and powered on. Open the disc tray or lid.
3. **Insert the CD:** Hold the CD by its edges or the center hole. Place the CD into the disc tray with the label side facing up.
4. **Close the Tray:** Gently close the disc tray or lid of your CD player.

OPERATING INSTRUCTIONS

Once the CD is loaded, you can begin playback:

- **Start Playback:** Press the "Play" button on your CD player or remote control. The first track of the album will typically begin playing.
- **Track Selection:** Use the "Next Track" or "Previous Track" buttons to navigate between songs. Most players also allow direct track selection using a numeric keypad.
- **Volume Control:** Adjust the volume using your CD player's or amplifier's volume controls.
- **Pause/Stop:** Use the "Pause" button to temporarily stop playback and "Stop" to end playback and reset the disc to the beginning.

MAINTENANCE AND CARE

Proper care will help preserve the quality and lifespan of your Audio CD:

- **Handling:** Always hold the CD by its outer edge or the center hole. Avoid touching the shiny playing surface to prevent fingerprints and scratches.
- **Cleaning:** If the CD becomes dirty, gently wipe it with a soft, lint-free cloth. Wipe from the center outwards in a straight line, not in a circular motion. Do not use abrasive cleaners or solvents.
- **Storage:** Store the CD in its original jewel case or a protective sleeve when not in use. Keep it away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Bending:** Do not bend the CD, as this can cause irreparable damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
CD will not play or skips	<ul style="list-style-type: none">• Dirty or scratched disc• CD inserted incorrectly• CD player malfunction	<ul style="list-style-type: none">• Clean the disc as described in the Maintenance section.• Ensure the disc is inserted label-side up.• Try playing another CD to confirm player functionality.

Problem	Possible Cause	Solution
No sound	<ul style="list-style-type: none"> Volume too low or muted Audio cables disconnected 	<ul style="list-style-type: none"> Increase volume or unmute your audio system. Check all audio cable connections between the CD player and amplifier/speakers.

SPECIFICATIONS

- Product Type:** Audio CD
- Artist:** Lime
- Album Title:** Lime 3
- ASIN:** B0000071LX
- Number of Discs:** 1
- Language:** English
- Product Dimensions:** 5.66 x 0.3 x 5.15 inches; 2.4 ounces
- Manufacturer:** Unidisc Records
- Date First Available:** February 13, 2007

WARRANTY INFORMATION

Specific warranty details for this Audio CD are not provided in the product information. Typically, Audio CDs are covered by a limited warranty against manufacturing defects at the point of purchase. For issues related to manufacturing defects, please contact the retailer where the product was purchased. Damage due to improper handling or storage is generally not covered.

SUPPORT

For further assistance or inquiries regarding the Lime 3 Audio CD, please refer to the following:

- Retailer Support:** Contact the customer service department of the retailer from whom you purchased this product.
- Manufacturer Information:** The manufacturer is Unidisc Records. You may be able to find contact information on their official website for general inquiries.
- Online Resources:** Search for information regarding Audio CD care and troubleshooting on reputable audio enthusiast forums or manufacturer websites.