

[manuals.plus](#) /› [Westinghouse](#) /› [Westinghouse 7006500 White Outlet Concealer Instruction Manual](#)**Westinghouse 7006500**

Westinghouse 7006500 White Outlet Concealer Instruction Manual

1. PRODUCT OVERVIEW

The Westinghouse 7006500 White Outlet Concealer is designed to cover and aesthetically improve the appearance of outdated or discolored electrical outlet boxes. This flat, white plate seamlessly blends with most surroundings and can be painted or wallpapered to match your decor. It is specifically designed for 4-inch outlet boxes.



Image 1.1: Front view of the Westinghouse 7006500 White Outlet Concealer.

2. SAFETY INFORMATION

WARNING: This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov. Always ensure power is disconnected before working with electrical components.

3. PACKAGE CONTENTS

- 1 x Westinghouse 7006500 White Outlet Concealer Plate
- 2 x 8-32 by 3/4-inch white head screws

4. INSTALLATION INSTRUCTIONS

Follow these steps to properly install your outlet concealer:

1. **Safety First:** Before beginning installation, ensure the power to the electrical outlet box is turned off at the circuit breaker.
2. **Prepare the Area:** Carefully remove any existing cover or fixture from the 4-inch outlet box.

3. **Position the Concealer:** Place the Westinghouse 7006500 White Outlet Concealer over the 4-inch outlet box, aligning the two holes on the concealer with the screw holes on the outlet box. The holes are spaced 3-1/2 inches apart.
4. **Secure the Concealer:** Insert the two provided 8-32 by 3/4-inch white head screws into the aligned holes and tighten them securely. Do not overtighten.
5. **Restore Power:** Once the concealer is firmly in place, you may restore power to the circuit.

5. CUSTOMIZATION AND MAINTENANCE

The white finish of the concealer is designed to be easily integrated into your home decor. For a more customized look, you can paint or wallpaper the concealer to match the surrounding wall surface.



Image 5.1: Example of the outlet concealer painted to blend with the wall color.

To clean the concealer, wipe it with a soft, damp cloth. Avoid abrasive cleaners that may damage the finish.

6. TROUBLESHOOTING

- **Concealer does not fit the outlet box:** Ensure your outlet box is a standard 4-inch round box and that the screw holes are spaced 3-1/2 inches apart. This concealer is designed for these specific dimensions.
- **Screws do not align:** Double-check the alignment of the concealer with the outlet box screw holes. If

the holes on your box are not 3-1/2 inches apart, this product may not be compatible.

- **Concealer appears flimsy or gaps after installation:** Ensure the screws are tightened sufficiently, but do not overtighten. The plate is designed to be flat; if the underlying surface is uneven, minor gaps may occur.

7. SPECIFICATIONS

Feature	Specification
Model Number	7006500
Brand	Westinghouse
Color	White
Diameter	4-3/4 inches
Mounting	On 4-inch outlet boxes
Screw Spacing	3-1/2 inches (center-to-center)
Included Screws	Two 8-32 by 3/4-inch white head screws
Product Dimensions	4.75 x 4.75 x 4.75 inches; 0.96 ounces
Country of Origin	China

8. WARRANTY INFORMATION

Specific warranty details for the Westinghouse 7006500 White Outlet Concealer are not provided in this manual. For information regarding product warranty, please refer to the packaging or contact Westinghouse customer support directly.

9. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries about the Westinghouse 7006500 White Outlet Concealer, please visit the official Westinghouse website or contact their customer service department. Contact information can typically be found on the product packaging or the brand's official website.

You can also visit the [Westinghouse Store on Amazon](#) for more product information.