

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SEGA](#) /

› [SEGA Streets of Rage Sega Genesis Instruction Manual](#)

SEGA 91019

SEGA Streets of Rage for Sega Genesis - Instruction Manual

Model: 91019

INTRODUCTION

Welcome to the world of Streets of Rage. This manual provides essential information for setting up, playing, and maintaining your SEGA Streets of Rage game cartridge for the Sega Genesis console. Join Axel, Adam, and Blaze as they fight to reclaim their city from criminal gangs.

SETUP

Installing the Game Cartridge

To begin playing, ensure your Sega Genesis console is powered off. Gently insert the Streets of Rage game cartridge into the cartridge slot on the console. Apply firm, even pressure until the cartridge is fully seated. Do not force the cartridge.





Image: The SEGA Streets of Rage game cartridge, still sealed in its original packaging, ready for installation into a Sega Genesis console.

Verify the cartridge is correctly inserted before powering on the console. The game's UPC is [010086010190](#).

STREETS OF RAGE™



Great 2 player action!

Axel, Adam and Blaze — ex-cops, the solution to punk pollution. The city's a war zone, and they're going out two at a time to give the gangs a kick in the guts.

This is the ultimate in street combat. These city fighters are martial arts maniacs with a battery of 40 individually controllable attacks — including jabs, head butts, and overhead kicks. They're up against a mob of Kung-Fu creeps and axe hurling fiends.

On the streets it's only two of them against hordes of attacking scum. Slam into pipe-wielding weirdos and bash 'em with their own metal. Throw an uppercut or an elbow smash — these goons keep comin'.

KIDS TO ADULTS

ANIMATED VIOLENCE

For information on this product's rating, please call 1-800-771-3772



Sega is a registered trademark of SEGA. Genesis and Streets of Rage are trademarks of SEGA. This game is licensed by Sega for home play on the Sega Genesis system only. Copying and/or transmission of this game is strictly prohibited. Unauthorized rental or public performance of this game is a violation of applicable laws. ©1995 SEGA, P.O. Box 8097, Redwood City, CA 94063. All rights reserved. Software programmed in Japan. Made and printed in USA.



We use recycled paper.

SEGA

Patents: U.S. Pat. 5,442,489; 5,493,485; 5,493,479; Europe No. 88044; Canada No. 1,183,279; Hong Kong No. 50-355; Singapore No. 18-155; Japan No. 62-100900 (pending).

Image: The reverse side of the game's packaging, displaying the game description, player count, and the Universal Product Code (UPC).

OPERATING INSTRUCTIONS

Starting the Game

Power on your Sega Genesis console. The game should load automatically. Press the **START** button on your controller at the title screen to begin.

Character Selection

Choose one of three characters: Axel Stone, Adam Hunter, or Blaze Fielding. Each character possesses unique attributes in terms of strength, speed, and jump ability.

- **Axel Stone:** A balanced character with good all-around abilities.
- **Adam Hunter:** Possesses greater strength but is slower in movement.
- **Blaze Fielding:** Faster and more agile, but with less raw power.

Controls

Refer to the following standard Sega Genesis controller layout for in-game actions:

- **Directional Pad (D-Pad):** Move character (Up, Down, Left, Right).
- **A Button:** Special Attack (consumes a portion of health or a special attack item).
- **B Button:** Attack (punches, kicks).
- **C Button:** Jump.
- **START Button:** Pause game, access options.

Combat Mechanics

Engage enemies using a variety of martial arts attacks. Combine directional inputs with the attack button for different moves, such as jabs, head butts, and overhead kicks. Picking up weapons found in the environment can enhance your attacks.

Two-Player Mode

Streets of Rage supports two-player cooperative gameplay. Connect a second controller to the console and select the two-player option from the main menu to play with a friend.

MAINTENANCE

Cartridge Care

To ensure the longevity and proper function of your game cartridge, follow these guidelines:

- Store the cartridge in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep the cartridge contacts clean. If the game fails to load, gently clean the gold contacts on the bottom of the cartridge with a cotton swab lightly dampened with isopropyl alcohol. Allow to dry completely before re-inserting.
- Avoid touching the gold contacts with your fingers.
- Do not expose the cartridge to liquids or excessive dust.

TROUBLESHOOTING

Game Does Not Start

If the game does not load after powering on the console:

1. Ensure the cartridge is fully and correctly seated in the console's slot.

2. Power off the console, remove the cartridge, and re-insert it firmly.
3. Clean the cartridge contacts as described in the Maintenance section.
4. Verify your Sega Genesis console is properly connected to your television and power source.

Controls Unresponsive

If controller inputs are not registering:

1. Check that the controller is securely plugged into the console's controller port.
2. Test with a different controller if available to rule out a controller malfunction.
3. Ensure no debris is obstructing the controller's buttons or D-Pad.

SPECIFICATIONS

Feature	Detail
Model Number	91019
UPC	010086010190
Platform	Sega Genesis
Item Weight	1.6 ounces
Product Dimensions	4.1 x 2.6 x 0.5 inches
Manufacturer	Sega of America, Inc.
Release Date	January 1, 2000
Player Count	1 or 2 Players
Rating	Kids to Adults (Animated Violence)

For information regarding the game's rating, please call 1-800-771-3772.

WARRANTY INFORMATION AND CUSTOMER SUPPORT

This product is a vintage video game cartridge. Specific warranty details for new purchases may vary depending on the retailer and original purchase date. For general inquiries or technical support related to Sega Genesis products, please refer to official Sega support channels or authorized service centers. For product rating information, please contact 1-800-771-3772.