

[Manuals.plus](#) /

> [OXO](#) /

> OXO Good Grips Stainless Steel Potato Masher Instruction Manual

OXO B00004OCJK

OXO Good Grips Stainless Steel Potato Masher Instruction Manual

PRODUCT OVERVIEW

The OXO Good Grips Stainless Steel Potato Masher is designed for efficient mashing of various foods. It features a durable stainless steel head and a comfortable, non-slip handle.



Figure 1: Front view of the OXO Good Grips Stainless Steel Potato Masher.

KEY FEATURES

- **Versatile Mashing:** Suitable for potatoes, root vegetables, fruits, and other soft foods.
- **Durable Construction:** Equipped with a sturdy stainless steel wire head for effective mashing.
- **Ergonomic Handle:** Features a soft, comfortable, and non-slip handle designed to absorb pressure during use.
- **Easy Storage:** Includes a large hole in the handle for convenient hanging.

**Cushioned
handle absorbs
pressure, won't
slip when wet**



Figure 2: The cushioned, non-slip handle provides comfort during mashing.

SETUP

The OXO Good Grips Stainless Steel Potato Masher requires no assembly. Remove all packaging materials before first use.

OPERATING INSTRUCTIONS

1. **Prepare Food:** Ensure food items such as potatoes, yams, carrots, or fruits are cooked until soft enough for mashing.
2. **Position Masher:** Place the masher head directly onto the food in a bowl or pot.
3. **Apply Pressure:** Grip the comfortable handle firmly and press down, using a rocking or circular motion to mash the food to the desired consistency.
4. **Repeat:** Continue mashing until all food is processed.

**Stainless steel
head works in
bowls or pots**



Figure 3: Mashing potatoes in a bowl using the stainless steel head.



Figure 4: The masher is effective for use in pots as well.

MAINTENANCE & CLEANING

To maintain the longevity and hygiene of your potato masher, follow these cleaning instructions:

- **Hand Washing:** Wash the masher with warm, soapy water immediately after use. Rinse thoroughly and dry completely to prevent water spots or corrosion.
- **Dishwasher Safety:** The product specifications indicate that the item is **not** dishwasher safe. Hand washing is recommended.
- **Storage:** Utilize the hanging hole in the handle for convenient storage, or store in a utensil drawer.

TROUBLESHOOTING

This is a simple mechanical tool, and issues are rare. However, consider the following if you encounter difficulties:

- **Difficulty Mashing:** Ensure food items are adequately cooked and soft. Hard or undercooked items will be difficult to mash.
- **Food Sticking:** If food sticks to the masher head, use a spoon or spatula to scrape it off. Rinsing the masher head under water periodically during use can also help.

SPECIFICATIONS

Attribute	Detail
Brand	OXO
Model Number (ASIN)	B00004OCJK

Material	Stainless Steel (Head), Rubber (Handle)
Color	Stainless Steel
Item Weight	0.1 Kilograms
Product Dimensions (L x W)	9.63"L x 3.38"W
Dishwasher Safe	No
GTIN/UPC	719812262918, 885417744750

WARRANTY & SUPPORT

Manufacturer Warranty: Satisfaction guaranteed.

For further support or warranty claims, please contact OXO customer service directly. Refer to the product packaging or the official OXO website for current contact information.