

OXO 33881

OXO Good Grips All Purpose Scrub Brush Instruction Manual

Model: 33881 | Brand: OXO

PRODUCT OVERVIEW

The OXO Good Grips All Purpose Scrub Brush is designed for various home cleaning tasks. It features a contoured handle for comfortable use and effective scrubbing, protecting your knuckles from surfaces. The non-slip grip ensures secure handling even when wet, providing leverage for efficient cleaning.



Image: The OXO Good Grips All Purpose Scrub Brush, featuring a white handle with a black non-slip grip and stiff bristles.

KEY FEATURES

- **Contoured Handle:** Designed to absorb pressure and protect knuckles during scrubbing.
- **Stiff and Gentle Bristles:** Effectively scrubs away dirt, grime, mildew, and soap scum from various surfaces.
- **Soft, Comfortable Non-Slip Grip:** Ensures a secure hold, even when the brush is wet.
- **Durable Construction:** Made from plastic with nylon and PP bristles for long-lasting performance.



Image: A hand holding the OXO scrub brush, actively scrubbing a surface, highlighting the ergonomic handle design.

SETUP

The OXO Good Grips All Purpose Scrub Brush requires no assembly. Simply remove it from its packaging before first use. It is ready for immediate application in your cleaning routine.

OPERATING INSTRUCTIONS

1. **Prepare Surface:** For best results, pre-wet the surface to be cleaned and apply your preferred cleaning solution.
2. **Grip the Brush:** Hold the brush firmly by its contoured handle, ensuring your knuckles are protected. The non-slip grip provides stability.
3. **Scrub:** Apply moderate pressure and scrub the soiled area using the stiff bristles. The brush is effective on various surfaces including bathtubs, tiles, and grout.
4. **Rinse:** After scrubbing, rinse the cleaned surface thoroughly with water to remove cleaning solution and loosened dirt.

Your browser does not support the video tag.

Video: Official product overview demonstrating the OXO Good Grips All Purpose Scrub Brush in use for various cleaning tasks.

MAINTENANCE

- **Cleaning the Brush:** Rinse the brush thoroughly under running water after each use to remove any residue. For deeper cleaning, the brush is dishwasher-safe.
- **Drying:** Shake off excess water and allow the brush to air dry. The handle design allows it to be hung on the edge of a sink or hook for convenient drying and storage.
- **Storage:** Store the brush in a dry area to prolong its lifespan.



Image: The OXO scrub brush conveniently hanging on the edge of a utility sink, illustrating its design for easy drying and storage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Bristles appear worn or bent.	Normal wear and tear from aggressive scrubbing or prolonged use.	While some wear is expected over time, the brush is designed for durability. Consider replacing the brush if effectiveness is significantly reduced.

Issue	Possible Cause	Solution
Brush feels slippery when wet.	Excess soap residue or improper grip.	Ensure the non-slip grip area is clean. Adjust your hand position to fully utilize the contoured handle for a secure hold.

SPECIFICATIONS

Brand	OXO
Model Number	33881
Product Dimensions	5"L x 3"W x 4"H (12.7 cm L x 7.6 cm W x 10.1 cm H)
Item Weight	2.08 ounces (0.13 Pounds)
Material	Plastic (Handle), Nylon and PP bristles
Color	White with Black grip
Specific Uses	Bathtub, Tile, Grout, General Household Cleaning
Included Components	Handle



Image: Detailed dimensions of the OXO Good Grips All Purpose Scrub Brush, showing its length, width, and height.

WARRANTY AND SUPPORT

OXO stands by the quality of its products. The OXO Better Guarantee ensures that if you experience any issue with your OXO product, you can contact them for a repair or replacement. This commitment reflects their dedication to product improvement based on user experience.

For further assistance or to learn more about OXO products, please visit the official [OXO Store on Amazon](#).