

[Manuals.plus](#) /

› [Nordic Ware](#) /

› Nordic Ware 01940 Scandinavian Dollar Pancake Pan Instruction Manual

Nordic Ware 01940AMZM

Nordic Ware 01940 Scandinavian Dollar Pancake Pan Instruction Manual

Model: 01940AMZM

INTRODUCTION

The Nordic Ware 01940 Scandinavian Dollar Pancake Pan is designed for preparing seven 3-inch round pancakes simultaneously. This pan features a durable cast aluminum construction for even heat distribution and a nonstick surface for easy food release.



Image: Top view of the Nordic Ware Scandinavian Dollar Pancake Pan, showcasing its seven circular cavities.

SETUP

1. **Initial Cleaning:** Before the first use, hand wash the pan with warm, soapy water. Rinse thoroughly and dry completely.
2. **Preheating:** Place the pan over medium heat on your stovetop. Allow the pan to preheat for a few minutes.
3. **Greasing:** Before each use, lightly brush the interior of each pan cavity with unsalted vegetable shortening or oil. This ensures optimal nonstick performance.

OPERATING INSTRUCTIONS

Follow these steps to prepare pancakes or other small round items using your Nordic Ware pan:

1. **Prepare Batter:** Use your preferred pancake or blini batter recipe.

2. **Fill Cavities:** Pour approximately 2 tablespoons of batter into each pan cavity. Avoid overfilling.
3. **Cook First Side:** Cook until the center of the pancakes shows bubbles and the edges appear golden brown.
4. **Flipping:** Using a non-metal utensil (such as wooden skewers, chopsticks, a small silicone spatula, or a plastic fork), carefully flip each pancake into an adjacent empty cavity or onto the cooked side.
5. **Cook Second Side:** Continue cooking until a toothpick inserted into the center of a pancake comes out clean, indicating it is fully cooked.



Image: Pancakes cooking in the pan on a gas stovetop, showing the golden-brown edges.



Image: Small blini topped with smoked salmon, cucumber slices, and cream cheese, demonstrating an alternative use for the pan.

Official Product Videos

Your browser does not support the video tag.

Video: An overview of Nordic Ware Pancake Pans, showcasing various designs and their use. This video demonstrates the versatility of the pan series.

Your browser does not support the video tag.

Video: A demonstration of baking with Nordic Ware Pancake Pans, providing visual guidance on the cooking process.

MAINTENANCE AND CARE

- **Cleaning:** Hand washing with warm, soapy water is recommended for this pan. Avoid using abrasive cleaners, metal scouring pads, or harsh chemicals, as these can damage the nonstick coating.
- **Drying:** Dry the pan thoroughly after washing to prevent water spots and maintain its finish.
- **Storage:** Store the pan in a dry location.

TROUBLESHOOTING

- **Pancakes Sticking:** If pancakes are sticking to the pan, ensure that the pan was properly greased with unsalted vegetable shortening or oil before adding batter. Also, confirm that the pan was preheated to medium heat. Insufficient greasing or improper temperature can lead to sticking.

SPECIFICATIONS

Brand	Nordic Ware
Model Name	Nordic Ware 01940 Silver Dollar Pancake Pan
Model Number	01940AMZM
Material	Aluminum
Special Feature	Electric Stovetop Compatible
Color	Silver
Capacity	6.4 ounces
Item Weight	1.2 pounds
Coating Description	Non-stick
Maximum Temperature	350 °F
Compatible Devices	Gas, Electric Stovetop




Image: Technical diagram illustrating the dimensions of the pancake pan (17.3 inches length, 10.5 inches width, 2.3 inches height).

WARRANTY AND SUPPORT

This Nordic Ware product is covered by a **One Year Manufacturer Warranty**. For warranty claims, product support, or additional information, please visit the official Nordic Ware website or contact their customer service department directly.

© 2026 Nordic Ware. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00004RFPM>

More documents and user manuals: <https://manuals.plus/>