

[Manuals.plus](#) /

› [Bandai Namco](#) /

› Tekken Tag Tournament - PlayStation 2 User Manual

Bandai Namco PlayStation 2 Game

Tekken Tag Tournament - PlayStation 2 User Manual

Brand: Bandai Namco | Model: PlayStation 2 Game




Image: Front cover of the Tekken Tag Tournament game for PlayStation 2, featuring key characters like Kazuya, Jin, and Heihachi.

1. INTRODUCTION

Welcome to the world of Tekken Tag Tournament! This manual provides essential information for setting up, playing, and maintaining your game. Tekken Tag Tournament brings together a vast roster of characters from the Tekken series for exciting 2-on-2 tag team battles. Master the unique tag mechanics and unleash powerful combos to defeat your opponents.

2. SETUP

2.1 System Requirements

- PlayStation 2 console (NTSC-U/C compatible)
- One or two PlayStation 2 compatible controllers

- PlayStation 2 Memory Card (8MB or larger) for saving game data
- Television or display with appropriate AV inputs

2.2 Installation

1. Ensure your PlayStation 2 console is powered off.
2. Gently open the disc tray of your PlayStation 2 console.
3. Place the Tekken Tag Tournament game disc onto the disc spindle, label side up. Ensure it is seated correctly.
4. Close the disc tray.
5. Connect your PlayStation 2 controller(s) to the controller ports.
6. Insert a PlayStation 2 Memory Card into a memory card slot.
7. Power on your PlayStation 2 console. The game should load automatically.




Image: An open Tekken Tag Tournament game case, displaying the game disc and the internal memory card holder.

3. OPERATING INSTRUCTIONS

3.1 Basic Controls

Action	Controller Input
Movement	Directional Pad / Left Analog Stick
Left Punch	Square (□)
Right Punch	Triangle (△)
Left Kick	X (×)
Right Kick	Circle (○)
Tag Partner	L1 / R1 (Default)
Guard	Back (away from opponent)

Note: Specific character moves and combos are detailed within the in-game command list.

3.2 Game Modes

- **Arcade Mode:** Fight through a series of opponents to reach the final boss.
- **VS Battle:** Compete against another player or the CPU in a single match.

- **Team Battle:** Select multiple characters for a team-based elimination match.
- **Time Attack:** Race against the clock to defeat opponents as quickly as possible.
- **Survival:** Fight as many opponents as possible with a single health bar.
- **Tekken Bowl:** A unique bowling mini-game featuring Tekken characters.
- **Theater Mode:** View character endings and cinematic sequences unlocked during gameplay.
- **Gallery Mode:** Pause the game at any time to capture screenshots saved to your memory card.

3.3 Tag System

Tekken Tag Tournament introduces a dynamic tag system. You select two characters for each match and can switch between them at any time using the designated tag button. This allows for strategic gameplay, enabling you to extend combos, recover health for your resting partner, or adapt to your opponent's fighting style. A round ends when one of your two characters is defeated.



Image: In-game combat between Jin Kazama and Ling Xiaoyu.



Image: In-game combat between Paul Phoenix and Jun Kazama.



Image: In-game combat between Marshall Law and Anna Williams.



Image: In-game combat between Heihachi Mishima and Baek Doo San.



Image: In-game combat between Jin Kazama and Gun Jack.

4. MAINTENANCE

4.1 Game Disc Care

- Always hold the disc by its edges to avoid fingerprints on the playing surface.
- Store the disc in its original case when not in use to protect it from dust and scratches.
- If the disc becomes dirty, gently wipe it with a soft, lint-free cloth from the center outwards. Do not use abrasive cleaners or solvents.
- Avoid exposing the disc to direct sunlight, extreme temperatures, or high humidity.

4.2 Console and Controller Care

- Keep your PlayStation 2 console and controllers clean and free of dust. Use a soft, dry cloth for cleaning.
- Ensure proper ventilation for your console to prevent overheating.
- Store controllers in a safe place to prevent damage to cables or analog sticks.

5. TROUBLESHOOTING

Problem	Possible Solution
Disc Read Error / Game Not Loading	Clean the game disc with a soft cloth. Ensure the disc is inserted correctly. Check for visible scratches or damage on the disc. Try another game disc to confirm console functionality.
Game Freezes / Crashes	Ensure the console has adequate ventilation. Power off the console, wait a few minutes, then restart. Check the disc for damage.

Problem	Possible Solution
Controller Not Responding	Ensure the controller is securely plugged into the console. Try plugging it into a different port. Test with another controller if available.
No Sound / No Picture	Check all AV cables are securely connected to both the console and the television. Ensure the TV input is set to the correct source. Adjust TV volume.
Save Data Issues	Ensure a PlayStation 2 Memory Card is inserted and has sufficient free space. Check if the memory card is properly formatted.

If you continue to experience issues, please refer to your PlayStation 2 console's instruction manual or contact Bandai Namco support.

6. SPECIFICATIONS

- **Computer Platform:** PlayStation 2
- **Compatible Video Game Console Models:** Sony PlayStation 2
- **Type of Item:** Video Game
- **Rated:** Teen
- **Manufacturer:** Namco
- **Product Dimensions:** 7.5 x 5.3 x 0.6 inches
- **Item Weight:** 5 ounces
- **Date First Available:** September 4, 2000
- **UPC:** 722674021036

7. WARRANTY AND SUPPORT

For information regarding product warranty, technical support, or service, please contact Bandai Namco Entertainment directly through their official website or customer service channels. Please retain your proof of purchase for any warranty claims.

For general inquiries or additional support, visit the official Bandai Namco Entertainment store: [Bandai Namco Entertainment Store](#)