

## Helen of Troy VS759

# Vidal Sassoon VS759 Quiet Traveler 1875W Hair Dryer Instruction Manual

Model: VS759 | Brand: Helen of Troy

## 1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **READ ALL INSTRUCTIONS BEFORE USING.**
- **KEEP AWAY FROM WATER.** Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- The appliance is equipped with an immersion shock safety plug. Do not attempt to defeat this safety feature.

- This appliance is for household use only.

## 2. PRODUCT OVERVIEW

---

The Vidal Sassoon VS759 Quiet Traveler is a compact and powerful 1875W hair dryer designed for efficient and quiet hair drying. Its foldable handle makes it ideal for travel and convenient storage. It features two heat settings to suit various styling needs.



An image of the Vidal Sassoon VS759 Quiet Traveler 1875W hair dryer, featuring a teal body, black handle grip, and a foldable design. The model name and wattage are visible on the barrel.

## 3. SETUP

---

Before first use, please follow these steps:

1. Unpack the hair dryer and all accessories from the packaging.
2. Inspect the appliance for any signs of damage. If damaged, do not use and contact customer support.
3. Ensure your electrical outlet voltage matches the voltage requirements of the hair dryer (typically 120V for North America).
4. Unfold the handle until it locks securely into place.
5. Plug the hair dryer into a standard electrical outlet.

## 4. OPERATING INSTRUCTIONS

---

To use your Vidal Sassoon VS759 Quiet Traveler hair dryer:

1. **Power On/Off:** Locate the slide switch on the handle. Slide it to the 'I' or 'II' position to turn the dryer on. Slide it to '0' to turn it off.
2. **Heat Settings:** The dryer offers 2 heat settings. Select the desired heat level using the slide switch. 'I'

typically indicates a lower heat/speed setting, and 'II' indicates a higher heat/speed setting.

3. **Drying Hair:** Hold the hair dryer at a comfortable distance from your hair. Move the dryer continuously to prevent concentrating heat in one area.
4. **Quiet Operation:** This model is designed for quiet operation, providing a more comfortable drying experience.
5. **Folding for Storage:** After use, unplug the dryer and allow it to cool. The handle can be folded for compact storage by pressing the release button (if present) or simply folding it back towards the barrel.

## 5. MAINTENANCE AND CARE

---

Proper maintenance ensures the longevity and performance of your hair dryer:

- **Cleaning the Air Filter:** Regularly clean the rear air intake filter to prevent lint and hair buildup, which can restrict airflow and cause overheating. Unplug the dryer before cleaning. Gently remove any accumulated debris with a soft brush or cloth.
- **General Cleaning:** Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the hair dryer in a cool, dry place. Do not wrap the power cord tightly around the appliance, as this can damage the cord. Hang it by the hanging loop if available.

## 6. TROUBLESHOOTING

---

If you encounter issues with your hair dryer, refer to the following common solutions:

- **No Power:**
  - Check if the hair dryer is securely plugged into a working electrical outlet.
  - Verify that the outlet itself is functional by testing it with another appliance.
  - Check the immersion shock safety plug for a reset button and press it if necessary.
- **Low Airflow or Overheating:**
  - Unplug the dryer and allow it to cool down.
  - Clean the rear air intake filter to remove any lint or hair blockage.
- **Unusual Noise:**
  - Unplug the dryer and check the air vents for any foreign objects or obstructions.

If the problem persists after trying these steps, please contact customer support.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Number	VS759
Power	1875W
Heat/Speed Settings	2
Power Source	Electric Cord
Product Dimensions (unfolded)	22.86 x 15.24 x 11.43 cm
Product Weight	453.59 g (1 Pound)
Manufacturer	Helen of Troy

## 8. WARRANTY AND SUPPORT

---

For information regarding warranty coverage, terms, and conditions, please refer to the documentation included with your product at the time of purchase. You may also visit the official Helen of Troy website or contact their customer service department for support and inquiries related to your Vidal Sassoon VS759 Quiet Traveler hair dryer.