

[Manuals.plus](#) /

> [Conair](#) /

> Conair Ceramic Hot Rollers User Manual

Conair CHV14XR

Conair Ceramic Hot Rollers User Manual

Model: CHV14XR

INTRODUCTION

The Conair Ceramic 1 1/2-inch and 1 3/4-inch Hot Rollers are designed to provide voluminous curls and waves quickly and easily. This set includes 12 ceramic-flocked rollers and wire pins for secure styling. The ceramic-infused technology ensures even heat transfer for long-lasting results, making it a convenient tool for achieving salon-style curls at home.



Image: Conair Ceramic Hot Rollers set, showcasing the heating unit, rollers, and wire pins.

IMPORTANT SAFEGUARDS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- Always unplug the appliance immediately after using.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Keep the cord away from heated surfaces.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- This appliance is for household use only.

PACKAGE CONTENTS

Your Conair Hot Rollers set includes the following components:

- 1 Hot Roller Heating Unit
- 4 Super Jumbo (1.75 inch) Ceramic Flocked Rollers
- 8 Jumbo (1.5 inch) Ceramic Flocked Rollers
- 12 Wire Pins for securing rollers



Image: Components of the Conair Hot Rollers set, detailing roller sizes, internal structure, and wire clips.

SETUP

Before first use, ensure the unit is placed on a flat, heat-resistant surface. Uncoil the power cord and plug the unit into a standard electrical outlet. The red indicator light will illuminate, signaling that the rollers are heating.

READY SIGNAL

Lights up when rollers begin to heat — in just 85 seconds, your rollers will be ready for use!



Ensure lid is tightly closed so rollers can heat to ultimate temperature.

Image: The hot roller unit showing the red indicator light, which signals heating.

The rollers heat up quickly, typically within 85 seconds. For optimal heating, ensure the lid is tightly closed. During the first use, a faint plastic smell or a smoking effect may occur. This is normal and will dissipate after initial use. It is recommended to operate the unit in a well-ventilated area for the first heating cycle to allow any manufacturing odors to clear.

WHAT TO EXPECT DURING FIRST USE

Initial heat-up may produce a smoking effect with a faint plastic smell. This is a normal part of the heating process that happens only the first time you use the rollers.



Image: Visual guide on what to expect during the first use, including potential smell and smoke.

OPERATING INSTRUCTIONS

Follow these steps to achieve beautiful curls and waves:

1. **Prepare Hair:** Ensure your hair is dry and free of tangles. You may apply a heat protectant spray.
2. **Heat Rollers:** Plug in the hot rollers and allow them to heat up. The small white dot on the top of each roller will turn transparent white when they are warm and ready for use.
3. **Section Hair:** Take a 1-inch section of hair. For best results, start with the top sections of your hair.
4. **Roll Hair:** Place the roller at the end of the hair section and wind the hair smoothly towards the scalp. Ensure the hair is wrapped tightly and evenly around the roller.
5. **Secure Roller:** Use the provided wire pins to secure the roller in place.
6. **Set Time:** Leave the rollers in your hair for 20 minutes or more for bouncy, voluminous curls. For looser waves, leave them in for 10 minutes or less.
7. **Remove Rollers:** Once the rollers are cool to the touch, carefully unroll them one at a time, making sure not to pull your hair.
8. **Style:** Gently comb through your hair or use your fingers to arrange the curls as desired. Set your style with your favorite hairspray for extra hold.



Image: Step-by-step visual instructions on how to roll your hair for waves and volume.




Image: Visual instructions on setting and finishing your hair with hot rollers.



Image: Example of voluminous, curly hair styled with the hot rollers.

MAINTENANCE AND CARE

To ensure the longevity and performance of your Conair Hot Rollers, follow these maintenance guidelines:

- Always unplug the unit and allow it to cool completely before cleaning.
- Wipe the heating unit and rollers with a damp cloth. Do not immerse the unit in water or any other liquid.

- Do not use abrasive cleaners or scouring pads, as these may damage the surface.
- Store the unit in a cool, dry place, out of reach of children.
- Do not wrap the cord around the appliance. Allow the cord to hang loose or lie coiled loosely at the side of the unit.

TROUBLESHOOTING

If you encounter any issues with your Conair Hot Rollers, refer to the following common solutions:

- **Rollers not heating:** Ensure the unit is properly plugged into a functioning electrical outlet. Check if the red indicator light is on. If not, try a different outlet.
- **Red light not turning transparent white:** The red light indicates the unit is heating. The small white dot on each roller turning transparent white indicates individual rollers are warm. If the dot does not change, ensure the lid is closed for optimal heat retention and allow sufficient time (at least 85 seconds, possibly longer for full heat).
- **Unusual smell during first use:** A faint plastic smell is normal during the initial heating cycles. This will dissipate with continued use. Ensure the unit is used in a well-ventilated area for the first few uses.
- **Rollers too hot to handle:** Allow the rollers to cool slightly before handling if they are too hot. The ceramic material retains heat effectively.
- **Curls not holding/Hair falling out of rollers:** Ensure hair sections are not too large for the roller size. Wrap hair tightly and evenly. Make sure the wire pins are securing the rollers firmly. Allow sufficient cooling time for the curls to set before removing rollers.

SPECIFICATIONS

Feature	Detail
Brand	Conair
Model Number	CHV14XR
Material	Ceramic
Number of Items	1 (set)
Roller Sizes	4 x 1.75 inch (Super Jumbo), 8 x 1.5 inch (Jumbo)
Included Accessories	12 Wire Pins
Dimensions	5.75 x 11.5 x 4.75 inches
Weight	2.9 Pounds
UPC	074108166807

WARRANTY AND SUPPORT

Conair products are manufactured to the highest standards and are warranted against defects in materials or workmanship for a specified period from the date of purchase. For detailed warranty information, product registration, or technical support, please refer to the official Conair website or contact their customer service. Keep your purchase receipt as proof of purchase.

