

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Orbit](#) /

› [Xlr8r Audio CD User Manual](#)

Orbit B00005B52T

Xlr8r Audio CD User Manual

Model: B00005B52T | Brand: Orbit

INTRODUCTION

This manual provides essential information for the proper use, care, and maintenance of your Xlr8r Audio CD. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.




Image: The album cover for Xlr8r, depicting a fast-moving train in a subway tunnel, with the artist name "orbit" visible on the right side of the image. The image conveys motion and speed.

SETUP

To begin enjoying your Xlr8r Audio CD, follow these simple steps:

1. **Unpack the CD:** Carefully remove the Audio CD from its packaging. Avoid touching the playing surface.
2. **Prepare your CD Player:** Ensure your CD player is connected to a power source and audio output devices (speakers, headphones).
3. **Insert the CD:** Open the CD tray or slot on your player. Hold the CD by its edges and gently place it onto the spindle or slide it into the slot with the label side facing up.
4. **Close the Tray:** Close the CD tray or allow the player to automatically draw the CD in.

OPERATING INSTRUCTIONS

Once the CD is loaded, you can control playback using your CD player's functions:

- **Play/Pause:** Press the **PLAY/PAUSE** button to start or temporarily stop playback.
- **Stop:** Press the **STOP** button to end playback and reset the CD to the beginning.
- **Skip Tracks:** Use the **SKIP FORWARD (>>)** or **SKIP BACKWARD (/<<)** buttons to navigate between tracks.
- **Fast Forward/Rewind:** Hold down the **FAST FORWARD** or **REWIND** buttons to quickly scan through a track.
- **Volume Control:** Adjust the volume using the volume controls on your CD player or connected audio system.

MAINTENANCE

Proper care will extend the life of your Audio CD and ensure consistent playback quality:

- **Handling:** Always hold the CD by its outer edges or the center hole. Avoid touching the shiny playing surface.
- **Cleaning:** If the CD becomes dirty, gently wipe it with a soft, lint-free cloth (e.g., microfiber) from the center outwards in a straight line. Do not wipe in circular motions. For stubborn smudges, use a specialized CD cleaning solution.
- **Storage:** Store the CD in its original jewel case or a protective sleeve when not in use. Keep it away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Scratches:** Do not bend the CD or place heavy objects on it. Scratches can lead to playback errors.

TROUBLESHOOTING

If you encounter issues with your Xlr8r Audio CD, try the following solutions:

Problem	Possible Cause	Solution
CD skips or stutters during playback.	Dust, fingerprints, or scratches on the playing surface.	Clean the CD with a soft, lint-free cloth. Inspect for deep scratches. Try playing on a different CD player.
CD does not play or is not recognized.	CD inserted incorrectly, dirty CD, or CD player issue.	Ensure the CD is inserted label-side up. Clean the CD. Check if other CDs play in your player.

Problem	Possible Cause	Solution
Poor sound quality.	Dirty CD, faulty audio cables, or speaker issues.	Clean the CD. Check all audio connections. Test with different speakers or headphones.

SPECIFICATIONS

Format: Audio CD

ASIN: B00005B52T

Label: Wicked Disc -- Burnside --

Manufacturer: Wicked Disc -- Burnside --

Product Dimensions: 4.75 x 5 x 0.5 inches; 3.2 ounces

First Available: February 11, 2007

WARRANTY AND SUPPORT

This Audio CD is manufactured to high-quality standards. While physical media can be susceptible to wear and tear, manufacturing defects are rare.


For issues related to manufacturing defects, please contact the retailer or the label, Wicked Disc -- Burnside --, directly. Keep your proof of purchase for any warranty claims.

For general inquiries or further assistance, refer to the contact information provided by the original point of purchase or the record label.

© 2025 Orbit / Wicked Disc -- Burnside --. All rights reserved.

Related Documents - B00005B52T

	<p><u>Orbit Keys FMN User Manual - Bluetooth Key Finder</u></p> <p>User manual for the Orbit Keys FMN, a Bluetooth key finder designed to locate your keys using the Apple Find My app. Features include a loud buzzer, long range, and durable aluminum construction.</p>

 <p>USER MANUAL MODEL: Orbit Card FMN</p>	<p>Orbit Card FMN User Manual: Thin Bluetooth Tracker for Apple Find My</p> <p>User manual for the Orbit Card FMN, a credit card-sized Bluetooth tracker compatible with Apple's Find My app. Learn how to set up, use, and find your lost items with this ultra-thin device. Includes specifications and FCC compliance information.</p>
	<p>Orbit Illuminated Globes: User Manual and Instructions</p> <p>Comprehensive instructions for Orbit illuminated geographical globes (Ø20-40 cm) by Tecnodidattica S.P.A., covering safety, assembly, bulb replacement, and disposal.</p>
 <p>Orbit Irrigation Products General Specification OS-0096 Rev. 1 USER MANUAL HT31BT</p>	<p>Orbit HT31BT B-hyve Bluetooth Hose Faucet Timer User Manual and Specifications</p> <p>User manual and technical specifications for the Orbit HT31BT B-hyve Bluetooth Hose Faucet Timer, detailing its features, electrical requirements, mechanical specifications, and regulatory compliance.</p>
	<p>Orbit B-hyve WiFi Sprinkler Timer User Manual</p> <p>Comprehensive user manual for the Orbit B-hyve WiFi Sprinkler Timer, covering installation, app setup, programming, manual operation, and troubleshooting. Learn how to conserve water and manage your irrigation efficiently.</p>