

Manuals.plus /

> [ABBA](#) /

> ABBA Voulez-Vous Audio CD Instruction Manual

## ABBA Voulez-Vous

# ABBA Voulez-Vous Audio CD Instruction Manual

Model: Voulez-Vous | Brand: ABBA

## 1. INTRODUCTION

This manual provides essential information for the proper handling, playback, and care of your ABBA Voulez-Vous Audio CD. Released in 1979, 'Voulez-Vous' is a classic album by the Swedish pop group ABBA, featuring their signature Eurodisco sound. Following these instructions will help ensure optimal enjoyment and longevity of your audio CD.

## 2. PRODUCT OVERVIEW



**Image 1:** Front cover of the ABBA Voulez-Vous Audio CD. This image displays the album title 'ABBA Voulez-Vous' prominently, along with a stylized blue pyramid design and a photograph of the four band members.



**Image 2:** Back cover of the ABBA Voulez-Vous Audio CD. This image shows the full tracklist, copyright information, manufacturer details, and the Universal Product Code (UPC) 0731454996327.

### 3. SETUP

- Unboxing:** Carefully remove the Audio CD from its packaging. Ensure the jewel case is intact and the disc is not loose.
- Inspect Disc:** Before first use, visually inspect the playing surface (the shiny, non-label side) for any visible scratches, smudges, or defects.
- Player Compatibility:** Ensure you have a compatible Audio CD player. This can be a dedicated CD player, a DVD player, a Blu-ray player, or a computer with a CD-ROM drive.

### 4. OPERATING INSTRUCTIONS

- Open Disc Tray:** Press the 'Open/Eject' button on your CD player to open the disc tray.
- Load Disc:** Hold the Audio CD by its edges or by placing a finger through the center hole. Place the disc label-side up onto the spindle in the disc tray. Ensure it is seated correctly.
- Close Disc Tray:** Press the 'Open/Eject' button again or gently push the tray to close it.

4. **Playback:** The player should automatically detect the disc. Press the 'Play' button to begin playback. Use the 'Next Track' and 'Previous Track' buttons to navigate between songs.
5. **Eject Disc:** When finished, press the 'Open/Eject' button to remove the disc. Always return the disc to its jewel case for storage.

## 5. MAINTENANCE AND CARE

- **Handling:** Always handle the CD by its edges or center hole. Avoid touching the playing surface to prevent fingerprints and smudges.
- **Cleaning:** If the disc becomes dirty, gently wipe the playing surface with a soft, lint-free cloth (e.g., microfiber). Wipe in a straight line from the center hub outwards to the edge. Do not wipe in a circular motion. Avoid using abrasive materials or chemical cleaners.
- **Storage:** Store the Audio CD in its original jewel case when not in use. Keep the case closed to protect the disc from dust and scratches.
- **Environment:** Store the CD in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity. Exposure to heat can warp the disc.
- **Avoid Bending:** Do not bend or flex the disc, as this can cause irreparable damage.

## 6. TROUBLESHOOTING

- **Disc Not Playing:**
  - Ensure the disc is clean and free of visible scratches.
  - Verify the disc is loaded correctly, label-side up.
  - Check if your CD player is functioning correctly with other discs.
- **Skipping or Stuttering Playback:**
  - Clean the disc thoroughly as described in the Maintenance section.
  - Inspect the disc for deep scratches or cracks. Severely damaged discs may not play correctly.
  - Ensure the CD player is on a stable surface to prevent vibrations.
- **No Sound:**
  - Check the volume level on your CD player and connected audio system.
  - Verify all audio cables are securely connected between the CD player and your amplifier/speakers.
  - Ensure the correct input source is selected on your audio system.

## 7. SPECIFICATIONS

|             |               |
|-------------|---------------|
| Format      | Audio CD      |
| Artist      | ABBA          |
| Album Title | Voulez-Vous   |
| ASIN        | B00005CDNI    |
| UPC         | 0731454996327 |

|                      |                                        |
|----------------------|----------------------------------------|
| Number of Discs      | 1                                      |
| Language             | English                                |
| Product Dimensions   | 4.88 x 5.51 x 0.47 inches; 2.68 ounces |
| Manufacturer         | Polydor / Umgd                         |
| Label                | Polydor / Umgd                         |
| Date First Available | February 9, 2007                       |

Tracklist:

- 1. As Good As New
- 2. Voulez-Vous
- 3. I Have A Dream
- 4. Angeleyes
- 5. The King Has Lost His Crown
- 6. Does Your Mother Know
- 7. If It Wasn't For The Night
- 8. Chiquitita
- 9. Lovers (Live A Little Longer)
- 10. Kisses Of Fire
- 11. Summer Night City (Bonus Track)
- 12. Lovelight (Bonus Track)
- 13. Gimme! Gimme! Gimme! (A Man After Midnight) (Bonus Track)

8. WARRANTY AND SUPPORT

For physical media such as Audio CDs, warranty coverage typically pertains to manufacturing defects at the time of purchase. Please refer to the retailer's return policy for information regarding defective or damaged products received. Content-related support for musical albums is generally not applicable. For further inquiries regarding your purchase, please contact your point of sale.

© 2024 ABBA. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**<https://manuals.plus/asin/B00005CDNI>**

More documents and user manuals: **<https://manuals.plus/>**