

## Rabbit W6005

# Rabbit Original Lever Corkscrew Wine Opener Instruction Manual

Model: W6005

---

## 1. PRODUCT OVERVIEW

The Rabbit Original Lever Corkscrew is designed for effortless wine bottle opening. This durable tool features a robust lever mechanism, an integrated foil cutter, and an ergonomic grip for comfortable and controlled use. It is suitable for both natural and synthetic corks and includes a spare spiral for extended product life.



Image 1: The Rabbit Original Lever Corkscrew Wine Opener, including the main unit, a spare spiral, and the foil cutter.

## 2. SETUP

Before using your Rabbit Original Lever Corkscrew, ensure all components are present and clean. The unit comes pre-assembled with one spiral installed. A spare spiral is provided for future replacement.

### 2.1 Using the Foil Cutter

1. Place the 4-blade foil cutter over the top of the wine bottle, ensuring it grips the foil securely.
2. Squeeze the foil cutter firmly and rotate it around the bottle neck to cleanly cut and remove the foil.
3. Discard the removed foil.

## 3. OPERATING INSTRUCTIONS

Follow these steps for efficient and effortless cork removal:

1. **Position the Corkscrew:** With the lever in the upward position, place the corkscrew firmly over the neck of the wine bottle. Ensure the rubberized grips on the corkscrew securely hold the bottle.

## Works on all bottle sizes and cork types



Image 2: The corkscrew is placed over the wine bottle, ready for operation.

2. **Insert the Spiral:** Firmly grip the corkscrew handles around the bottle neck. Push the lever down smoothly. The spiral will automatically rotate and insert itself into the cork. Continue pushing until the lever is fully down.
3. **Extract the Cork:** Once the lever is fully down, pull the lever back up with a steady motion. The cork will be effortlessly extracted from the bottle.
4. **Release the Cork:** To remove the cork from the corkscrew, grip the handles around the extracted cork. Push the lever down and then pull it back up. The cork will be automatically ejected from the spiral.

## Automatically releases cork



Image 3: The cork is automatically released from the corkscrew after extraction.

### 3.1 Official Product Video

Video 1: Demonstration of the Original Rabbit Corkscrew in action, showing the full process of opening a wine bottle and ejecting the cork. Provided by Lifetime Brands, Inc.

## 4. MAINTENANCE

### 4.1 Cleaning

The Rabbit Original Lever Corkscrew should be hand washed only. Use warm, soapy water and a soft cloth. Rinse thoroughly and dry immediately to prevent water spots or corrosion. Do not place in a dishwasher.

### 4.2 Spiral Replacement

The corkscrew spiral is designed for durability but may require replacement after approximately 1,000 cork pulls or if it becomes damaged. A spare non-stick coated spiral is included with your purchase.

1. To replace, locate the small pin holding the spiral in place.
2. Carefully remove the pin and slide out the old spiral.
3. Insert the new spiral and re-secure it with the pin.

## 5. TROUBLESHOOTING

## 5.1 Cork Breakage

If the cork breaks during extraction, ensure the corkscrew is positioned centrally and the lever is pushed down completely to fully engage the spiral. For very old or fragile corks, extra care and a slower, steady motion may be required.

## 5.2 Difficulty Operating the Lever

Ensure the corkscrew is clean and free of debris. If the lever mechanism feels stiff, check for any obstructions. Applying a small amount of food-grade lubricant to the moving parts may help, but consult the manufacturer if issues persist.

## 6. SPECIFICATIONS

Feature	Detail
Model Number	W6005
Brand	Rabbit
Material	Metal (with polycarbonate and nylon components)
Color	Silver
Finish Type	Non-stick Coated (spiral)
Item Weight	0.8 Pounds (approximately 12.8 ounces)
Product Dimensions	8.46"L x 7.5"W (or 8.9 x 7.8 x 2.7 inches)

## Pulls a cork in 3 seconds




Image 4: Product dimensions of the Rabbit Original Lever Corkscrew.

### 7. WARRANTY & SUPPORT

The Rabbit Original Lever Corkscrew is backed by a **10-year warranty** from the manufacturer, Lifetime Brands Inc. This warranty covers defects in materials and workmanship under normal use. For warranty claims or product support, please refer to the contact information provided with your product packaging or visit the official Rabbit brand website.