

[manuals.plus](#) /

› [Oster](#) /

› [Oster 4093-008 5-Cup Glass Jar 2-Speed Beehive Blender Instruction Manual](#)

Oster 4093-008

Oster 4093-008 5-Cup Glass Jar 2-Speed Beehive Blender Instruction Manual

Model: 4093-008

Brand: Oster

INTRODUCTION

The Oster Beehive Blender, model 4093-008, is designed for efficient blending with its 600-watt motor and two-speed toggle control. It features a durable 5-cup glass jar, thermal shock tested for versatility, and a stainless steel ice crusher blade. The blender incorporates an All Metal Drive system for enhanced durability and longevity. This manual provides essential information for safe and effective use of your blender.



LEGENDARY PERFORMANCE.
DESIGNED TO LAST.

Beehive Blender

Built to Withstand
Heavy Use

**DURABLE
DIE-CAST
CONSTRUCTION**



5-Cup Glass Jar
dishwasher safe
Boroclass® Glass



600 Watts
of ice crushing power



**Stainless Steel
Blade**
chops and grinds



Classic Design
for timeless style

www.oster.com

4093



Image: Oster Beehive Blender highlighting its features and capacity.

SETUP

Before using your Oster Beehive Blender for the first time, please follow these setup instructions:

1. Unpack all components: blender base, glass jar, blade assembly, and lid.
2. Before initial use, wash the glass jar, lid, and blade assembly in warm, soapy water. Rinse thoroughly and dry completely.

3. Place the blade assembly onto the bottom of the glass jar, ensuring it is securely seated.
4. Place the rubber sealing gasket over the blade assembly.
5. Screw the base collar onto the bottom of the jar, tightening firmly to prevent leaks.
6. Place the assembled jar onto the blender base, aligning the tabs on the jar with the slots on the base. Ensure it is seated correctly and stable.
7. Place the lid securely on top of the glass jar.



Image: The 5-cup glass jar, ready for ingredients.

OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation of your blender:

1. Ensure the blender is unplugged before adding ingredients.
2. Place ingredients into the assembled glass jar. Do not overfill; ensure the liquid level is below the maximum fill line.
3. Securely place the lid on the jar. The filler cap can be removed to add ingredients during blending.
4. Plug the blender into a standard North American electrical outlet.
5. Select the desired speed using the toggle switch: 'LOW' for softer ingredients or 'HIGH' for harder ingredients and ice crushing. For short bursts of power, use the 'PULSE' function by quickly toggling the switch to 'HIGH' and releasing.
6. Allow the blender to run until the desired consistency is achieved. Do not operate continuously for more than 3 minutes.
7. To stop blending, toggle the switch to 'OFF'.
8. Unplug the blender from the outlet before removing the jar or pouring contents.



Image: The blender base featuring the classic toggle switch for speed control.

Demonstration Video

Your browser does not support the video tag.

Video: An official demonstration of the Oster 4093-008 blender in use, showcasing its blending capabilities.



Image: Example of a blended beverage, demonstrating the blender's output.

MAINTENANCE AND CLEANING

Proper maintenance ensures the longevity and performance of your blender:

1. Always unplug the blender from the electrical outlet before cleaning.
2. Disassemble the jar by unscrewing the base collar and carefully removing the blade assembly and rubber sealing gasket.
3. The glass jar, lid, and blade assembly are dishwasher safe for convenient cleaning. Alternatively, wash them in

warm, soapy water, rinse thoroughly, and dry completely.

4. Exercise extreme caution when handling the blade assembly as the blades are sharp.
5. Wipe the blender base with a damp cloth. Do not immerse the blender base in water or any other liquid.
6. Ensure all parts are completely dry before reassembling and storing the blender.

TROUBLESHOOTING

If you encounter any issues with your blender, refer to the following common problems and solutions:

- **Blender does not turn on:**

Ensure the power cord is securely plugged into a working electrical outlet. Check if the outlet is functional by plugging in another appliance. Verify the blender jar is correctly seated on the base.

- **Blender leaks during operation:**

Confirm the blade assembly and sealing gasket are correctly installed and the base collar is tightly screwed onto the jar. Ensure the lid is securely placed on the jar. Do not overfill the jar beyond the maximum fill line.

- **Ingredients are not blending smoothly:**

Add more liquid if the mixture is too thick. Use the 'PULSE' function to break down larger pieces before continuous blending. Ensure the blade assembly is clean and free from obstructions.

SPECIFICATIONS

Brand	Oster
Model Number	4093-008
Capacity	5 Cups (Glass Jar)
Product Dimensions	15.75"D x 8.25"W x 15.75"H
Item Weight	7.9 pounds
Power Source	Corded Electric
Number of Speeds	2 (with Pulse function)
Blade Material	Stainless Steel
Container Material	Glass
Control Type	Manual Toggle Switch
Special Features	Thermal Shock Tested Glass Jar, All Metal Drive
Electrical Standards	Built to North American Electrical Standards

Key Features

- **All Metal Drive:** This blender features an All Metal Drive system, where the two pieces that connect are metal instead of plastic, ensuring greater durability and a longer-lasting performance.
- **Durable Die-Cast Construction:** The robust construction is designed to withstand heavy use, providing reliable operation over time.



Image: Illustration of the Oster All Metal Drive system, emphasizing durability.

DURABLE DIE-CAST CONSTRUCTION

Image: Graphic highlighting the blender's durable die-cast construction.

WARRANTY

The Oster 4093-008 Beehive Blender is backed by a **10-Year DURALAST All-Metal Drive Limited Warranty**, ensuring lasting durability and peace of mind. For complete details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product packaging or visit the official Oster website for the most current information.

SUPPORT

For product assistance, replacement parts, or any further inquiries regarding your Oster 4093-008 Beehive Blender, please visit the official Oster website or contact their customer service department. When contacting support, please have your purchase receipt and the model number (4093-008) readily available for faster and more efficient service.

Oster Official Website: www.oster.com