

Hama 00048402

Hama CD Rack Model 00048402 Instruction Manual

For the Hama 20-Disk Space-Saving CD Storage System

1. PRODUCT OVERVIEW

The Hama CD Rack Model 00048402 is designed to provide an organized and space-saving storage solution for up to 20 compact discs (CDs) in their cases. Constructed from durable plastic, this rack helps protect your CDs from dirt and scratches. Its modular design allows for vertical or horizontal expansion by connecting multiple units.

- Stores up to 20 CDs in their cases.
- Features plastic compartments for easy CD insertion and removal.
- Designed to be fully stackable and expandable, both vertically and horizontally.
- Space-saving design suitable for various rooms.

2. SAFETY INFORMATION

Please read and understand the following safety guidelines before assembly and use:

- Keep all packaging materials away from children to prevent choking hazards.
- Handle plastic components with care during assembly to avoid breakage.
- Do not overload the rack beyond its intended capacity of 20 CDs.
- Ensure the rack is placed on a stable, level surface to prevent tipping.
- If mounting to a wall, use appropriate hardware for your wall type and ensure secure installation.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Hama 20-Disk CD Rack (unassembled components)
- *Note: CDs are not included.*

4. SETUP AND ASSEMBLY

The Hama CD Rack requires assembly. Follow these steps carefully:

1. **Identify Components:** Lay out all plastic pieces. You should have a top panel, a bottom panel, two side panels, and the internal CD dividers. The top and bottom panels may be marked "TOP" and "BOTTOM" respectively.
2. **Attach Side Panels to Bottom:** Carefully align the tabs on one side panel with the slots on the bottom panel. Gently push them together until they click into place. Repeat for the second side panel. Ensure the side panels are oriented correctly, with any connection points for expansion facing outwards.
3. **Insert CD Dividers:** Slide the internal CD divider sections into the grooves on the bottom panel. These should fit snugly to create the individual CD slots.
4. **Attach Top Panel:** Align the tabs on the top panel with the corresponding slots on the side panels and the top of the CD dividers. Press firmly until all connections are secure. Ensure the "TOP" marking (if present) is facing upwards.
5. **Verify Stability:** Once assembled, gently test the rack for stability. All connections should be firm.



Figure 1: A single Hama CD Rack unit, fully assembled and ready for use.

4.1. Expanding Your CD Storage

The Hama CD Rack is designed for modular expansion. You can connect multiple units horizontally or stack them vertically.

1. **Horizontal Connection:** To connect units horizontally, align the connection points on the side of one assembled rack with the corresponding points on another rack. Gently push them together until they interlock.
2. **Vertical Stacking:** To stack units vertically, place one assembled rack directly on top of another. Ensure the bottom unit is stable and the top unit is securely seated. Some models may have small pegs or indentations for secure stacking.



Figure 2: Example of multiple Hama CD Racks connected and stacked for expanded storage.

5. OPERATING INSTRUCTIONS

Using your Hama CD Rack is straightforward:

- **Inserting CDs:** Gently slide a cased CD into an empty slot. The plastic dividers are designed to hold the CD cases securely.
- **Removing CDs:** Grasp the desired CD case and pull it gently upwards and outwards from its slot.
- **Placement:** Position the rack on a flat, stable surface such as a desk, shelf, or cabinet. The rack can also be mounted to a wall using appropriate hardware (not included) through the designated holes on the back/sides, if present.

6. MAINTENANCE

To keep your Hama CD Rack in optimal condition:

- **Cleaning:** Wipe the rack periodically with a soft, damp cloth. Avoid abrasive cleaners or solvents, as these may damage the plastic finish.
- **Dusting:** Use a dry cloth or duster to remove dust from the rack and CD cases.
- **Inspection:** Periodically check for any loose connections or damage, especially if the rack is frequently moved or expanded.

7. TROUBLESHOOTING

If you encounter issues with your Hama CD Rack, refer to the following:

- **Difficulty Assembling:**
Ensure all components are correctly oriented. Some connections may require firm, even pressure to snap into place. Check for any markings like "TOP" or "BOTTOM" on the panels. Avoid excessive force to prevent breaking plastic tabs.
- **Rack is Unstable:**
Verify that all panels are fully engaged and clicked into their respective slots. Ensure the rack is placed on a flat, level surface. If multiple units are stacked, ensure they are properly aligned and seated.
- **CDs Do Not Fit:**
The rack is designed for standard CD jewel cases. If your CDs are in non-standard or oversized cases, they may not fit. Ensure CDs are inserted straight into the slots.

8. SPECIFICATIONS

Model Number:	00048402
Brand:	Hama
Material:	Plastic
Color:	Grey
Capacity:	20 CDs
Product Dimensions (D x W x H):	4.92" x 6.18" x 11.38" (12.5 cm x 15.7 cm x 28.9 cm)
Special Features:	Stackable, Expandable
Mounting Type:	Countertop (can be wall-mounted with appropriate hardware)
Assembly Required:	Yes (User assembly)
Item Weight:	15.2 ounces (430 Grams)

9. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Hama CD Rack, please contact Hama customer service directly. Refer to the official Hama website or product packaging for the most current contact details.

Hama GmbH & Co KG

www.hama.com