

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Monster](#) /

› [Monster ScreenClean Display Cleaner Kit - Model TV CLNKIT Instruction Manual](#)

## Monster TV CLNKIT

# Monster ScreenClean Display Cleaner Kit (Model TV CLNKIT)

Instruction Manual

## 1. INTRODUCTION

The Monster ScreenClean Display Cleaner Kit is designed to safely and effectively clean a variety of electronic screens, including TVs, computer monitors, laptops, tablets, smartphones, and camera lenses. This alcohol-free and ammonia-free formula removes dust, dirt, and fingerprints, enhancing display brightness and clarity without leaving streaks or residue. The kit includes a specialized cleaning solution and a high-tech microfiber cloth.

## 2. SAFETY INFORMATION

- **Caution:** Keep away from children.
- To prevent potential damage, ensure ScreenClean is compatible with your specific product/display before use.
- If your product requires only soap and water for cleaning, do not use ScreenClean.
- Do not spray directly onto the screen. Always spray onto the microfiber cloth first.
- Avoid pressing too hard on the screen during cleaning, especially on thin LED displays, to prevent damage.

## 3. WHAT'S IN THE BOX

- 1x Monster ScreenClean Liquid Gel Formula (6.7 oz / 200 ml)
- 1x High-Tech Reusable MicroFiber Cloth



Image 1: Contents of the Monster ScreenClean Kit, showing the spray bottle and microfiber cloth.

## 4. SETUP AND PREPARATION

1. Ensure the electronic device is turned off and cooled down before cleaning.
2. Gather the Monster ScreenClean spray bottle and the included microfiber cloth.
3. Inspect the screen for any loose dust or debris. If present, gently wipe it away with a dry part of the microfiber cloth or use a soft brush to avoid scratching.

## 5. OPERATING INSTRUCTIONS

Follow these steps for optimal cleaning results:

1. **Spray the Cloth:** Lightly spray the Monster ScreenClean solution onto a section of the microfiber cloth. Do not spray directly onto the screen.
2. **Wipe the Screen:** Gently wipe the screen surface with the damp section of the microfiber cloth. Use light, even pressure. For stubborn smudges or fingerprints, you may need to apply slightly more solution to the cloth and repeat the wiping motion.
3. **Polish Dry:** Immediately use a dry, clean section of the microfiber cloth to gently polish the screen until it is dry and

streak-free.

4. **Repeat if Necessary:** For very dirty screens, you may need to repeat the process. Ensure the cloth is clean and slightly damp with solution for each pass.

Your browser does not support the video tag.

Video 1: Product Overview demonstrating the use of a screen cleaner on a display. This video illustrates the general application process for screen cleaning solutions.

## 6. MAINTENANCE

To maintain the effectiveness of your microfiber cloth:

- Wash the microfiber cloth alone in a washing machine with cold water and laundry detergent.
- Do NOT wash the cloth with other items to prevent lint transfer.
- Air dry the cloth. Do NOT put the cloth in a dryer, as high heat can damage the microfiber material.

## 7. TROUBLESHOOTING

### Streaks or Residue After Cleaning

- **Too Much Solution:** If streaks appear, you might be using too much cleaning solution. Use a lighter spray on the cloth.
- **Dirty Cloth:** Ensure the microfiber cloth is clean. A dirty cloth can redistribute grime and leave streaks. Wash the cloth as per maintenance instructions.
- **Insufficient Drying:** Make sure to immediately follow up with a dry section of the cloth to polish the screen completely dry.
- **Incorrect Wiping Technique:** Try different wiping patterns (e.g., circular motions, straight lines) to find what works best for your screen type.

## 8. SPECIFICATIONS

Product Dimensions	10.5 x 6.75 x 3 inches
Item Weight	8.4 ounces
Brand	Monster
Model Number	TV CLNKIT
Formula Type	Alcohol-Free, Ammonia-Free Liquid Gel
Included Cloth	Microfiber
UPC	050644394836, 803983103474, 050644304606

## 9. WARRANTY AND SUPPORT

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

You can visit the official Monster store for more information:[Monster Store](#)

