

[Manuals.plus](#) /

› [Presto](#) /

› Presto 07211 Liddle Griddle Electric Griddle Instruction Manual

Presto 07211

Presto 07211 Liddle Griddle Electric Griddle Instruction Manual

Your guide to operating and maintaining your compact electric griddle.

INTRODUCTION

Thank you for choosing the Presto 07211 Liddle Griddle. This compact electric griddle is designed for convenience and efficiency, perfect for preparing meals for one or two servings. Its durable nonstick surface and automatic temperature control ensure consistent cooking results and easy cleanup.

IMPORTANT SAFEGUARDS

READ ALL INSTRUCTIONS BEFORE USE.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the Control Master heat control or cord in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "OFF", then remove plug from wall outlet.
- Do not use appliance for other than intended household use.

PRODUCT OVERVIEW

The Presto Liddle Griddle is a versatile electric griddle designed for small-batch cooking. It features a compact design and a nonstick cooking surface for easy use and cleaning.

Key Features:

- Compact size for cooking one or two servings.
- 8 1/2- x 10 1/2-inch cooking surface.
- PFAS-free ceramic nonstick cooking surface.
- Control Master heat control maintains desired cooking temperature automatically.
- Built-in grease tray collects drippings.
- Fully immersible with the heat control removed for thorough cleaning.
- Heavy cast aluminum griddle base is virtually warp-proof.



Figure 1: Front view of the Presto Liddle Griddle with its detachable Control Master heat control.

SETUP

1. **Unpack Components:** Carefully remove the griddle, Control Master heat control, and any packaging materials.



Figure 2: The griddle and its separate temperature control unit.

2. **Initial Cleaning:** Before first use, wash the griddle surface with warm, soapy water. Rinse thoroughly and dry completely. Do NOT immerse the Control Master heat control in water.
3. **Attach Heat Control:** Insert the Control Master heat control into the receptacle on the side of the griddle. Ensure it is firmly seated.



Figure 3: The Control Master heat control is inserted into the griddle's side receptacle.

4. **Positioning:** Place the griddle on a stable, heat-resistant surface, away from walls or cabinets that could be damaged by heat or steam.

OPERATING INSTRUCTIONS

1. **Preheating:** Plug the Control Master heat control into a 120-volt AC wall outlet. Turn the temperature dial to your desired setting (ranging from Warm to 400°F). The indicator light will illuminate, signaling that the griddle is heating.
2. **Cooking:** Once the indicator light turns off, the griddle has reached the set temperature. You may lightly grease the nonstick surface if desired, though it is often not necessary. Place food directly onto the griddle surface.



Figure 4: Cooking pancakes and bacon on the griddle.



Figure 5: The griddle is suitable for cooking various items like burgers and bacon.

3. **Temperature Maintenance:** The Control Master heat control will cycle on and off during cooking to maintain the selected temperature. The indicator light will turn on when the heating element is active and off when the temperature is stable.
4. **Grease Management:** The built-in grease tray along one end of the griddle collects drippings from fattier foods, promoting healthier cooking and easier cleanup.
5. **Finishing:** When cooking is complete, turn the temperature dial to "OFF" and unplug the unit from the wall outlet. Allow the griddle to cool completely before cleaning.

CLEANING AND MAINTENANCE

1. **Cool Down:** Always allow the griddle to cool completely before attempting to clean it.
2. **Remove Heat Control:** Detach the Control Master heat control from the griddle. This component is NOT submersible and should only be wiped clean with a damp cloth.
3. **Submersible Cleaning:** The griddle unit itself is fully submersible. Wash it in warm, soapy water. For stubborn food residue, a non-abrasive cleaning pad can be used.

- 4. **Rinse and Dry:** Rinse the griddle thoroughly and dry completely before storing.
- 5. **Storage:** Store the griddle and heat control in a dry place. The heat-resistant leg-handle units can be unscrewed for even more compact storage if needed.

TROUBLESHOOTING

Griddle not heating:

Ensure the Control Master heat control is fully inserted into the griddle receptacle and the power cord is securely plugged into a working 120-volt outlet. Check if the temperature dial is set to an active heating temperature (not "OFF" or "WARM" if higher heat is desired).

Food sticking to the surface:

Although the griddle has a nonstick surface, a light application of cooking spray or oil before preheating can further prevent sticking, especially for certain foods. Ensure the griddle is properly preheated before adding food.

Uneven heating:

The heavy cast aluminum base is designed for even heat distribution. If uneven heating is suspected, ensure the griddle is placed on a flat, stable surface and that the heat control is functioning correctly (indicator light cycling on and off). Allow sufficient preheating time.

SPECIFICATIONS

Feature	Detail
Model Number	07211
Brand	Presto
Cooking Surface Dimensions	8.5 x 10.5 inches
Overall Product Dimensions	10"D x 15.5"W x 2.75"H
Material	Cast Aluminum
Coating	PFAS-free Ceramic Nonstick
Color	Black
Wattage	1046 watts
Voltage	120 Volts
Item Weight	3.3 Pounds
Special Features	Built-in grease tray, Control Master heat control
Included Components	Griddle, Heat control, Legs, Drip tray

WARRANTY AND SUPPORT

The Presto 07211 Liddle Griddle comes with a **1-year Limited Warranty** against defects in material and workmanship. For warranty claims or technical support, please refer to the contact information provided in your product packaging or visit the official Presto website.

Keep your purchase receipt as proof of purchase for warranty purposes.

