

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Conair](#) /
- › [Conair Compact Hair Dryer 127NPR User Manual](#)

Conair 127NPR

Conair Compact Hair Dryer User Manual

Model: 127NPR | Brand: Conair

1. INTRODUCTION

Thank you for choosing the Conair Compact Hair Dryer, Model 127NPR. This 1875-watt travel blow dryer is designed for efficient and convenient hair drying, featuring a folding handle, dual voltage capability, and multiple heat/speed settings. This manual provides essential information for safe and effective use of your appliance.

What's in the box



Compact Folding Handle Hair Dryer

Figure 1: Conair Compact Hair Dryer as packaged.

2. IMPORTANT SAFETY INFORMATION

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep out of reach of children.
- **DANGER:** Do not use near water.
- **WARNING:** Avoid flammable materials.
- Always unplug the appliance immediately after use.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- If an appliance falls into water, unplug it immediately. Do not reach into the water.

3. PRODUCT FEATURES

The Conair Compact Hair Dryer is equipped with features designed for convenience and performance:

- **1875 Watts:** Provides powerful drying performance.
- **Folding Handle:** Allows for compact storage and easy portability.
- **Dual Voltage:** Compatible with 125V and 250V for worldwide travel (travel adapter not included).
- **2 Heat/Speed Settings:** Offers flexibility for various hair types and styling needs.
- **Cool Shot Button:** Helps to set styles in place.
- **Removable Rear Filter:** For easy cleaning and maintenance.



Figure 2: Key features of the Conair Compact Hair Dryer.

4. SETUP

1. **Unfold the Handle:** Gently pull the handle away from the dryer body until it clicks securely into the extended position.

2. **Check Voltage Setting:** Locate the dual voltage switch on the handle. Ensure it is set to the correct voltage for your region (125V for North America, 250V for many international locations). Use a coin or screwdriver to adjust if necessary.
3. **Plug In:** Insert the appliance plug into a suitable electrical outlet. If traveling internationally, use an appropriate travel adapter (not included).

Your browser does not support the video tag.

Video 1: Demonstration of the Conair Compact Hair Dryer's dual voltage feature and folding handle, useful for international travel.

5. OPERATING INSTRUCTIONS

1. **Power On/Select Setting:** Slide the switch on the handle to select your desired heat and speed setting:
 - **LOW:** For gentle drying and styling.
 - **HIGH:** For fast drying and powerful styling.
2. **Cool Shot:** Press and hold the blue 'COOL' button to deliver a burst of cool air. This helps to lock in your style and add shine. Release the button to return to the selected heat setting.
3. **Drying Hair:** Hold the dryer approximately 6-8 inches from your hair. Move the dryer continuously to prevent overheating any one section of hair.
4. **Power Off:** After use, slide the switch to the 'OFF' position and unplug the appliance from the electrical outlet.

Your browser does not support the video tag.

Video 2: A detailed demonstration of the Conair 1875 watt travel hair dryer's controls, including low, high, and cool shot settings.

6. MAINTENANCE

To maintain optimal performance and extend the life of your hair dryer, regular cleaning is recommended:

- **Cleaning the Air Filter:** Ensure the dryer is unplugged. The rear filter cover can be removed by twisting or gently prying it off. Clean any accumulated lint or hair from the filter screen using a soft brush or cloth. Replace the filter cover securely.
- **Storage:** When not in use, the dryer should be disconnected from the power outlet, allowed to cool, and stored in a safe, dry location out of reach of children. The folding handle allows for compact storage.

Your browser does not support the video tag.

Video 3: This video demonstrates how to remove and clean the rear filter of the Conair Compact Hair Dryer, ensuring proper airflow and longevity.

7. TROUBLESHOOTING

If your hair dryer is not operating as expected, refer to the following common issues and solutions:

- **Dryer not turning on:**
 - Ensure the dryer is securely plugged into a working electrical outlet.
 - Check the voltage switch to ensure it is set correctly for your region.
 - Verify that the circuit breaker has not tripped.
- **Reduced airflow or overheating:**

- The rear air filter may be clogged. Refer to the Maintenance section for cleaning instructions.
 - The dryer may have an automatic shut-off feature to prevent overheating. Unplug the dryer and allow it to cool down for a few minutes before attempting to use it again.
- **Unusual noise:**
 - Check the rear air filter for any obstructions or loose debris.

If problems persist, discontinue use and contact customer support.

8. SPECIFICATIONS

Feature	Detail
Model Number	127NPR
Brand	Conair
Wattage	1875 watts
Power Source	Corded Electric
Voltage	Dual Voltage (125V/250V)
Number of Speeds	2
Number of Heat Settings	2
Special Features	Ergonomic Handle, Portable, Compact, Lightweight, Cool Shot Button, Dual Voltage, Foldable
Hair Type	All
Material Type	Plastic
Item Weight	1 Pound
Product Dimensions	5.5 x 3 x 10 inches

9. WARRANTY AND SUPPORT

This Conair appliance is covered by a **Limited One Year Warranty** from the date of purchase. If you experience any issues with your product, please refer to the troubleshooting section or contact Conair customer support for assistance.

For warranty claims or further support, please visit the official Conair website or contact their customer service department. Keep your purchase receipt as proof of purchase for warranty validation.