Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi A935

De'Longhi A935 Continuous Juice Extractor Attachment

Instruction Manual

Introduction

Thank you for choosing the De'Longhi A935 Continuous Juice Extractor Attachment. This accessory is designed to work seamlessly with your De'Longhi DSM800 or DSM700 stand mixer, allowing you to extract fresh juice from non-citrus fruits and vegetables. Please read this manual carefully before use to ensure proper operation and maintenance.

Important Safety Instructions

- Always ensure the stand mixer is unplugged before attaching, detaching, or cleaning the juicer attachment.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Use the food pusher provided.
- Do not operate the juicer attachment if any part is damaged or improperly assembled.
- This attachment is designed for non-citrus fruits and vegetables. Remove pits from fruits like peaches and plums, and thick rinds from pineapple and melons before juicing.
- Ensure all parts are securely locked into place before starting the stand mixer.
- Do not immerse the main juicer body (the part that connects to the mixer) in water. Clean with a damp cloth.
- Supervise children to ensure they do not play with the appliance.

Package Contents

Before assembly, please verify that all components are present and undamaged.

- Juicer attachment main body with stainless steel filter
- Clear juice collection spout and pulp ejection chute assembly
- Food pusher
- Pulp collection frame/stand



Image: All components of the De'Longhi A935 Continuous Juice Extractor Attachment. This includes the main juicer body with its stainless steel filter, the clear plastic assembly for juice and pulp, the white food pusher, and the metal frame for pulp collection.

Setup and Assembly

1. **Prepare the Stand Mixer:** Ensure your De'Longhi DSM800 or DSM700 stand mixer is unplugged and placed on a stable, flat surface.
2. **Attach the Juicer Body:** Locate the attachment hub on your stand mixer. Insert the juicer attachment main body into the hub, aligning the tabs and rotating until it locks securely into place.
3. **Assemble Chute and Spout:** Attach the clear juice collection spout and pulp ejection chute assembly to the main juicer body. Ensure it clicks firmly into position.
4. **Position Pulp Frame:** Place the metal pulp collection frame under the pulp ejection chute.
5. **Prepare Containers:** Position a suitable container (glass, pitcher) under the juice spout to collect the extracted juice. Place a separate container under the pulp ejection chute to collect the pulp.
6. **Insert Food Pusher:** Place the food pusher into the feed chute, but do not push down until ready to juice.

Note: The juicer attachment is designed to be used with the stand mixer turned around, allowing for optimal positioning of the collection containers.

Operating Instructions

1. **Prepare Ingredients:** Wash all fruits and vegetables thoroughly. Remove any pits (e.g., from peaches, plums) and thick rinds (e.g., from pineapple, melons). Thin skins on apples and carrots can remain. Cut ingredients into pieces small enough to fit into the feed chute.
2. **Plug In Mixer:** Once the juicer attachment is fully assembled and containers are in place, plug in your De'Longhi stand mixer.
3. **Start Juicing:** Turn on the stand mixer to a medium speed setting.
4. **Feed Ingredients:** Gradually feed the prepared fruits and vegetables into the feed chute. Use the food pusher to

gently guide the ingredients down. Do not force ingredients.

5. **Continuous Operation:** The juicer is designed for continuous operation, automatically separating juice into one container and pulp into another.
6. **Finish Juicing:** Once all ingredients have been processed, turn off the stand mixer and unplug it from the power outlet.

For best results, process softer fruits and harder vegetables alternately to maintain optimal juicing efficiency.

Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your juicer attachment. Always unplug the stand mixer before cleaning.

1. **Disassemble:** Carefully detach the juicer attachment from the stand mixer. Disassemble all removable parts: the clear chute/spout assembly, food pusher, and pulp collection frame.
2. **Rinse Immediately:** Rinse all removable parts under warm running water immediately after use to prevent pulp from drying and sticking.
3. **Clean Filter:** Use a cleaning brush (if provided, or a small brush) to thoroughly clean the stainless steel filter screen. Ensure all pulp residue is removed from the mesh.
4. **Hand Wash:** Hand wash all removable parts with warm, soapy water. Rinse thoroughly.
5. **Main Body Cleaning:** Wipe the main juicer body (the part that connects to the mixer) with a damp cloth. Do not immerse this part in water.
6. **Dry and Store:** Allow all parts to air dry completely before reassembling or storing. Store the attachment in a clean, dry place.

Important: The juicer attachment is **not** dishwasher safe. Hand washing is recommended for all components to preserve their integrity and performance.

Troubleshooting

Problem	Possible Cause	Solution
Juicer does not operate.	Mixer not plugged in or turned on. Attachment not properly secured.	Ensure mixer is plugged in and power is on. Verify the attachment is correctly locked into the mixer hub.
Low juice yield or excessive pulp in juice.	Ingredients too large or fed too quickly. Filter screen clogged.	Cut ingredients into smaller pieces. Feed ingredients slowly and evenly. Clean the filter screen thoroughly.
Attachment vibrates excessively or makes unusual noise.	Improper assembly. Hard ingredients causing strain.	Check that all parts are securely assembled. Ensure pits and thick rinds are removed from ingredients. Do not force ingredients.
Pulp not ejecting properly.	Pulp chute clogged.	Turn off and unplug the mixer. Disassemble and clear any blockages in the pulp chute.

Specifications

- **Model:** A935
- **Brand:** De'Longhi
- **Compatibility:** De'Longhi DSM800 and DSM700 Stand Mixers
- **Recommended Use:** Juicing non-citrus fruits and vegetables
- **Blade Material:** Stainless Steel
- **Product Dimensions:** 11.9 x 9.9 x 9.7 inches (approximately)
- **Item Weight:** 3.54 pounds (approximately)
- **Care Instructions:** Hand wash recommended (Not dishwasher safe)
- **UPC:** 044387779357

Warranty Information

This De'Longhi A935 Continuous Juice Extractor Attachment comes with a**1-year limited warranty** against manufacturing defects from the date of purchase. This warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, abuse, accident, alteration, or commercial use.

Please retain your proof of purchase for warranty claims. For detailed warranty terms and conditions, refer to the documentation included with your stand mixer or contact De'Longhi customer support.

Customer Support

For assistance with your De'Longhi A935 Continuous Juice Extractor Attachment, or for any questions regarding its operation, maintenance, or warranty, please contact De'Longhi Customer Service.

You can find contact information and frequently asked questions on the official De'Longhi website:www.delonghi.com

When contacting support, please have your product model number (A935) and proof of purchase readily available.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00006JL0I

More documents and user manuals: **https://manuals.plus/**