

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [CONAIR](#) /

› [Conair HB1R Ultimate Hair Remover Instruction Manual](#)

CONAIR HB1

Conair HB1R Ultimate Hair Remover Instruction Manual

Model: HB1

INTRODUCTION

The Conair HB1R Ultimate Hair Remover is designed for gentle hair removal and skin exfoliation. This device utilizes counter-rotating fine-grain exfoliating pads to remove hair and leave skin feeling smooth. It is suitable for use on various body areas and is intended to provide a painless hair removal experience.

Key features include:

- Pain-free hair removal and exfoliation.
- Safety power switch, operating only while engaged.
- Sleek ergonomic design for comfortable handling.
- Includes 4 replacement discs for extended use.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **READ ALL INSTRUCTIONS BEFORE USING.**
- **DANGER:** To reduce the risk of electrocution, always unplug this appliance from the electrical outlet immediately after using and before cleaning.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not use while bathing or in a shower.
- Do not place or store appliance where it can fall or be pulled into a tub or sink. Do not place in or drop into water or other liquid.
- **WARNING:** To reduce the risk of burns, electrocution, fire, or injury to persons:
 - An appliance should never be left unattended when plugged in.
 - Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
 - Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
 - Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged, or dropped into water. Return the appliance to an authorized service center

for examination and repair.

- Keep the cord away from heated surfaces. Do not pull, twist, or wrap cord around the appliance.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.
- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not touch surfaces that may become hot during operation.

• Specific Usage Warnings:

- Ensure skin is completely dry before use.
- Avoid bathing and applying moisturizers immediately prior to using the device.
- Skin may be sensitive after use. Test any moisturizer on a small skin patch to check for irritation. Alcohol-free moisturizers are recommended.
- Avoid prolonged use on bony or sensitive areas to prevent skin irritation.

PRODUCT OVERVIEW

The Conair HB1R Ultimate Hair Remover features a handheld design with a rotating head for exfoliating pads. The device is powered by an AC cord and includes a safety switch for controlled operation.



Image 1: The Conair HB1R Ultimate Hair Remover, a white and grey handheld device, is displayed alongside three circular grey exfoliating pads. The device has a tapered handle and a rotating head where the pads attach.



Image 2: A side view of the Conair HB1R Ultimate Hair Remover, showcasing its contoured, ergonomic design in white and grey. The power cord extends from the base, and the rotating pad mechanism is visible at the top.



Image 3: A close-up of the Conair HB1R Ultimate Hair Remover's rotating head, with a grey exfoliating pad securely attached. The textured edge of the pad holder is also visible.



Image 4: An angled perspective of the Conair HB1R Ultimate Hair Remover, illustrating the complete device with an exfoliating pad in place and the attached power cord. The white and grey casing highlights its streamlined form.

SETUP

- 1. Attach an Exfoliating Pad:** Ensure the device is unplugged. Align a new exfoliating pad (Model HPRP08) with the rotating head of the device. Press firmly until it clicks securely into place.
- 2. Connect to Power:** Plug the AC cord into a standard electrical outlet.
- 3. Prepare Skin:** Ensure the skin area where you intend to remove hair is completely dry. Do not apply lotions, oils, or moisturizers before use.

OPERATING INSTRUCTIONS

Follow these steps for effective hair removal and exfoliation:

- 1. Power On:** Press and hold the safety power switch to activate the device. The exfoliating pads will begin to counter-rotate.
- 2. Application:** Gently place the rotating pad flat against your dry skin. Do not press down firmly; allow the device to float over the skin surface.
- 3. Movement:** Move the device in small, circular motions over the desired area. Ensure even coverage.
- 4. Duration:** Continue until hair is removed and skin feels smooth. Avoid prolonged use on a single spot,

especially on bony or sensitive areas, to prevent irritation.

5. **Power Off:** Release the safety power switch to turn off the device.
6. **Frequency:** The device can be used weekly. Over time, hair may grow back finer, potentially allowing for longer intervals between applications.

Note: Results may vary depending on individual hair and skin type. The device is designed to remove hair without nicks, cuts, or ingrown hairs, while simultaneously exfoliating the skin.

MAINTENANCE

Cleaning the Device

- Always unplug the device before cleaning.
- Remove the exfoliating pad.
- Wipe the device body with a clean, damp cloth. Do not immerse the device in water.
- Ensure the device is completely dry before storing or next use.

Replacing Exfoliating Pads

- Exfoliating pads are designed for multi-use but will wear down over time. Replace pads when they become less effective or show signs of wear.
- To remove a used pad, gently peel it off the rotating head.
- Attach a new Conair Replacement Pad (Model HPRP08) as described in the Setup section.

TROUBLESHOOTING

- **Skin Irritation/Sensitivity:** If your skin becomes sensitive or irritated after use, ensure you are using the device on completely dry skin and not pressing too firmly. Avoid prolonged use on one area. Consider applying an alcohol-free moisturizer after use.
- **Ineffective Hair Removal:** Ensure the exfoliating pad is clean and not worn out. Replace the pad if necessary. Confirm the device is making proper contact with the skin and being moved in circular motions.
- **Device Not Turning On:** Check that the AC cord is securely plugged into both the device and a working electrical outlet. Ensure the safety power switch is fully engaged.

SPECIFICATIONS

Model Number	HB1
Product Dimensions	14 x 5 x 10 inches
Product Weight	2.01 Pounds
UPC	074108020543
Manufacturer	Conair
Power Source	AC Corded
Replacement Pads	Model HPRP08

WARRANTY AND SUPPORT

This Conair HB1R Ultimate Hair Remover comes with a**Limited 1 Year Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For warranty service, technical support, or to inquire about replacement parts (such as Model HPRP08 exfoliating pads), please contact Conair Customer Service. Contact information can typically be found on the official Conair website or product packaging.

Do not attempt to repair the appliance yourself. Refer all servicing to authorized Conair service personnel.