

[manuals.plus](#) /› [Braun](#) /› [Braun 30B Series 3 Replacement Foil & Cutter Set Instruction Manual](#)**Braun 30B, 5491765**

Braun 30B Series 3 Replacement Foil & Cutter Set Instruction Manual

Model: 30B, 5491765

1. INTRODUCTION

The Braun 30B Series 3 Replacement Foil & Cutter Set is designed to restore optimal shaving performance for your compatible Braun electric shaver. Over time, shaver foils and cutter blocks experience natural wear, which can reduce shaving efficiency and comfort. Regular replacement of these precision parts ensures a consistently close and comfortable shave.

2. COMPATIBILITY

This Braun 30B Replacement Foil & Cutter Set is compatible with specific Braun shaver models. Please verify your shaver's model number against the list below to ensure proper fit and function.

Compatible Shavers:

- **Braun Series 3 and Braun Smart Control:** Models 340, 330, 320, 310, 300, 4875, 4845, 4840, 4815
- **Braun SyncroPro and Braun Syncro:** Models 7790, 7785, 7765, 7680, 7650, 7630, 7570, 7540, 7520, 7516, 7515, 7510, 7505, 7504, 7493, 7475, 7015
- **Braun Tri Control:** Models 4775, 4745, 4740, 4715

Important Note:

This set is not suitable for all Braun Series 3 shavers. It is specifically designed for shavers where the power button is located on the side. For shavers with front-facing power buttons, you will require part 32b or 32s (an all-in-one cassette) instead.


3. INSTALLATION INSTRUCTIONS

Follow these steps to correctly replace the foil and cutter set on your Braun electric shaver:

1. **Preparation:** Ensure your shaver is turned off and unplugged from any power source.
2. **Remove Old Parts:** Gently remove the existing foil and cutter block. Depending on your shaver model, this may involve pressing release buttons on the sides of the shaver head or simply pulling the old unit upwards.
3. **Install New Parts:** Align the new Braun 30B foil and cutter set with the shaver head. Press it firmly

into place until you hear an audible click, indicating it is securely attached.

4. **Verify:** Ensure the new foil and cutter set is stable and properly seated before operating the shaver.



This image displays the Braun 30B Series 3 Replacement Foil and Cutter Set. It includes the integrated foil head and two individual cutter blocks, ready for installation into a compatible Braun electric shaver.

4. MAINTENANCE

Proper maintenance extends the life of your shaver and ensures consistent performance:

- **Regular Cleaning:** Clean the shaving parts regularly with Braun cleaning agents or as directed in your shaver's original manual. This prevents debris buildup and maintains hygiene.
- **Replacement Frequency:** The foil and cutter block are precision parts that wear over time. For optimal performance and hygiene, it is recommended to replace the foil and cutter block every 18 months.

5. TROUBLESHOOTING

If you encounter issues after replacing your foil and cutter set, consider the following:

- **Improper Fit:** If the new foil and cutter set does not fit or seems loose, re-check your shaver's model number against the compatibility list in Section 2. Ensure the power button location on your shaver

matches the requirements for the 30B part (side-mounted power button).

- **Poor Shaving Performance:** Ensure the new part is securely clicked into place. Check for any debris that might be obstructing the cutters or foil. If issues persist, ensure the shaver itself is functioning correctly.

6. SPECIFICATIONS

Feature	Detail
Model Name	Braun Combi 30B Foil and Cutter Replacement for Series 3
Item Model Number	5491765
Product Dimensions	3.15 x 0.98 x 6.3 inches; 0.35 ounces
Brand	Braun
Recommended Uses	Face
Special Feature	Detachable Head
Power Source (Shaver)	Battery Powered

7. SAFETY INFORMATION

Adhere to the following safety guidelines for optimal product use and personal safety:

- Always replace the foil and cutter block every 18 months to ensure optimal performance and safety. Worn parts can cause irritation or reduce effectiveness.
- Clean the shaving parts regularly with Braun cleaning agents to prevent bacterial growth and maintain hygienic operation.
- Ensure the shaver is turned off and unplugged before attempting to replace any parts.

8. WARRANTY AND SUPPORT

For product support, technical assistance, or inquiries regarding your Braun 30B Series 3 Replacement Foil & Cutter Set, please contact Braun customer service directly. Specific warranty details for replacement parts may vary; refer to your original shaver's manual or Braun's official website for comprehensive warranty information.

You can find additional support and contact information by visiting the official Braun website or contacting their customer service line.