

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [TOMY](#) /

› [Tomy Don't Wake Dad! Board Game Instruction Manual \(Model 284247\)](#)

## TOMY 284247

# Tomy Don't Wake Dad! Board Game Instruction Manual

Model: 284247 | Brand: TOMY

## 1. INTRODUCTION

---

The Tomy Don't Wake Dad! board game is an exciting game designed for 2 to 4 players, aged 4 years and older. The primary objective is to be the first player to successfully navigate the game board and reach the refrigerator space without waking Dad. Players must move cautiously, as any noise might disturb Dad's sleep, sending them back to the start.

## 2. COMPONENTS

---

Please ensure all the following components are present in your game box before starting:

- Game Board
- 4 Player Pawns
- 1 Die
- Playing Cards
- Dad Figure in Bed
- Instruction Manual



Image 2.1: All game components laid out, showing the board, Dad in bed, pawns, and cards.

### 3. SETUP

---

Follow these steps to set up the game:

1. Place the game board on a flat, stable surface.
2. Position the Dad figure in his bed onto the designated spot on the game board.
3. Shuffle the playing cards thoroughly and place them face down in the designated card space on the board.
4. Each player selects a pawn and places it on the "Start" space.
5. Determine the first player. The youngest player typically begins, or players can roll the die to decide who goes first.

**TOMY®**

# SSHH! Don't Wake Dad!

*It's a race  
to get to  
the fridge  
first  
without  
waking Dad!*

**2-4  
PLAYERS  
AGES 4+**



Image 3.1: Game board set up with Dad in bed and player pawns at the start.

## 4. HOW TO PLAY

### Game Objective

The goal is to be the first player to reach the refrigerator space on the game board without waking Dad.

### Player Turn

1. On your turn, roll the die and move your pawn the corresponding number of spaces along the path.
2. Follow the instructions indicated on the space where your pawn lands. These instructions may include:
  - **"Press Dad's alarm clock X times"**: Carefully press the button on Dad's alarm clock the specified number of times. Each press carries a risk of waking Dad.
  - **"Take a card"**: Draw the top card from the deck and follow its instructions. Cards may direct you to move forward, backward, or perform another action.
  - **"Safe space"**: No specific action is required on these spaces.
3. If Dad wakes up (he will sit up and make a sound) after you press the alarm clock, you must return your pawn to the "Start" space.

4. If Dad does not wake up, your turn ends, and play passes to the next player in a clockwise direction.

## Winning the Game

The first player to successfully reach the refrigerator space on the game board without waking Dad is the winner.



Image 4.1: Children engaged in playing the game, demonstrating a turn.

## 5. MAINTENANCE

---

To ensure the longevity of your game, follow these maintenance guidelines:

- Always store all game components in their original box when not in use to prevent loss or damage.
- Keep the game away from direct sunlight, excessive moisture, and extreme temperatures.
- Clean the game board and plastic components with a soft, dry cloth. Do not use abrasive cleaners, solvents, or liquids.
- Ensure the Dad figure's mechanism is free from dust or obstructions for proper operation.

## 6. TROUBLESHOOTING

---

### Dad does not wake up or makes no sound:

Ensure the Dad figure is correctly placed in his bed on the designated spot on the game board. Check for any visible obstructions around the alarm clock button or the Dad figure's internal mechanism. This game does not require batteries, so no battery check is necessary.

### Missing components:

Refer to the "Components" section to verify all parts are present. If components are missing from a new, unopened box, please contact TOMY customer support for assistance.

## 7. SPECIFICATIONS

---

Feature	Detail
Model Number	284247

Brand	TOMY
Age Range	Child (4+ years)
Number of Players	2 to 4
Dimensions (L x W x H)	32 x 10 x 32 cm
Weight	730.28 grams (1.61 pounds)
Material Type	Cardboard, Paper, Plastic
Battery Requirement	None
Educational Objective	Promotes dexterity, strategy, and coordination

## 8. WARRANTY AND SUPPORT

---

For detailed warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official TOMY website. It is recommended to retain your proof of purchase for any warranty claims.

For further assistance with your Don't Wake Dad! game, you may contact TOMY customer service through their official channels.