

Waring FS150

Waring FS150 Food Slicer Instruction Manual

Model: FS150

Sections:

[Introduction](#)

[Safety Instructions](#)

[Parts Identification](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides essential instructions for the safe and efficient use of your Waring FS150 Food Slicer. Designed for home kitchen use, this appliance facilitates the uniform slicing of various foods such as meats, cheeses, vegetables, and breads. Please read all instructions thoroughly before operating the slicer to ensure proper function and safety.



Figure 1: The Waring FS150 Food Slicer. This image displays the overall design of the food slicer, including its stainless steel blade, food carriage, and base.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before use.
- Avoid contact with moving parts. Keep hands, hair, clothing, and utensils away from the blade during operation to prevent injury.
- Always use the food guide to protect fingers when slicing.
- Ensure the appliance is placed on a stable, level surface. The non-slip feet are designed to keep it stationary.
- Do not operate the slicer for more than 10-minute intervals to prevent motor overheating. Allow it to cool down between uses.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not immerse the motor base in water or other liquids.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Close supervision is necessary when any appliance is used by or near children.

3. PARTS IDENTIFICATION

Familiarize yourself with the components of your Waring FS150 Food Slicer:

- **Stainless Steel Blade:** The 7.5-inch undulated blade for slicing.
- **Slice Control Knob:** Adjusts slice thickness from 0-15mm (approximately 1/32 to 1/2 inch).
- **Food Carriage:** The surface where food rests for slicing.
- **Food Holder Arm/Polycarbonate Food Guide:** Secures food and protects hands during slicing.
- **Motor Base:** Contains the 130-watt motor and controls.
- **Non-Slip Feet:** Suction cups on the base for stability.



Figure 2: Removable Slicing Carriage. This close-up view highlights the removable slicing carriage and the stainless steel blade, demonstrating the design for ease of cleaning and operation.

4. SETUP INSTRUCTIONS

1. **Unpack:** Carefully remove all packaging materials and inspect the slicer for any damage.
2. **Placement:** Place the slicer on a clean, dry, and stable countertop. Ensure the non-slip feet are securely gripping the surface.
3. **Blade Installation (if removed):** Ensure the 7.5-inch stainless steel blade is securely attached. Refer to the "Maintenance" section for blade removal/installation details.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet.

5. OPERATING THE FOOD SLICER

Follow these steps for safe and effective slicing:

1. **Prepare Food:** Ensure food items are properly chilled for best slicing results. Trim any bones or excessively hard rinds.
2. **Adjust Slice Thickness:** Turn the slice control knob to your desired thickness, ranging from 0-15mm.
3. **Position Food:** Place the food item on the food carriage. Use the food holder arm to secure the food against the guide plate and protect your fingers.

4. **Power On:** Turn on the slicer using the power switch.
5. **Slice:** Gently push the food carriage back and forth, guiding the food into the rotating blade. Apply even pressure.
6. **Power Off:** After slicing, turn off the slicer and unplug it from the outlet.

Note: This slicer is intended for 10-minute intervals of slicing. For larger quantities, allow the motor to cool down between uses.



Figure 3: Slicer in Operation. This image shows the Waring FS150 Food Slicer on a kitchen counter, accompanied by freshly sliced meats, cheeses, and bread, illustrating its practical application.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your slicer. Always unplug the unit before cleaning.

6.1. Daily Cleaning

1. **Unplug:** Ensure the slicer is unplugged from the power outlet.
2. **Remove Food Holder Arm and Carriage:** The stainless steel carriage surface and food holder arm are designed to detach for easy cleanup.
3. **Blade Removal:** The 7.5-inch stainless steel blade is removable. Carefully detach it for thorough cleaning.
4. **Wash Parts:** Hand wash the removable blade, food carriage, and food holder arm with warm, soapy water. Rinse thoroughly and dry immediately.
5. **Wipe Base:** Use a damp cloth to wipe down the motor base and exterior surfaces. Do not immerse the motor base in water.
6. **Reassemble:** Once all parts are dry, carefully reassemble the slicer.

Caution: The blade is extremely sharp. Handle with care to avoid injury.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Slicer does not turn on.	Not plugged in; power outlet not active; power switch off.	Ensure power cord is securely plugged in. Check power outlet with another appliance. Turn power switch to ON position.
Slices are uneven or difficult to cut.	Blade is dull; food not properly chilled; incorrect slice thickness setting; food not secured.	Ensure food is firm and chilled. Adjust slice control knob. Secure food with the food holder arm. If blade is dull, consider professional sharpening or replacement.
Slicer moves on countertop during operation.	Non-slip feet not gripping; surface is wet or oily.	Ensure countertop is clean, dry, and free of oil. Press down on the slicer to engage suction cups.
Motor sounds strained or overheats.	Overuse; cutting excessively hard items; food jammed.	Do not operate for more than 10 minutes continuously. Allow motor to cool. Avoid cutting frozen or extremely hard items. Clear any food jams after unplugging.

8. PRODUCT SPECIFICATIONS

Brand	Waring
Model Number	FS150
Material	Stainless Steel (Blade, Carriage Surface), Die-cast Aluminum (Housing)
Blade Material	Stainless Steel
Blade Size	7.5 inches
Slice Thickness Adjustment	0-15mm (approx. 1/32 to 1/2 inch)
Motor Power	130 watts
Dimensions (L x W x H)	17.5 x 11.2 x 11.2 inches
Item Weight	11.66 pounds (approx. 5.3 kg)
Special Feature	Anti-Slip (Suction-cup feet)
Operation Mode	Electric
Product Care	Hand Wash Only (removable parts)
UPC	040072000508





9. WARRANTY AND CUSTOMER SUPPORT



The Waring FS150 Food Slicer comes with a limited 5-year motor warranty from Waring. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact Waring customer service.

For technical assistance, parts, or service inquiries, please contact Waring customer support. Contact information can typically be found on the manufacturer's website or in the product packaging.

© 2023 Waring. All rights reserved.

Related Documents - FS150

 <p>WARING COMMERCIAL Food Slicer Rebanadora de alimentos/ Cortadora de fiambré Trancheuse WCS220/250/300 Series</p>	<p>Waring Commercial Food Slicer WCS220/250/300 Series User Manual</p> <p>Comprehensive guide for Waring Commercial Food Slicers, models WCS220, WCS250, and WCS300. Covers unpacking, safety, installation, operation, cleaning, sharpening, and troubleshooting.</p>
 <p>WARING COMMERCIAL 10-TRAY FOOD DEHYDRATOR DESSEHIDRADOR DE ALIMENTOS DE DIEZ BANDEJAS DESHYDRATEUR ALIMENTAIRE À 10x PLATEAUX WDH10</p>	<p>Waring Commercial 10-Tray Food Dehydrator WDH10 User Manual</p> <p>Discover the Waring Commercial 10-Tray Food Dehydrator (WDH10). This manual guides you through safe operation, food preservation techniques, and recipes for drying fruits, vegetables, and meats. Learn about the benefits of dehydration for healthy snacking and ingredient preparation.</p>
 <p>WARING COMMERCIAL 3.5 Qt. Food Processors WFP14S & WFP14SC</p>	<p>Waring WFP14S & WFP14SC Food Processors Parts and Information</p> <p>Detailed parts list and information for Waring Commercial 3.5 Qt. Food Processors, models WFP14S and WFP14SC. Includes diagrams and component descriptions.</p>
 <p>WARING COMMERCIAL BB155/BB155S SERIES INSTRUCTION MANUAL MANUAL DE INSTRUCCIONES DE LAS LICUADORAS DE LA SERIE BB155/BB155S DIRECTIVES D'UTILISATION DES MÉLANGEURS DE LA SERIE BB155/BB155S</p>	<p>Waring BB155/BB155S Series Commercial Blender Instruction Manual</p> <p>Comprehensive user manual for Waring BB155 and BB155S Series commercial blenders, covering safety, operation, assembly, cleaning, and warranty information.</p>

	<p>Waring Commercial Coffee Warmers WCW10/WCW20/WCW20R - Instruction Manual</p> <p>Official instruction manual for Waring Commercial Coffee Warmers models WCW10, WCW20, and WCW20R. Find detailed information on safety, operation, grounding, troubleshooting, and warranty.</p>
	<p>Waring Commercial Sous Vide: A Smarter Way to Cook</p> <p>Explore the Waring Commercial Sous Vide Thermal Circulator (WSV16) and associated vacuum sealing systems (WCV300, WVS50) and induction cooktops (WIH400, WIH800). Learn about precision cooking, time-saving benefits, and enhanced food quality for professional kitchens.</p>

Documents - Waring – FS150

[\[pdf\]](#) User Manual Instructions

Waring Pro Food Slicer Model FS150 User Manual waringproducts WaringPro Fante 39 s Kitchen Shop in this manual please refer to a qualified service center recommended by Always read the instructions for use carefully before using and keep them place where they can be referred whenever necessary UNPACKING INSTRUCTIONS 1 Place box on large sturdy flat surface 2 Remove instruction book any other literature 3 waringpro food slicer fs150 fantes net manuals Food Slicer **FS150** For your safety and continued enjoyment of this product, always read the instruction book carefully before using. IMPORTANT SAFEGUARDS When using electrical appliances, basic safety precautions should always be followed, including the following: 1. Read all instructions. 2. To ... lang:en score:45 filesize: 193.14 K page_count: 8 document date: 2010-03-05

[\[pdf\]](#) User Manual Instructions

ood Slicer FS150 Everything Kitchens FOOD SLICER in this manual please refer to a qualified service center recommended by Waring Always read the instructions for use carefully before using and keep them place where they can be referred whenever necessary UNPACKING INSTRUCTIONS 1 Place box on large sturdy flat surface 2 Remove instruction book any other literature 3 FS155 everythingkitchens media 80 manuals Food Slicer **FS150** For your safety and continued enjoyment of this product, always read the instruction book carefully before using. IMPORTANT SAFEGUARDS When using electrical appliances, basic safety precautions should always be followed, including the following: 1. Read all instructions. 2. To ... lang:en score:43 filesize: 174.59 K page_count: 8 document date: 2008-04-22

[pdf] User Manual

W6314 Mail In Certificatewaring fs150 mg100 20 cash back6 30 11everythingkitchens media manual
waring 11 srsltid AfmBOorY03qGSgEu5 FiicNgfKXiBJzslartggUyucxC3bnjPCD1Wsc Certificate
Everything KitchensWhen you purchase a Waring Pro® FS150 Food Slicer or MG100A Meat Grinder and
mail in this certificate will receive check for \$20 00 This waring 11waring AfmBOopDnH1FpBYj
uAWnnepFjzao37qR qaMxr Kka PadGxomKppCQeverythingkitchens
FiicNgfKXiBJzslartggUyucxC3bnjPCD1Wsceverythingkitchens AfmBOop
uCDUubP9ZZK0KM06KyFZcMuvRgoo8Usfszjj1Ir2iLMETeVs3
uCDUubP9ZZK0KM06KyFZcMuvRgoo8Usfszjj1Ir2iLMETeVs3everythingkitchens KitchensMail This When
AfmBOoqx4MplhbiQ1sXAXmMOHU4kO6fZmhNjXWE0NwKpxAE1FndybYDweverythingkitchens |||
Mail-In Certi cate When you purchase a Waring Pro **FS150** Food Slicer or MG100A
Meat Grinder and mail in this certi cate, you will receive a check for 20.00. Here s how
to receive your check: 1. Purchase a Waring Pro **FS150** Food Slicer or MG100A Meat
Grinder from any Waring retailer. 2. Send...
lang:en score:33 filesize: 303.51 K page_count: 1 document date: 2011-04-20

[pdf] User Manual





W6306 FREE! From Receive a FREE BONUS GIFT of one Stainless Steel Platter \$25 00 value with the
purchase Waring Pro® FS150 or FS800 Food Slicer Mail In Certificate This offer is good on purchases
made between 1 11 and 12 31 Any response postmarked after not eligible waring rebate fs150 fs800
platter everythingkitchens media manual
FREE From Receive a FREE BONUS GIFT of one Stainless Steel Platter - a 25.00
value - with the purchase of one Waring Pro **FS150** or FS800 Food Slicer. Mail-In
Certificate This offer is good on purchases made between 1/1/11 and 12/31/11. Any
response postmarked after 1/31/12 is not eligible. Here ...
lang:en score:32 filesize: 574.48 K page_count: 1 document date: 2010-12-29

[pdf] User Manual

W6116 Mail In Certificate This certificate has no cash value Void where prohibited restricted licensed or
taxed Limit one request per item family name address waring pro fs150 slicer rebate 12 31 09
everythingkitchens media manual
Mail-In Certificate When you purchase a Waring Pro **FS150** Food Slicer and mail in
this certificate, you will receive a check for 20.00. Here s how to receive your check:
1. Purchase a Waring Pro **FS150** Food Slicer from any Waring retailer. 2. Send this
original completed certificate photocopied cert...
lang:en score:32 filesize: 298.71 K page_count: 1 document date: 2009-11-12

[pdf]

W6314 waring fs150 mg100 20 cash back6 30 11 everythingkitchens
Mail-In Certificate When you purchase a Waring Pro **FS150** Food Slicer or MG100A
Meat Grinder and mail in this certificate, you will receive a check for 20.00. Here s
how to receive your check: 1. Purchase a Waring Pro **FS150** Food Slicer or MG100A
Meat Grinder from any Waring retailer. 2. Send this or...
lang:en score:29 filesize: 303.5 K page_count: 1 document date: 2011-04-20






[\[pdf\]](#) User Manual Instructions Guide Warranty

Food Slicer FS 150PR Everything Kitchens 2 English Directions for use 1 @Place NESCO food slicer on a flat stable surface If appliance is being used the first time follow Cleaning Instructions below fs150 nesco pro careuse1 everythingkitchens media manual 80 files

Food Slicer FS-150PR Care/Use Guide Trancheuse De Nourriture FS-150PR Guide de Soin/Utilisation English Food Slicer FS-150PR Table of Contents IMPORTANT SAFEGUARDS..... 1 SAVE THESE INSTRUCTIONS 1 Direct...

lang:en score:26 filesize: 1.34 M page_count: 16 document date: 2010-01-21



[\[pdf\]](#) Catalog

FS150 1 1st Generation interchangeable Same Catalog Model Illustration Part Description 029670B

Blade Guard 2nd generation 026573 2 029671B Motor Cover 026574 3 029672B Screw 026575 Req 39 d 4 029673B 5 ereplacementparts images waring |||

1st Generation 2nd Generation 14 16 17 15 18 19 20 27 Unit Information 130 Watts Slicing Thickness 1/32 to 1/2 Operate for Short Periods of Time 10 minutes max. Remove Blade Turn Hub Screw Clockwise with Nickel or Quarter Do Not Wash Any Part Of Slicer In Dishwasher Blade is 7.5 1 **FS150** Note: S...

lang:en score:23 filesize: 1.15 M page_count: 3 document date: 2008-11-12

[\[pdf\]](#) User Manual

W6216 Mail In Certificate This certificate has no cash value Void where prohibited restricted licensed or taxed Limit one request per item family name address FS 20 CashBack 12 31 10 everythingkitchens media manual 80

Mail-In Certificate When you purchase a Waring Pro **FS150** or FS800 Food Slicer and mail in this certificate, you will receive a check for 20.00. Here s how to receive your check: 1. Purchase a Waring Pro **FS150** or FS800 Food Slicer from any Waring retailer. 2. Send this original completed certificate...

lang:en score:23 filesize: 297.76 K page_count: 1 document date: 2010-11-15





[\[pdf\]](#) Guide Borchure

DownloadBrochures Adhesealadheseal product guide first edition 1cdn shopify s files 1 0507 3630 0224 adheseal v 1616554318 |||


Product Guide Construction Manufacturing Marine Automotive www.adheseal.com.au
First E ... Wall Scraper Size 100mm Code SCRAPERWA/100 Floor Scraper - Heavy Duty Size Floor Scraper - 150mm **FS150** Floor Scraper - 300mm FSHD300 Replacement Blade 150mm **FS150RB** Replacement Blade 300mm FS...
lang:en **score:16** filesize: 15.79 M page_count: 144 document date: 2018-09-11



[\[pdf\]](#)

W6216 f txt content haycdn images 2 CUI419 |||

Mail-In Certificate When you purchase a Waring Pro **FS150** or FS800 Food Slicer and mail in this certificate, you will receive a check for 20.00. Here s how to receive your check: 1. Purchase a Waring Pro **FS150** or FS800 Food Slicer from any Waring retailer. 2. Send this original completed certificate...
lang:en **score:16** filesize: 862.66 K page_count: 2 document date: 2010-11-17



[\[pdf\]](#)

waring fs150 mg100 20 cash back Laura Waring DF250B Cash Back Rebate 7 31 11 everythingkitchens

...

lang:en **score:13** filesize: 93.56 K page_count: 1 document date: 2011-04-25



[Oregon 2019 Catalog: Outdoor Power Equipment & Forestry Tools](#)

Explore the comprehensive 2019 Oregon catalog featuring a wide range of outdoor power equipment, including cordless tools, log splitters, and forestry essentials. Discover innovative solutions for professional and homeowner needs.

lang:en **score:13** filesize: 231.3 M page_count: 1716 document date: 2019-02-19



[Oregon 2019 Catalog: Outdoor Power Equipment & Forestry Tools](#)

Explore the 2019 Oregon catalog featuring a comprehensive range of outdoor power equipment, including cordless chainsaws, mowers, trimmers, and log splitters, alongside forestry tools and accessories. Find detailed product information and application guides.

lang:en score:13 filesize: 231.3 M page_count: 1716 document date: 2019-02-19




[\[pdf\] Instructions Guide Warranty](#)

Untitled FS 150PR Electric Food Slicer CUG fs150 nesco pro slicer careuse1 2020 11 2018 09

Food Slicer FS-150PR Care/Use Guide Trancheuse De Nourriture FS-150PR Guide de Soin/Utilisation English Food Slicer FS-150PR Table of Contents IMPORTANT SAFEGUARDS..... 1 SAVE THESE INSTRUCTIONS 1 Directi...

lang:en score:12 filesize: 259.7 K page_count: 16 document date: 2019-05-13



[\[pdf\] Catalog](#)

Untitled DownloadMedunjess Product Catalog Explore Our Premium Bathtub Collection Medunjess Stone Bathtubs Your Bathroom Reimagined2023 1022 1cdn shopify s files 1 0644 3617 4986 2023 v 1724231425 |||

ME DUNJE55 Custom luxury villo BATH COLLECTIONS OUR GOAL TO GRASP DEMAND TRENDS ANT THEM FROM A CON ... 5x135mm Colour can be customised FS110-610 Starry Blue 610x365x135mm Colour can be customised **FS150**-585 Jelly Green 585x385x150mm Colour can be customised **FS150**-585 Pompeif Red 585x385x150mm ...

lang:en score:10 filesize: 19.62 M page_count: 65 document date: 2024-08-21



[\[pdf\] Accessories Borchure](#)

DownloadBrochures Adhesealadheseal tools accessories and safety equipmentcdn shopify s files 1 0507 3630 0224 adheseal equipment v 1616554801 |||

Adheseal Tools Accessories Safety Equipment General Construction Adhesives STeoaollasnAtsccesso ... Wall Scraper Size 100mm Code SCRAPERWA/100 Floor Scraper - Heavy Duty Size Floor Scraper - 150mm **FS150** Floor Scraper - 300mm FSHD300 Replacement Blade 150mm **FS150RB** Replacement Blade 300mm FS...

lang:en score:9 filesize: 1.14 M page_count: 19 document date: 2018-09-11

