

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Craftmade](#) /

> [Craftmade WB348TS3 Tiger Shark Warplane 48-Inch Ceiling Fan with Light User Manual](#)

Craftmade WB348TS3

Craftmade WB348TS3 Tiger Shark Warplane 48-Inch Ceiling Fan with Light User Manual

Model: WB348TS3 | Brand: Craftmade

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Craftmade WB348TS3 Tiger Shark Warplane 48-inch ceiling fan. Please read all instructions carefully before beginning installation to ensure proper function and safety.



Image: The Craftmade WB348TS3 Tiger Shark Warplane 48-inch ceiling fan, featuring a distinctive warplane design with three black blades and an integrated light kit.




Image: The Craftmade WarPlanes collection, showcasing various models including the WB348TS3 Tiger Shark, highlighting its unique design within the series.

IMPORTANT SAFETY INFORMATION

- **Read all instructions:** Before installing or operating the fan, read and understand all safety information and installation instructions.
- **Electrical Safety:** All electrical wiring must be performed by a qualified electrician and conform to all local and national electrical codes. Disconnect power at the circuit breaker before installation or servicing.
- **Mounting:** Ensure the mounting structure can support the weight of the fan (approximately 13.87 pounds) plus the dynamic load of the fan in operation.
- **Blade Clearance:** Maintain a minimum clearance of 7 feet from the floor to the fan blades. Ensure blades do not strike any objects.
- **Light Bulb:** Use only the specified bulb type (B10 60-watt candelabra frosted bulb) or an equivalent LED bulb. Do not exceed the maximum wattage.
- **Cleaning:** Always disconnect power before cleaning the fan. Use a soft, damp cloth. Do not use abrasive cleaners.
- **Proposition 65 Warning:** This product may expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

PARTS LIST

Verify that all components are present before beginning installation:

- Motor Housing Assembly
- Fan Blades (3)

- Light Kit Assembly (Integrated)
- Mounting Bracket/Plate
- Hardware Pack (screws, washers, wire nuts)
- Pull Chains (for fan speed and light)
- B10 60-watt Candelabra Frosted Bulb (1)
- Installation Guide (this manual)

SETUP AND INSTALLATION

Tools Required: Phillips screwdriver, flathead screwdriver, wire strippers, electrical tape, ladder.

1. **Power Disconnection:** Before starting, ensure the power supply to the fan location is turned off at the circuit breaker.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure the junction box is securely fastened to the building structure and can support the fan's weight.
3. **Wiring:** Carefully connect the fan's electrical wires to the household wiring according to local electrical codes. Typically, this involves connecting the black (hot) wire from the fan to the black (hot) wire from the ceiling, the white (neutral) wire from the fan to the white (neutral) wire from the ceiling, and the green or bare copper (ground) wire from the fan to the ground wire from the ceiling. Use approved wire nuts for all connections.
4. **Attaching Fan Body:** Lift the fan motor housing and align it with the mounting bracket. Some models feature a hook and loop system or a slot and slide system to temporarily support the fan while wiring. Secure the fan body to the mounting bracket using the provided screws. *Note: If instructions mention loosening screws from the motor housing for mounting, it is often more effective to remove the three screws from the mounting plate, attach the motor housing, and then re-use those screws to secure it.*
5. **Blade Attachment:** Attach the three fan blades to the motor housing using the provided screws and washers. Ensure all screws are tightened securely.
6. **Light Kit Installation:** Connect the light kit wiring to the fan motor wiring. Secure the light kit assembly to the bottom of the fan motor housing. Install the included B10 60-watt candelabra frosted bulb into the light kit socket.
7. **Pull Chain Installation:** Attach the decorative pull chains to the fan speed and light switches.
8. **Power Restoration:** Once installation is complete and all connections are secure, restore power at the circuit breaker.




Image: Diagram illustrating the dimensions of the Craftmade WB348TS3 ceiling fan, showing an overall height of 17 inches and a blade sweep diameter of 48 inches.



Image: Close-up view of the integrated light kit and pull chains on the Craftmade WB348TS3 ceiling fan, highlighting the matte white glass and red housing.

OPERATING INSTRUCTIONS

Your Craftmade WB348TS3 ceiling fan is operated by two pull chains:

- **Fan Speed Control:** One pull chain controls the fan speed. Pull the chain repeatedly to cycle through the three available speeds (High, Medium, Low) and Off.
- **Light Control:** The other pull chain controls the integrated light kit. Pull the chain to turn the light On or Off.
- **Reversible Motor:** This fan features a reversible motor for year-round use. A switch on the motor housing (usually located above the blades) allows you to change the direction of blade rotation.
 - **Summer Operation:** Set the switch for counter-clockwise rotation to create a downward airflow, providing a cooling effect.
 - **Winter Operation:** Set the switch for clockwise rotation to create an upward airflow, circulating warm air trapped near the ceiling.

MAINTENANCE

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive materials or harsh chemicals, as these can damage the finish. Ensure power is disconnected before cleaning.
- **Blade Care:** Periodically check the blade screws for tightness. Loose screws can cause wobbling and noise.
- **Light Bulb Replacement:** Disconnect power before replacing the light bulb. Allow the bulb to cool completely. Replace with a B10 60-watt candelabra frosted bulb or an equivalent LED bulb.

- **Motor Lubrication:** The fan motor is permanently lubricated and does not require additional oiling.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Motor switch in OFF position.	Check circuit breaker/fuse; Verify all wire connections are secure; Ensure pull chain is not in OFF position.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a balancing kit (not included) if necessary; Ensure mounting bracket is securely fastened.
Light does not work	Bulb burned out; Loose wire connection in light kit; Light pull chain in OFF position.	Replace bulb; Check light kit wiring; Ensure light pull chain is in ON position.
Noisy operation	Loose screws; Blades rubbing; Motor hum.	Check and tighten all screws; Ensure blades have proper clearance; A slight motor hum is normal, but excessive noise may indicate an issue.

SPECIFICATIONS

Model Number	WB348TS3
Brand	Craftmade
Fan Design	Hugger Ceiling Fan (Warplane Style)
Blade Span	48 inches
Number of Blades	3
Blade Material	Plywood
Motor Type	Quiet AC Motor (153x12 mm)
Airflow Capacity	4138 CFM
Control Type	Pull Chain (3-speed fan, On/Off light)
Light Kit	Integrated, Cased White Glass
Bulb Type	1 x B10 60-watt Candelabra Frosted Bulb (Incandescent)
Voltage	120 Volts
Product Dimensions	48"D x 48"W x 17"H
Item Weight	13.87 pounds
Indoor/Outdoor Usage	Indoor

Certifications	cULus Listed
----------------	--------------

WARRANTY INFORMATION

The Craftmade WB348TS3 ceiling fan comes with a **Lifetime Limited Warranty**. For specific terms and conditions, please refer to the warranty card included with your product or visit the official Craftmade website.

CUSTOMER SUPPORT

For further assistance, technical support, or to view other products, please visit the official Craftmade store or contact customer service:

Craftmade Official Store: [Visit Craftmade Store on Amazon](#)

Contact information (phone/email) typically found on product packaging or official website.

