

Intempo PG-01

Intempo PG-01 DAB Digital Radio User Manual

1. INTRODUCTION

Thank you for purchasing the Intempo PG-01 DAB Digital Radio. This manual provides detailed instructions to help you set up, operate, and maintain your radio, ensuring optimal performance and longevity. Please read this manual thoroughly before using the device and retain it for future reference.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Avoid placing the unit near heat sources such as radiators or stoves.
- Ensure proper ventilation; do not block any ventilation openings.
- Use only the power adapter supplied with the unit.
- Do not attempt to open or service the unit yourself. Refer all servicing to qualified personnel.
- Clean the unit only with a dry, soft cloth.

3. PACKAGE CONTENTS

Please check that all items are present:

- Intempo PG-01 DAB Digital Radio
- Power Lead
- Telescopic Antenna (pre-attached)
- User Manual (this document)

4. PRODUCT OVERVIEW

4.1 Front Panel



This image displays the front of the Intempo PG-01 DAB Digital Radio, featuring its wooden casing, a silver control panel, two prominent speaker grilles, and a central LCD display. The control panel includes a circular knob for tuning/volume and four rectangular buttons for various functions.

- **LCD Display:** Shows station information, time, and menu options.
- **Tuning/Volume Knob:** Rotates to adjust volume or navigate menus; press to select.
- **Function Buttons (1-4):** Used for presets, menu navigation, and specific features like alarm/sleep.
- **Speakers:** Integrated stereo speakers for audio output.

4.2 Rear Panel



This image shows the rear panel of the Intempo PG-01 DAB Digital Radio. Visible components include the telescopic antenna, a headphone jack, and the DC power input port. A product label with model information is also present.

- **Telescopic Antenna:** Extend for optimal DAB/FM reception.
- **Headphone Jack (3.5mm):** For private listening.
- **DC IN:** Power input for the supplied adapter.

4.3 Control Panel Close-up



This close-up view highlights the silver control panel of the Intempo PG-01 DAB Digital Radio. It features the 'intempo digital' branding, a 'stereo' indicator, the circular tuning/volume knob, and four distinct rectangular buttons labeled 1 through 4, used for various radio functions and presets.

5. SETUP

5.1 Power Connection

1. Insert the DC plug of the supplied power adapter into the **DC IN** socket on the rear of the radio.
2. Plug the power adapter into a standard wall outlet.
3. The radio will power on automatically or enter standby mode.

5.2 Antenna Adjustment

For optimal reception, fully extend the telescopic antenna located on the rear of the unit. Adjust its position for the best signal quality, especially in DAB mode.

5.3 Initial DAB Scan

Upon first power-on, the radio will automatically perform a full scan for available DAB stations. This process may take a few minutes. Once complete, the first available station will begin playing.

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the **Power** button (often integrated with the tuning knob or a dedicated button) to switch the radio on or off (standby mode).

6.2 Mode Selection (DAB/FM)

Press the **Mode** button (or a similarly labeled function button) to switch between DAB Digital Radio and FM

Radio modes.

6.3 Tuning

DAB Mode:

1. In DAB mode, rotate the **Tuning Knob** to scroll through the list of available stations.
2. Press the **Tuning Knob** to select and play the desired station.

FM Mode:

1. In FM mode, rotate the **Tuning Knob** to manually tune to a frequency.
2. Press and hold the **Tuning Knob** (or a dedicated scan button) to automatically scan for the next available station.

6.4 Preset Stations

The radio supports 8 programmable preset stations (4 for DAB, 4 for FM).

To Store a Preset:

1. Tune to the desired DAB or FM station.
2. Press and hold one of the **Preset Buttons (1-4)** until the display confirms the station has been saved.

To Recall a Preset:

1. Briefly press the desired **Preset Button (1-4)** to switch to the stored station.

6.5 Volume Control

Rotate the **Tuning/Volume Knob** to increase or decrease the audio volume.

6.6 Clock and Alarm Functions

The radio features a built-in clock and alarm functions. Refer to the on-screen menu options for setting the time and configuring alarms. Typically, this involves navigating the menu using the **Tuning Knob** and selecting options with a press.

6.7 Sleep Timer

The sleep timer allows the radio to turn off automatically after a set period. Access the **Sleep** function via the menu or a dedicated button, then select the desired duration (e.g., 15, 30, 60 minutes).

6.8 Headphone Use

Plug standard 3.5mm headphones into the **Headphone Jack** on the rear panel for private listening. The internal speakers will automatically mute.

6.9 AUX Input (If applicable)

If your model includes an AUX input, you can connect external audio devices (e.g., MP3 player, smartphone) using a 3.5mm audio cable. Select the AUX mode on the radio to play audio from the connected device.

7. MAINTENANCE

7.1 Cleaning

Wipe the radio's surface with a soft, dry, lint-free cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

7.2 Storage

If storing the radio for an extended period, disconnect it from the power supply and store it in a cool, dry place away from direct sunlight and extreme temperatures.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Power adapter not connected or faulty outlet.	Ensure power adapter is securely connected and the outlet is functional.
Poor DAB/FM reception	Antenna not extended or poor signal area.	Fully extend and adjust the telescopic antenna. Try repositioning the radio. Perform a full scan in DAB mode.
No sound	Volume too low, headphones connected, or muted.	Increase volume. Disconnect headphones. Check if the unit is muted.
Buttons unresponsive	Temporary software glitch.	Disconnect power for a few seconds, then reconnect to reset the unit.

9. SPECIFICATIONS

Feature	Specification
Brand	Intempo
Model	PG-01
Tuner Technology	DAB, FM
Radio Bands Supported	2-bands
Max. Speaker Output Power	5 Watts RMS
Display Type	LCD
Special Features	Built-in clock, Alarm, Sleep function, 8 programmable presets
Hardware Interface	3.5 mm audio
Connector Type	AUX
Power Source	Electric Wired
Compatible Devices	Earphone, Tablet, Laptop, MP3-player, Headphone, Smartphone
Dimensions (approx.)	30.4 x 25.4 x 14.8 cm
Weight (approx.)	1.76 kg

10. WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions. For technical support or service inquiries, please contact your retailer or the manufacturer's customer service department.