Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Master Lock 8122D

Master Lock Cable Lock Instruction Manual

Model: 8122D
Brand: Master Lock

Product Overview

The Master Lock 8122D Cable Lock is designed to provide basic security for bicycles and other outdoor equipment. Its braided steel construction offers flexibility and durability, while a protective vinyl coating helps prevent scratching of your valuables. This lock features a convenient set-your-own four-digit combination, eliminating the need for keys.

- Ideal for securing bicycles and various outdoor equipment.
- Features a customizable four-digit combination for keyless convenience.
- Constructed with braided steel for strength and flexibility.
- Protective vinyl coating helps prevent damage to surfaces.
- Cable length: 6 ft. (1.8 m), Diameter: 1/2 in. (13 mm).

Setup and Combination Setting

Setting Your Own Combination

Your Master Lock cable lock comes preset to 0-0-0-0. To set your personal combination, follow these steps:

1. Ensure the lock is set to the current combination (initially 0-0-0-0) and the cable is disengaged.
2. Locate the reset knob on the end of the lock mechanism.
3. Turn the reset knob 90 degrees clockwise to the position indicated for resetting.
4. Set your desired four-digit combination by rotating the number wheels. Align your chosen numbers with the indicator marks.
5. Once your new combination is set, turn the reset knob 90 degrees counter-clockwise back to its original position. This locks in your new combination.
6. Scramble the dials to secure the lock. Test your new combination to ensure it opens correctly before locking your equipment.

Your browser does not support the video tag.

Video: Operating Master Lock Combination Bike Cables. This video demonstrates how to set and reset the combination on your Master Lock cable lock.

Attaching the Mounting Bracket (if included)

Some models include a mounting bracket for convenient storage on your bicycle. To attach the bracket:

1. Identify a suitable location on your bicycle frame or seat post.
2. Use the provided screws to secure the bracket firmly to the bike. Ensure it is tight enough to prevent movement during riding.
3. To attach the lock to the bracket, align the lock's end with the bracket's slot and press the red button on the bracket to release the clasp. Insert the lock and release the button to secure it.
4. To remove the lock from the bracket, press the red button and pull the lock away.



Image: The Master Lock cable lock shown alongside its optional mounting bracket, which allows for convenient attachment to a bicycle frame.

Operating the Lock

Using your Master Lock combination cable lock is straightforward:

1. **To Unlock:** Rotate the number wheels to your personal four-digit combination. Once the correct combination is aligned, the

cable end will release from the lock body.

2. **To Lock:** Wrap the cable around the item(s) you wish to secure and a fixed object. Insert the free end of the cable into the lock body until it clicks securely. Scramble the number wheels to a random sequence to prevent unauthorized access.



Image: The Master Lock cable lock in its coiled state, ready for use or storage.



Image: The Master Lock cable lock is suitable for securing various items such as bicycles, lawn mowers, and other outdoor equipment.

Maintenance

To ensure the longevity and smooth operation of your Master Lock cable lock:

- Keep the combination wheels clean and free from dirt or debris. Use a soft, damp cloth for cleaning.
- Periodically apply a small amount of silicone lubricant to the moving parts of the combination mechanism to maintain smooth operation.
- Avoid exposing the lock to extreme temperatures or harsh chemicals, which could damage the vinyl coating or internal components.
- Store the lock in a dry place when not in use to prevent rust or corrosion.




Image: A cross-section view of the cable, highlighting the braided steel core and the protective vinyl coating designed to prevent scratches.

Troubleshooting

- **Difficulty Rotating Dials:** If the combination wheels are stiff, apply a small amount of silicone lubricant and try rotating them again. Ensure no dirt or foreign objects are lodged between the wheels.
- **Lock Not Opening with Correct Combination:** Double-check that each number is precisely aligned with the indicator marks. If you recently reset the combination, ensure you are using the new combination. If the issue persists, try the original 0-0-0-0 combination as a last resort, in case the reset was not fully completed.
- **Forgetting Your Combination:** Unfortunately, if you forget your combination and did not record it, there is no master key or backdoor to open the lock. The only solution would be to attempt to cycle through combinations or, if necessary, use a cutting tool. It is highly recommended to store your combination securely in a memorable location or using the Master Lock Vault service.

Specifications

Brand	Master Lock

Model Name	8122D
Lock Type	Combination Lock
Special Feature	Resettable
Material	Vinyl, Alloy Steel
Color	Black
Cable Length	6 ft. (1.8 m)
Cable Diameter	1/2 in. (13 mm)
Item Weight	1.61 pounds
Product Dimensions	8 x 5.8 x 1.1 inches
Country of Origin	China
UPC	071649049491

Warranty and Support

This Master Lock product is backed by a **Limited Lifetime Warranty**. For detailed warranty information, product support, or to register your combination, please visit the official Master Lock website or contact their customer service.
You can also securely store your combination at MasterLockVault.com for easy retrieval if you forget it.

© 2025 Master Lock. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0000D1E3S

More documents and user manuals: **https://manuals.plus/**