

Westclox 47550

Westclox Bell Ringer II Quartz Analog Alarm Clock User Manual

Model: 47550

INTRODUCTION

Thank you for choosing the Westclox Bell Ringer II Quartz Analog Alarm Clock. This manual provides essential information for setting up, operating, and maintaining your new alarm clock. Designed for reliability and ease of use, this clock features a traditional bell alarm and a precise quartz movement.

PACKAGE CONTENTS

Please ensure all items are present before proceeding:

- Westclox Bell Ringer II Quartz Analog Alarm Clock (Model 47550)

PRODUCT OVERVIEW

The Westclox Bell Ringer II is a classic analog alarm clock with a durable black casing and a clear, easy-to-read dial.



This image shows the front view of the Westclox Bell Ringer II alarm clock, featuring its black casing and clear analog dial with large numerals.



A close-up view of the clock's face, highlighting the luminous hour and minute hands, the 'Westclox' brand name, and the 'QUARTZ' designation.



The alarm clock is shown positioned on a white, multi-tiered bedside shelf, demonstrating its compact size and suitability for various indoor settings.

Key Features:

- Large analog display for easy readability.
- Light on demand for viewing in low-light conditions.
- Loud bell alarm to ensure you wake up.
- Compact and suitable for travel.

SETUP

Battery Installation

1. Locate the battery compartment cover on the back of the clock.
2. Remove the cover by sliding or lifting it.
3. Insert one (1) C-size battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. (Note: Battery is not included).
4. Replace the battery compartment cover securely.

Setting the Time

1. Locate the time setting knob on the back of the clock.
2. Rotate the knob clockwise or counter-clockwise until the hour and minute hands indicate the correct time.

OPERATING INSTRUCTIONS

Setting the Alarm

1. Locate the alarm setting knob on the back of the clock.
2. Rotate the alarm setting knob until the alarm hand points to your desired wake-up time.
3. Ensure the alarm ON/OFF switch (usually a small lever or button on the side or back) is in the 'ON' position.

Using the Light

- Press and hold the button located on the top of the clock to illuminate the dial for temporary viewing in the dark. Release the button to turn off the light.

Turning Off the Alarm

- When the alarm sounds, move the alarm ON/OFF switch to the 'OFF' position to silence it. The alarm will reset for the next 24-hour cycle at the set time.

MAINTENANCE

Cleaning

- Wipe the clock's exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.

Battery Replacement

- Replace the battery when the clock begins to lose time or the alarm weakens. Follow the battery installation steps outlined in the 'Setup' section.
- Always dispose of old batteries responsibly according to local regulations.

TROUBLESHOOTING

Clock Not Keeping Accurate Time

- Ensure the battery is fresh and correctly installed. A weak battery can affect timekeeping accuracy.
- Verify that the time setting knob is not accidentally nudged.

Alarm Not Sounding

- Check that the alarm ON/OFF switch is in the 'ON' position.
- Confirm that the alarm hand is correctly set to the desired wake-up time.
- Ensure the battery has sufficient power.

SPECIFICATIONS

Brand	Westclox
Model Number	47550
Color	Black
Display Type	Analog
Movement Type	Quartz
Power Source	Battery Powered (1 C battery required)
Material	Metal (Bell), Plastic (Frame)
Product Dimensions	6.75 x 5 x 4 inches
Item Weight	6.4 ounces

WARRANTY INFORMATION

This Westclox Bell Ringer II Quartz Analog Alarm Clock comes with a**1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims.

For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact the manufacturer directly.

CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please refer to the contact information provided by your retailer or visit the official Westclox website for support resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B00013K77M>

More documents and user manuals: <https://manuals.plus/>