

Andis 04710

Andis 04710 Professional T-Outliner Beard & Hair Trimmer User Manual

INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Andis 04710 Professional T-Outliner Beard & Hair Trimmer. Designed for crisp, clean lines, dry-shaving, and sharp edges with zero overlap blades, this corded electric trimmer is suitable for various grooming needs. Please read all instructions carefully before operation.








Image: The Andis 04710 Professional T-Outliner Beard & Hair Trimmer, a gray corded electric trimmer with a carbon steel T-blade.

SAFETY INFORMATION

WARNING: Read and follow all safety instructions before use. This appliance is intended for professional use. Always ensure the trimmer is unplugged before cleaning or maintenance. Do not immerse the trimmer in water. Keep out of reach of children.

SETUP

1. **Unpack:** Carefully remove the trimmer and all accessories from the packaging.
2. **Inspect:** Check the trimmer for any signs of damage. Ensure the carbon steel T-blade is securely attached and free from defects.
3. **Lubricate Blades:** Before first use, apply a few drops of clipper oil to the blades. (Refer to the Maintenance section for detailed lubrication instructions).
4. **Power Connection:** Plug the 8-foot heavy-duty cord into a suitable electrical outlet (120V, 60Hz).



Image: The Andis T-Outliner Trimmer and its accessories, including the power cord and oil, neatly arranged in its packaging.

OPERATING INSTRUCTIONS

The Andis 04710 T-Outliner is designed for precise grooming tasks. Its high-torque rotary motor ensures consistent performance for dry and wet hair.

1. **Turning On/Off:** Locate the power switch on the side of the trimmer. Slide the switch to the 'ON' position to activate the trimmer and to the 'OFF' position to turn it off.
2. **Hairline Trimming:** For crisp, clean lines and sharp edges, hold the T-blade flat against the skin and move it slowly against the direction of hair growth. The zero-overlap blades provide a super-close shave without causing razor bumps or irritation.
3. **Beard and Mustache Trimming:** Use the trimmer to shape and maintain beards and mustaches. For best results, trim against the grain of the hair.
4. **Dry Shaving:** The bump-free technology with diamond-finished T-blades allows for dry trimming, providing a close shave without the need for shaving cream.



Image: A barber using the Andis T-Outliner to precisely trim a man's hairline, demonstrating its use for sharp edges.



Image: A barber using the Andis T-Outliner to trim the side of a man's head, showcasing its versatility for hair grooming.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Andis T-Outliner.

- **Cleaning Blades:** After each use, brush off any loose hair from the blades. You can also unscrew the blade assembly to thoroughly clean underneath with a brush or alcohol.
- **Lubrication:** Apply a few drops of clipper oil to the blades before and after each use. This reduces friction, keeps the blades sharp, and prevents pulling or snagging of hair.
- **Blade Remounting:** If you remove the blade for cleaning, fit the mounting hook into the blade mounting on the trimmer and push in until you hear a click.



Image: A diagram illustrating the proper steps for lubricating the trimmer blades by applying oil to specific points and remounting the blade assembly.

TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the power cord is securely plugged into a working electrical outlet.

Check the power switch is in the 'ON' position.

- **Blades pulling hair:** This often indicates dull blades or insufficient lubrication. Clean and oil the blades. If the problem persists, consider replacing the blades.
- **Excessive noise or vibration:** Ensure the blade assembly is correctly mounted and tightened. Lubricate the blades. If the issue continues, contact customer support.

SPECIFICATIONS

Brand Name	Andis
Model Number	04710
Product Dimensions	1.75 x 1.5 x 5.25 inches
Item Weight	11.2 Ounces
Blade Material	Stainless Steel (Carbon Steel T-Blade)
Material Type	Alloy Steel
Power Source	Corded Electric
Cord Length	8-foot heavy-duty cord
Color	Gray
Recommended Uses	Beard, Dry Shaving, Edging, Light Shaping, Outlining
Hair Type	All

WARRANTY

This product comes with a one-year limited warranty. Please refer to the insert included in the packaging for additional information regarding warranty terms and conditions.

SUPPORT

For customer support, please refer to the contact number provided in your product packaging or visit the official Andis website: www.andis.com.