

**Remington 5012314100760**

# Remington F7027 Foot Spa User Manual

Model: 5012314100760

## 1. IMPORTANT SAFETY INSTRUCTIONS

---

Please read all instructions carefully before using the Remington F7027 Foot Spa. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance immediately after use and before cleaning.
- Do not use while bathing or showering.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not immerse in water or other liquid.
- Never use if the appliance has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Keep the cord away from heated surfaces.
- This appliance is for household use only.
- Consult your doctor before using if you have any medical conditions, including diabetes, heart disease, or circulatory problems.

## 2. PRODUCT OVERVIEW

---

The Remington F7027 Foot Spa is designed to provide a relaxing and invigorating foot massage experience. It features various functions to soothe tired feet.



**Figure 1:** The Remington F7027 Foot Spa. This image shows the compact design of the foot spa, highlighting its main basin and control panel area.

## Key Components:

- **Water Basin:** Holds water for soaking.
- **Control Panel:** For selecting functions (e.g., heat, massage, bubbles).
- **Massage Rollers/Nodes:** Integrated for foot massage.
- **Splash Guard:** Prevents water from splashing out.
- **Power Cord:** For connecting to an electrical outlet.

## 3. SETUP INSTRUCTIONS

---

Follow these steps to prepare your foot spa for use:

1. **Placement:** Place the foot spa on a flat, stable, and waterproof surface. Ensure it is near an electrical outlet and away from any items that could be damaged by water.
2. **Fill with Water:** Fill the foot spa with warm or cool water up to the indicated maximum fill line. Do not overfill. You may add a small amount of foot spa salts or essential oils if desired, ensuring they are compatible with the unit.
3. **Connect Power:** Ensure your hands are dry, then plug the power cord into a standard electrical outlet.

## 4. OPERATING INSTRUCTIONS

---

Once set up, you can begin your foot spa experience:

1. **Power On:** Press the power button on the control panel to turn on the foot spa.
2. **Select Functions:** Use the control panel to select your desired functions. Options may include:
  - **Heat:** Activates the water heating element to maintain water temperature.
  - **Bubbles:** Generates soothing bubbles for a gentle massage.
  - **Vibration:** Provides a vibrating massage sensation.
3. **Immerse Feet:** Carefully place your feet into the water basin.
4. **Enjoy:** Relax and enjoy the foot spa for up to 20-30 minutes. Avoid using for excessively long periods.
5. **Power Off:** After use, press the power button to turn off the foot spa.
6. **Unplug:** Unplug the appliance from the electrical outlet.

## 5. MAINTENANCE AND CLEANING

---

Regular cleaning ensures hygiene and prolongs the life of your foot spa:

1. **Drain Water:** After unplugging, carefully pour out the water from the basin. Use the designated pouring spout if available.
2. **Clean Basin:** Wipe the interior of the basin with a soft cloth and a mild, non-abrasive cleaner. Rinse thoroughly with clean water.
3. **Exterior Cleaning:** Wipe the exterior of the unit with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
4. **Drying:** Allow all parts to air dry completely before storing.

5. **Storage:** Store the foot spa in a cool, dry place, away from direct sunlight. Do not wrap the power cord tightly around the unit.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Remington F7027 Foot Spa, refer to the following common problems and solutions:

- **Unit does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the outlet is receiving power (test with another appliance).
- **No bubbles or weak bubbles:**
  - Ensure the bubble function is selected on the control panel.
  - Check if the air vents are clear of debris or blockages.
- **Water is not heating or not warm enough:**
  - Confirm the heat function is activated.
  - Note that the foot spa is designed to maintain warm water, not to rapidly heat cold water. Start with warm water for best results.

If problems persist, please contact customer support.

## 7. SPECIFICATIONS

---

- **Model Number:** 5012314100760
- **Dimensions (approx.):** 50 x 40.2 x 23.8 cm (L x W x H)
- **Weight (approx.):** 4.64 kg
- **Power Supply:** 220-240V ~ 50/60Hz (Typical for EU models, verify on product label)
- **Manufacturer:** Varta Consumer Batteries GmbH & Co. KGaA

## 8. WARRANTY AND SUPPORT

---

The Remington F7027 Foot Spa comes with a manufacturer's warranty. Please refer to the warranty card included with your product for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts, or warranty claims, please contact Remington customer service. Contact information can typically be found on the Remington website or on the product packaging.