

[Manuals.plus](#) /

› [Possini Euro Design](#) /

› Possini Euro Design Modern Ceiling Light Flush Mount Fixture Instruction Manual

Possini Euro Design 29206

Possini Euro Design Ceiling Light Instruction Manual

Model: 29206

1. PRODUCT OVERVIEW

This manual provides instructions for the installation, operation, and maintenance of your Possini Euro Design Modern Ceiling Light Flush Mount Fixture. This fixture features a brushed nickel finish, metal construction, and a marbled glass shade, designed to enhance various indoor spaces.



Figure 1: Front view of the Possini Euro Design Modern Ceiling Light, showcasing its brushed nickel finish and marbled glass shade.



Figure 2: The ceiling light fixture installed in a modern living room setting, illuminating the space and complementing the decor.

2. SAFETY INFORMATION

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be fatal or cause property damage.

- Always disconnect power at the main circuit breaker before installation or maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- Ensure all electrical connections comply with local codes and ordinances.
- Do not exceed the maximum wattage specified for the bulbs.
- Handle glass components with care to prevent breakage.
- This fixture is designed for indoor use only.

3. PACKAGE CONTENTS

Carefully unpack your fixture and check that all parts are included. Keep the packaging materials until you are sure all parts are present and the fixture is working correctly.

- Ceiling Light Fixture Assembly (Brushed Nickel Metal Frame)
- Marbleized Glass Shade
- Mounting Hardware (screws, wire nuts, mounting bracket)
- Instruction Manual

Note: Bulbs are not included. This fixture requires three E26 base bulbs, maximum 60 watts each.

4. SPECIFICATIONS

Feature	Detail
Model Number	29206
Dimensions	16 3/4" (42.5 cm) Wide x 5 3/4" (14.6 cm) High
Ceiling Canopy Width	12 1/4" (31.1 cm)
Weight	8 lbs (3.6 kg)
Bulb Type	E26 Standard-Medium Base (3 bulbs required, not included)
Max Wattage per Bulb	60 Watts
Voltage	120 Volts
Material	Metal, Marbleized Glass
Finish	Brushed Nickel
Installation Type	Flush Mount
Indoor/Outdoor Use	Indoor Only



Figure 3: Detailed dimensions of the ceiling light fixture, including overall width, height, and canopy width for installation planning.

5. SETUP AND INSTALLATION

Before You Begin:

- Turn off power at the circuit breaker or fuse box.
- Ensure the mounting surface is structurally sound to support the fixture's weight.
- Gather necessary tools: screwdriver, wire strippers, electrical tape, safety glasses.

Installation Steps:

1. **Attach Mounting Bracket:** Secure the mounting bracket to the electrical junction box in the ceiling using the provided screws. Ensure the bracket is firmly attached.
2. **Make Electrical Connections:**
 - Connect the fixture's black wire to the house's black (hot) wire using a wire nut.
 - Connect the fixture's white wire to the house's white (neutral) wire using a wire nut.
 - Connect the fixture's ground wire to the house's ground wire (bare copper or green) and to the mounting bracket using a ground screw.
 - Carefully tuck all wires into the junction box.
3. **Mount the Fixture:** Align the fixture's base with the mounting bracket and secure it with the provided screws. Ensure the fixture is flush against the ceiling.
4. **Install Bulbs:** Screw three E26 base bulbs (max 60W each) into the sockets. Do not overtighten.
5. **Attach Glass Shade:** Carefully place the marbled glass shade onto the fixture and secure it according to the design (e.g., by twisting or using retaining clips/screws).



Figure 4: The ceiling light fixture securely mounted and flush against the ceiling, demonstrating a completed installation.

6. OPERATING INSTRUCTIONS

Once installed, the Possini Euro Design Ceiling Light operates like any standard ceiling fixture. It is controlled by a wall switch (not included) connected to the electrical circuit.

- **Turning On/Off:** Use the wall switch connected to the fixture to turn the light on or off.
- **Bulb Replacement:** To replace bulbs, ensure the power is off at the circuit breaker. Allow bulbs to cool before touching. Unscrew old bulbs and screw in new E26 base bulbs (max 60W).

The fixture is designed for simple, reliable operation.

7. MAINTENANCE AND CARE

Regular cleaning will help maintain the appearance and performance of your light fixture.

- **Cleaning:** Always turn off the power and allow the fixture to cool before cleaning. Wipe the metal parts with a soft, dry cloth. For the glass shade, use a mild glass cleaner and a soft cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Inspection:** Periodically check all electrical connections and mounting hardware to ensure they remain secure.

8. TROUBLESHOOTING

If your fixture is not operating correctly, consult the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb.	Check circuit breaker. Verify all wire connections are secure (with power off). Replace bulb.
Light flickers.	Loose bulb. Incorrect bulb type/wattage. Loose wire connection.	Tighten bulb. Ensure bulbs are E26, max 60W. Check wire connections (with power off).
Glass shade is loose.	Shade not properly secured.	Re-secure the glass shade according to installation steps.

If problems persist, contact a qualified electrician or the manufacturer's support.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation provided at the time of purchase or contact Possini Euro Design directly. Keep your proof of purchase for any warranty claims.

For technical support or replacement parts, please visit the [Possini Euro Design Store on Amazon](#) or contact Lamps Plus, the vendor for this product.

Product Video:

Your browser does not support the video tag.

Video: Possini Euro Design Brand Overview. This video showcases various lighting products and design philosophies from Possini Euro Design, providing a general overview of the brand's style and offerings.

© 2024 Possini Euro Design. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question