

WOLF Garten 1814000

Wolf-Garten EAM 1814000 Seed Planter Instruction Manual

1. PRODUCT OVERVIEW

The Wolf-Garten EAM 1814000 Seed Planter is a specialized gardening tool designed to facilitate precise and uniform seed planting in rows. This tool is part of the Wolf-Garten gardening collection, known for its quality and ergonomic design.

Key features include:

- Creates uniform spacing for planting seeds in rows.
- Compatible with various seed sizes, up to the size of a pea.
- Designed for ergonomic use when paired with a compatible long handle (sold separately), promoting comfortable, stand-up-straight operation.
- Durable construction for reliable performance.

2. SAFETY INFORMATION

Always handle gardening tools with care. Keep the seed planter clean and free from debris to ensure proper function. Store the tool in a dry, secure location away from children and pets. Ensure any attached handles are securely fastened before use.

3. PACKAGE CONTENTS

The Wolf-Garten EAM 1814000 Seed Planter package includes:

- 1 x Wolf-Garten EAM 1814000 Seed Planter head.

Note: A compatible long handle, such as the ZMA150 garden tool handle, is required for stand-up operation and is sold separately.

4. ASSEMBLY AND SETUP

The EAM 1814000 Seed Planter is designed to be used with a compatible Wolf-Garten Multi-Star handle. Follow these steps to prepare your tool for use:

1. Select a suitable Wolf-Garten Multi-Star handle (e.g., ZMA150).
2. Align the connection point of the seed planter head with the end of the handle.
3. Push the planter head onto the handle until it clicks securely into place. Ensure the connection is firm and there is no wobbling.
4. To detach, press the release button on the handle and pull the planter head off.



Image: The Wolf-Garten EAM 1814000 Seed Planter attached to a long handle, dispensing seeds into a garden row. Visible are small green seeds (likely peas) being planted with uniform spacing in tilled soil, with lettuce plants in the background.

5. OPERATING INSTRUCTIONS

The seed planter is designed for efficient and precise seed distribution. Follow these steps for optimal results:

1. **Prepare the Soil:** Ensure your garden bed is properly tilled and prepared for planting, with a shallow

furrow created for the seeds.

2. **Load Seeds:** Open the seed compartment on the planter head and fill it with your desired seeds. The planter is designed for seeds up to the size of a pea.
3. **Adjust for Seed Size:** The planter features an adjustment mechanism to accommodate different seed sizes. Rotate the dial or lever to the appropriate setting for your specific seed type to ensure proper dispensing.
4. **Begin Planting:** Place the planter head into the prepared furrow. Gently push the tool forward along the row. The mechanism will automatically dispense seeds at uniform intervals as you move.
5. **Cover Seeds:** After planting, gently cover the seeds with soil according to the specific requirements of your seed type.

For best results, maintain a consistent pace while moving the planter to ensure even spacing.

6. MAINTENANCE AND STORAGE

Proper maintenance ensures the longevity and performance of your seed planter:

- **Cleaning:** After each use, remove any remaining seeds and soil debris from the planter head. A soft brush or cloth can be used. Ensure the dispensing mechanism is clear.
- **Drying:** Allow the tool to dry completely before storage to prevent rust or corrosion.
- **Storage:** Store the seed planter in a dry, protected area, away from extreme temperatures and moisture. Detaching the head from the handle for storage is recommended if space is limited.

7. TROUBLESHOOTING

Issue: Uneven seed dispersal or seeds getting caught.

Solution:

- Verify that the seed size is compatible with the planter (up to pea size). Larger seeds like corn or beans may not dispense correctly and can cause blockages.
- Check the seed compartment and dispensing mechanism for any blockages from debris or clumped seeds. Clean thoroughly.
- Ensure the seed size adjustment is set correctly for the seeds being used.
- Maintain a consistent and steady pace while operating the planter. Jerky movements can affect dispersal.

Issue: Planter head detaches from handle during use.

Solution:

- Ensure the planter head is fully engaged with the handle until it clicks into place.
- Inspect the handle's connection mechanism and the planter head's receiver for any damage or wear. Replace components if necessary.

8. SPECIFICATIONS

Specification	Detail
Brand	WOLF Garten
Model Number	1814000

Material Feature	Naturbelassen
Color	Red
Indoor/Outdoor Usage	Outdoor
Included Components	Seed Sower (head only)
Manufacturer	Wolf Garten

9. WARRANTY AND SUPPORT

The Wolf-Garten EAM 1814000 Seed Planter is manufactured in Germany and comes with a **10-year warranty**, reflecting its quality and durability.

For warranty claims, technical support, or further assistance, please refer to the contact information provided with your purchase or visit the official Wolf-Garten website.