

[Manuals.plus](#) /

› [Hasbro Gaming](#) /

› Hasbro Whac-A-Mole Game Instruction Manual

Hasbro Gaming 40509

Hasbro Whac-A-Mole Game Instruction Manual

Model: 40509 | Brand: Hasbro Gaming

PRODUCT OVERVIEW

The Hasbro Whac-A-Mole Game brings the classic carnival fun right into your home. This electronic game challenges players to whack moles as they pop up, guided by lights and sounds. Designed for engaging play, it offers multiple modes for solo or group enjoyment.



Figure 1: Front view of the Hasbro Whac-A-Mole Game packaging.

Key Features:

- Features 4 interactive moles with distinct personalities.
- Moles light up and provide sound cues to indicate when to whack.
- Electronic talking Mole guides gameplay and keeps score.
- Supports solo play or competitive play for 2 to 4 players.
- Includes the main game unit and 4 mallets.

WHAT'S IN THE BOX

Your Hasbro Whac-A-Mole Game package should contain the following items:

- 1 x Whac-A-Mole Game Unit
- 4 x Mallets

- Instruction Manual (English and Spanish)

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 4 years of age.

Adult supervision is recommended during play. Ensure all components are used as intended to prevent injury.

SETUP

1. Battery Installation:

The Whac-A-Mole Game Unit requires 3 AA batteries (not included). To install:

1. Locate the battery compartment on the underside of the game unit.
2. Using a Phillips head screwdriver, open the battery compartment cover.
3. Insert 3 AA batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the battery compartment cover and secure it with the screw.

2. Prepare for Play:

Place the game unit on a flat, stable surface. Distribute the four mallets among the players.

OPERATING INSTRUCTIONS

Game Modes:

The game offers various modes to suit different play styles and skill levels:

- **Solo Mode:** Play by yourself to practice your whacking skills and aim for a high score.
- **Multi-Player Mode (2 or 4 players):** Compete against friends or family.
- **Easy Mode:** Moles will light up and make sounds, providing both visual and auditory cues for when to whack.
- **Hard Mode:** Moles will only provide sound cues, requiring players to listen carefully.

How to Play:

1. Turn on the game unit using the power switch.
2. Select your desired game mode using the mode selector switch.
3. Listen for the electronic talking mole to begin the game.
4. When a mole lights up (Easy Mode) or makes its unique sound (Hard Mode), quickly whack it on the head with your mallet.
5. The electronic mole will keep score. Whack up to 100 points to win multi-player games.

Grab a mallet and take a whack!

Listen for the right sound
Look for the light
Whack that mole on the head
And you will win! ALL RIGHT!



Figure 2: Children engaging in multi-player gameplay, demonstrating the use of mallets.

MAINTENANCE

To ensure the longevity of your Hasbro Whac-A-Mole Game:

- **Cleaning:** Wipe the game unit and mallets with a soft, dry cloth. Do not immerse in water or use harsh cleaning agents.
- **Storage:** Store the game in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** Remove batteries if the game will not be used for an extended period to prevent leakage.

TROUBLESHOOTING

If you encounter issues with your Whac-A-Mole Game, consider the following:

- **Game not turning on:** Ensure batteries are correctly installed and are not depleted. Replace with fresh AA batteries

if necessary.

- **Moles not popping up or lighting:** Check battery levels. Ensure no obstructions are preventing mole movement.
- **Sound issues:** Verify the volume switch (if present) is not set to mute or lowest setting.

If problems persist, please refer to the Warranty and Support section.

SPECIFICATIONS

Feature	Detail
Product Dimensions	4.1 x 10.6 x 10.6 inches
Item Weight	1.88 pounds
Model Number	40509
Manufacturer Recommended Age	4 years and up
Batteries Required	3 AA batteries (not included)
Manufacturer	Hasbro Gaming
ASIN	B0001GDP00

WARRANTY AND SUPPORT

For warranty information or technical support regarding your Hasbro Whac-A-Mole Game, please contact Hasbro Gaming customer service. Refer to the contact details provided on the product packaging or visit the official Hasbro Gaming website for the most up-to-date support information.

Please retain your purchase receipt for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question