

[manuals.plus](#) /

› [KETTLER](#) /

› [KETTLER Palma 4-Position Folding Chair Instruction Manual](#)

KETTLER Palma

KETTLER Palma 4-Position Folding Chair Instruction Manual

Model: 740/W

INTRODUCTION

Thank you for choosing the KETTLER Palma 4-Position Folding Chair. This manual provides essential information for the safe and proper use, maintenance, and care of your new outdoor chair. Please read these instructions carefully before use and retain them for future reference.



Image: The KETTLER Palma 4-Position Folding Chair in its upright position, showcasing its snow-white finish and slatted design.

SETUP

The KETTLER Palma 4-Position Folding Chair arrives fully assembled and ready for immediate use. No additional tools or assembly steps are required.

1. Carefully remove the chair from its packaging.

2. Unfold the chair by gently pulling the seat and backrest apart until it locks into the upright position. Ensure all locking mechanisms are engaged before sitting.

3. Place the chair on a stable, level surface.



Image: Two KETTLER Palma chairs placed in an outdoor garden setting, ready for use.

OPERATING INSTRUCTIONS

Adjusting Recline Positions

The KETTLER Palma chair features a 4-position reclining backrest for personalized comfort. To adjust the recline:

1. While seated, slightly lift your weight off the backrest.
2. Gently push the backrest forward to disengage the locking mechanism.
3. Lean back to the desired position. The backrest will click into one of the four available positions.
4. Ensure the backrest is securely locked in place before fully leaning back.



Image: Side view of the chair in its most upright position.



Image: Side view of the chair in a slightly reclined position.



Image: Side view of the chair in a more reclined position.

Folding and Storage

To fold the chair for compact storage or transport:

1. Ensure the backrest is in the most upright position.
2. Stand in front of the chair and grasp the front edge of the seat.
3. Lift the seat upwards while simultaneously pushing the backrest forward. The chair will collapse into a flat, compact form.
4. Store the folded chair in a dry, protected area.



Image: Side view of the KETTLER Palma chair in its folded, compact state for storage.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your KETTLER Palma chair.

- **Cleaning:** Wipe clean with a damp cloth and mild soap. Avoid abrasive cleaners or harsh chemicals, as these can damage the resin material. Rinse thoroughly with water and dry completely.

- Storage:** When not in use for extended periods, especially during harsh weather conditions (e.g., extreme cold, heavy rain, direct prolonged sunlight), it is recommended to store the chair indoors or cover it with a protective outdoor furniture cover.
- Inspection:** Periodically check all moving parts and connections to ensure they are secure.

TROUBLESHOOTING

If you encounter any issues with your KETTLER Palma chair, refer to the following common solutions:

- Difficulty Adjusting Recline:** Ensure you are slightly lifting your weight off the backrest before attempting to adjust. The mechanism requires a slight forward push to disengage.
- Difficulty Folding:** Make sure the backrest is in the most upright position. Apply even pressure when lifting the seat and pushing the backrest forward. Do not force the mechanism.
- Chair Feels Unstable:** Verify that the chair is placed on a flat, level surface. Check that all parts are fully extended and locked into position.

SPECIFICATIONS

| Feature | Detail |
|--------------------------------|-----------------------------|
| Brand | KETTLER |
| Model Name | Palma |
| Item Model Number | 740/W |
| Color | Snow-white |
| Material | High-impact Resin (Plastic) |
| Product Dimensions (D x W x H) | 26.4" x 24.4" x 41.4" |
| Seat Height | 16.5" (approx.) |
| Item Weight | 11.22 pounds |
| Maximum Weight Recommendation | 260 Pounds |
| Recline Positions | 4 |
| Foldable | Yes |
| Indoor/Outdoor Usage | Outdoor |
| Care Instructions | Wipe Clean |




Image: Technical diagram illustrating the key dimensions of the KETTLER Palma chair.

WARRANTY AND SUPPORT

For warranty information or technical support, please contact KETTLER customer service directly. Details can typically be found on the KETTLER official website or through your purchase documentation. Please have your model number (740/W) and proof of purchase available when contacting support.

© 2025 KETTLER. All rights reserved.

Related Documents - Palma



[Kettler Palma Low Lounge Fire Pit Table Assembly Instructions](#)

Comprehensive assembly, operation, safety, and maintenance guide for the Kettler Palma Low Lounge Fire Pit Table (Model 0193393-3310/5510).

| | |
|---|---|
|  <p>KETTLER HOI RIDE+ COMPUTER HOI TOUR COMPUTER HOI CROSS+ COMPUTER</p> <p>Montageanleitung Montagekit, kein elektr. Montagekit für elektr. Manuel de montage - FRANÇAIS</p> | <p><u>KETTLER HOI Computer Bedienungsanleitung: HOI Ride+, Tour, Cross+</u> Umfassende Bedienungsanleitung für den KETTLER HOI Trainingscomputer, einschließlich HOI Ride+, HOI Tour und HOI Cross+. Erfahren Sie mehr über Funktionen, Modi und Konnektivität.</p> |
|  <p>KETTLER Montageanleitung - STRATOS GT Elegance* Art.-Nr. 7969-300</p> <p>Montageanleitung Montagekit, kein elektr. Montagekit für elektr. Manuel de montage - FRANÇAIS</p> | <p><u>KETTLER STRATOS GT Elegance 7969-300 Montageanleitung</u> Umfassende Montageanleitung für den KETTLER STRATOS GT Elegance Heimtrainer (Art.-Nr. 7969-300). Enthält wichtige Sicherheitshinweise, Gebrauchsanweisungen und Wartungsinformationen für ein sicheres und effektives Training.</p> |
|  <p>KETTLER 3.3m LED Free Arm Parasol PLD33</p> <p>Montageanleitung Montagekit, kein elektr. Montagekit für elektr. Manuel de montage - FRANÇAIS</p> | <p><u>KETTLER 3.3m LED Free Arm Parasol (PLD33) Assembly and User Guide</u> Comprehensive assembly instructions, operating guide, and safety information for the KETTLER 3.3m LED Free Arm Parasol (Model PLD33), including details on its wireless speaker and LED lighting.</p> |
|  <p>KETTLER Cora Rope Lounge Armchair HUC23887</p> <p>Montageanleitung Montagekit, kein elektr. Montagekit für elektr. Manuel de montage - FRANÇAIS</p> | <p><u>Kettler Garden Furniture Assembly and Care Guide: Armchair, Sofa, Coffee Table</u> Comprehensive assembly instructions, parts lists, maintenance tips, and safety information for Kettler Cora Rope Lounge Armchair, Cora Rope 2 Seat Sofa, and Cora Coffee Table 90cm. Learn how to care for your Kettler outdoor furniture.</p> |
|  <p>KETTLER Navodila za sestavo in uporabo</p> <p>Montageanleitung Montagekit, kein elektr. Montagekit für elektr. Manuel de montage - FRANÇAIS</p> <p>Art.-Nr. KTM1000-100</p> <p>SL KETTLER ALPHA RUN 400</p> | <p><u>Kettler Alpha Run 400: Navodila za Sestavo, Uporabo in Vzdrževanje</u> Celovit priročnik za tekalno stezo Kettler Alpha Run 400, ki vključuje navodila za sestavo, varno uporabo, vzdrževanje, odpravljanje težav in garancijo.</p> |