

## **RAYMOND WEIL 4875-STC-00209**

# **Raymond Weil 4875-STC-00209 Automatic Chronograph Watch User Manual**

Your guide to understanding and operating your timepiece.

## **1. INTRODUCTION**

Thank you for choosing a Raymond Weil timepiece. This manual provides essential information for the proper setup, operation, and maintenance of your Raymond Weil 4875-STC-00209 automatic chronograph watch. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

## **2. PRODUCT OVERVIEW**

The Raymond Weil 4875-STC-00209 is an elegant automatic chronograph watch featuring a stainless steel case, a black dial with Roman numerals, and a brown leather strap. It includes a chronograph function and a calendar display at the 12 o'clock position. The watch is equipped with a curved sapphire crystal for enhanced durability and a transparent caseback that showcases its intricate automatic movement.



Figure 1: Front view of the Raymond Weil 4875-STC-00209 watch. This image displays the watch's black dial with Roman numeral hour markers, three chronograph sub-dials, and the date window at 12 o'clock. The watch is fitted with a brown leather strap.



Figure 2: Rear view of the Raymond Weil 4875-STC-00209 watch. This image highlights the transparent caseback, allowing visibility of the automatic mechanical movement. The brown leather strap with its buckle is also visible.

### 3. SETUP

---

#### 3.1. Initial Winding

Your Raymond Weil 4875-STC-00209 is an automatic watch, meaning it is powered by the motion of your

wrist. However, for initial setup or if the watch has stopped due to lack of wear, it requires manual winding:

1. Ensure the crown (located on the side of the watch) is in its normal, pushed-in position.
2. Turn the crown clockwise approximately 20-30 times. This will provide enough power reserve to start the watch.
3. Once worn, the natural motion of your arm will keep the watch wound.

### 3.2. Setting the Time

To set the time on your watch:

1. Pull the crown out to the outermost position (position 3). The seconds hand will stop.
2. Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time.
3. Push the crown back into its normal position (position 1) to restart the watch.

### 3.3. Setting the Date

To set the date:

1. Pull the crown out to the middle position (position 2).
2. Turn the crown clockwise to advance the date. Avoid setting the date between 9 PM and 3 AM, as this is when the date change mechanism is engaged and could cause damage.
3. Once the correct date is displayed, push the crown back into its normal position (position 1).

## 4. OPERATING THE CHRONOGRAPH

---

Your watch features a chronograph function for measuring elapsed time. It is operated by two pushers located on the side of the case, typically above and below the crown.

1. **Start:** Press the top pusher to start the chronograph. The central chronograph seconds hand will begin to move.
2. **Stop:** Press the top pusher again to stop the chronograph. The elapsed time will be indicated by the central chronograph seconds hand and the chronograph sub-dials (typically for minutes and hours).
3. **Reset:** After stopping the chronograph, press the bottom pusher to reset all chronograph hands to their zero positions.

*Note:* Avoid operating the chronograph pushers underwater to prevent water ingress.

## 5. MAINTENANCE

---

### 5.1. Water Resistance

Your Raymond Weil 4875-STC-00209 watch has a water resistance rating of 30 meters (100 feet). This rating means the watch is suitable for everyday use and can withstand splashes or brief immersion in water. It is **not** suitable for swimming, showering, or diving. Always ensure the crown is fully pushed in before any contact with water.

### 5.2. Cleaning

To maintain the appearance of your watch:

- Wipe the case and crystal with a soft, dry cloth.
- For the leather strap, avoid prolonged exposure to water, direct sunlight, and harsh chemicals to prevent damage and discoloration.

### 5.3. Storage

When not wearing your watch for an extended period, store it in a cool, dry place, away from direct sunlight and strong magnetic fields, which can affect the accuracy of the automatic movement.

## 6. TROUBLESHOOTING

If you encounter issues with your watch, consider the following:

- **Watch not running:** Ensure the watch is sufficiently wound. If it has been stationary, manually wind it as described in Section 3.1.
- **Inaccurate time:** Exposure to strong magnetic fields can affect accuracy. If you suspect this, consult an authorized service center.
- **Date not changing:** Check if the date is being set during the prohibited hours (9 PM - 3 AM). Adjust the time past 3 AM before setting the date.

For persistent issues, please contact an authorized Raymond Weil service center.

## 7. SPECIFICATIONS

Feature	Detail
Model Number	4875-STC-00209
Movement	Automatic
Case Material	Stainless Steel
Dial Color	Black
Strap Material	Brown Leather
Crystal	Curved Sapphire
Case Diameter	44mm
Water Resistance	30m / 100ft
Product Dimensions	6.3 x 4.53 x 10.24 inches
Item Weight	2.11 Pounds
Manufacturer	Raymond Weil
ASIN	B0002FQHO6

## 8. WARRANTY AND SUPPORT

Your Raymond Weil watch is covered by a manufacturer's warranty against defects in materials and

workmanship. For specific warranty terms, registration, and to locate an authorized service center, please refer to the official Raymond Weil website or the warranty card included with your purchase. For any support inquiries, it is recommended to contact Raymond Weil customer service directly.

© 2024 Raymond Weil. All rights reserved.