

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Microsoft](#) /

> [Microsoft Optical Desktop Elite for Bluetooth User Manual](#)

Microsoft Optical Desktop Elite

Microsoft Optical Desktop Elite for Bluetooth User Manual

Model: Optical Desktop Elite

INTRODUCTION

The Microsoft Optical Desktop Elite for Bluetooth provides a wireless keyboard and mouse solution designed for use with Windows PCs. This combo utilizes Bluetooth wireless technology for connectivity, offering enhanced range and reliability. It enables synchronization and information sharing between your PC and other Bluetooth-enabled devices.

WHAT'S IN THE BOX

- Microsoft Bluetooth Keyboard
- Microsoft Bluetooth Optical Mouse
- USB Bluetooth Transceiver
- Batteries (pre-installed or included separately)
- Product Documentation



Image: The retail packaging for the Microsoft Optical Desktop Elite for Bluetooth, showing the keyboard, mouse, and USB transceiver.

SETUP

1. Install Batteries

Ensure fresh batteries are installed in both the keyboard and the mouse. Refer to the battery compartment markings for correct polarity.

2. Connect USB Transceiver

Plug the included USB Bluetooth transceiver into an available USB port on your Windows PC. The system will typically install the necessary drivers automatically.



Image: A blue USB Bluetooth transceiver plugged into the side of a laptop computer.

3. Pair Devices

Follow the on-screen prompts or refer to your Windows Bluetooth settings to pair the keyboard and mouse with the transceiver. This usually involves pressing a connect button on the devices and the transceiver.

4. Install Software (Optional)

For advanced customization of keyboard shortcuts and mouse buttons, install the Microsoft IntelliPoint and IntelliType Pro software from the official Microsoft website or the included CD (if applicable).

OPERATING INSTRUCTIONS

The Microsoft Optical Desktop Elite for Bluetooth offers a range of features for enhanced productivity.



Image: The Microsoft Optical Desktop Elite keyboard and mouse, showcasing their ergonomic design and wireless nature.

Keyboard Features:

- **Standard QWERTY Layout:** Full-size keyboard with a standard QWERTY layout.
- **Programmable Hot Keys:** Utilize the customizable hot keys for quick access to applications, documents, or web pages.
- **Media Controls:** Dedicated keys for volume control, play/pause, and track navigation.
- **Side-to-Side Scrolling:** The keyboard features a scroll wheel or button for horizontal scrolling in documents and web pages.

Mouse Features:

- **Optical Tracking:** Provides precise and smooth cursor control on various surfaces.
- **Scroll Wheel:** For vertical scrolling and button functionality.
- **Side-to-Side Scrolling:** The mouse scroll wheel also supports horizontal scrolling.
- **Programmable Buttons:** Customize side buttons for specific functions using the IntelliPoint software.
- **Longer Battery Life:** Designed for extended use between battery replacements.



Image: A detailed diagram highlighting various features and buttons on the Microsoft Optical Desktop Elite keyboard and mouse.

MAINTENANCE

Cleaning:

- **Keyboard:** Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid excessive moisture.
- **Mouse:** Clean the optical sensor area on the bottom of the mouse with a dry cotton swab. Wipe the body with a soft, damp cloth.
- Do not immerse devices in liquid.

Battery Replacement:

- When battery indicators on the keyboard or mouse signal low power, replace batteries promptly.
- Open the battery compartment, remove old batteries, and insert new ones, ensuring correct polarity.
- Dispose of old batteries according to local regulations.

TROUBLESHOOTING

Devices not connecting or frequently disconnecting:

- Ensure the USB Bluetooth transceiver is securely plugged into a working USB port.
- Check battery levels in both the keyboard and mouse. Replace if low.

- Re-pair the devices with the transceiver. Refer to the "Pair Devices" step in the Setup section.
- Ensure no other strong wireless signals (e.g., Wi-Fi routers, other Bluetooth devices) are causing interference. Try moving the transceiver closer to the devices.
- Restart your computer.

Mouse cursor is erratic or unresponsive:

- Clean the optical sensor on the bottom of the mouse.
- Ensure you are using the mouse on a suitable surface. Highly reflective or transparent surfaces may cause issues.
- Check battery levels.

Keyboard keys are not responding:

- Check battery levels.
- Ensure the keyboard is paired correctly.
- Verify that the keyboard is not in a sleep mode. Press any key to wake it.

Side-to-side scrolling not working:

- Ensure the IntelliPoint/IntelliType Pro software is installed and configured correctly.
- Verify that the application you are using supports horizontal scrolling.

SPECIFICATIONS

Feature	Detail
Brand	Microsoft
Model	Optical Desktop Elite for Bluetooth
Connectivity Technology	Bluetooth, USB, Wireless
Compatible Devices	Personal Computer (Windows OS)
Movement Detection	Optical (Mouse)
Keyboard Layout	QWERTY (105 Keys)
Power Source	Battery Powered
Item Weight	4 Pounds (approx.)
Color	Black/Blue

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your product or visit the official Microsoft support website. Keep your proof of purchase for warranty claims.

Online Support: support.microsoft.com

