

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Fissler](#) /

› Fissler Magic Can Opener Instruction Manual - Model 020 081 18 000

Fissler 020 081 18 000

Fissler Magic Can Opener Instruction Manual

Model: 020 081 18 000

Brand: Fissler

INTRODUCTION

The Fissler Magic Can Opener is a high-quality kitchen accessory designed for effortless and safe can opening. Crafted from hygienic 18/10 stainless steel, it features a smooth-edge cutting mechanism that eliminates sharp edges on opened cans and lids. Its classic design and durable construction ensure long-lasting performance and easy care.

Key Features:

- High-quality stainless steel construction.
- Beautiful brushed stainless steel finish.
- Mirrored hanging loops for convenient storage.
- Dishwasher-safe for easy cleaning.
- Smooth-edge cutting mechanism for safety.
- Limited lifetime warranty against defects.



Image: Fissler Magic Can Opener, showcasing its ergonomic design and stainless steel finish.

SETUP

The Fissler Magic Can Opener requires no assembly. Before first use, wash the can opener with warm soapy water and rinse thoroughly. Dry completely before storing or using.

OPERATING INSTRUCTIONS

1. Positioning the Can Opener:

Place the can opener on top of the can, aligning the cutting wheel with the outer rim of the can's lid. The can opener is designed to cut along the side seam of the lid, not into the top surface.

2. Engaging the Mechanism:

Turn the handle clockwise to engage the cutting wheel. You will feel the mechanism grip the can. Continue turning the handle smoothly around the entire circumference of the can until the lid is fully separated from the can body.

3. Removing the Lid:

Once the cutting is complete, turn the handle counter-clockwise slightly to release the can opener from the can. The can opener features a small gripper that can be used to safely lift the lid off the can without touching the edges. Simply position the gripper onto the lid and lift.

Important Notes:

- The smooth-edge design ensures no sharp edges are left on the can or the lid, making it safe to handle.
- The lid may appear to be still attached after cutting; gently lift it to confirm separation.
- Avoid forcing the mechanism if it feels stuck; re-adjust the can opener's position.

MAINTENANCE & CARE

- **Cleaning:** The Fissler Magic Can Opener is dishwasher-safe. For best results, rinse immediately after use to remove any food particles.
- **Storage:** Store in a dry place. The mirrored hanging loops allow for convenient storage on a kitchen hook.
- **Longevity:** Made from durable 18/10 stainless steel, this can opener is built to last. Regular cleaning and proper storage will ensure its continued performance.

TROUBLESHOOTING

Can Opener Not Engaging:

Ensure the cutting wheel is properly aligned with the can's outer rim. Apply firm, but not excessive, pressure while turning the handle to engage the cutting mechanism.

Lid Not Separating Cleanly:

Make sure you have completed a full 360-degree turn around the can. Sometimes, a second pass may be necessary for very thick or unusually shaped can rims. Use the lid lifter to gently pry the lid if it remains slightly attached.

Difficulty Turning Handle:

If the handle is difficult to turn, the can opener might be misaligned or the can's rim could be damaged. Remove the can opener, inspect the can, and re-position the opener carefully.

SPECIFICATIONS

Feature	Detail
Brand	Fissler
Model Number	020 081 18 000
Material	18/10 Stainless Steel

Feature	Detail
Color	Stainless Steel
Operation Mode	Manual
Product Dimensions	1.2"W x 9.3"H
Item Weight	4.9 ounces (0.14 Kilograms)
GTIN	04009209256153
ASIN	B0002TSF10

WARRANTY & SUPPORT

Limited Lifetime Warranty:

The Fissler Magic Can Opener comes with a limited lifetime warranty against manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support:

For further assistance, product inquiries, or warranty claims, please visit the official Fissler website or contact their customer service department.

Fissler Store: [Visit the Fissler Store on Amazon](#)