

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Scholl](#) /

› [Dr. Scholl's DR6624 Toe-Touch Foot Spa User Manual](#)

## Scholl DR6624

# Dr. Scholl's DR6624 Toe-Touch Foot Spa User Manual

Model: DR6624

## INTRODUCTION

This user manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Dr. Scholl's DR6624 Toe-Touch Foot Spa. Please read this manual thoroughly before using the appliance and retain it for future reference.

The Dr. Scholl's DR6624 Toe-Touch Foot Spa is designed to provide a soothing and invigorating foot massage experience. It features a smart heat function to maintain water temperature, a massaging action to soothe tired feet, and refreshing bubbles. The unit includes waterproof toe-touch controls for convenient, hands-free operation, an accunode textured basin, three stationary massage attachments, a splash guard hood, and a removable reflexology foot roller attachment.

## IMPORTANT SAFETY INFORMATION

### **WARNING: To reduce the risk of burns, fire, electric shock, or injury to persons:**

- Always unplug the appliance from the electrical outlet immediately after using and before cleaning.
- Do not use while bathing or showering.
- Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- An appliance should never be left unattended when plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair.
- Keep the cord away from heated surfaces.

- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep air openings free of lint, hair, and the like.
- Never use while sleeping or drowsy.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not operate under a blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons.
- Do not carry this appliance by supply cord or use cord as a handle.
- To disconnect, turn all controls to the "OFF" position, then remove plug from outlet.
- This appliance is designed for household use only.

## PRODUCT FEATURES

---

- **Smart Heat Feature:** Maintains water temperature for a consistently warm foot spa experience.
- **Massaging Action:** Soothes tired feet with gentle vibrations.
- **Invigorating Bubbles:** Refreshes and revitalizes feet.
- **Waterproof Toe-Touch Controls:** Allows for easy, hands-free operation.
- **Accunode Textured Basin:** Provides additional massage points for the soles of your feet.
- **3 Stationary Massage Attachments:** Integrated massage nodes for targeted relief.
- **Splash Guard Hood:** Prevents water from splashing out during use.
- **Removable Reflexology Foot Roller Attachment:** For focused massage on specific foot areas.

## PACKAGE CONTENTS

---

Upon opening the package, please ensure all components are present and undamaged:

- Dr. Scholl's DR6624 Toe-Touch Foot Spa Unit
- Integrated 3 Stationary Massage Attachments
- Removable Reflexology Foot Roller Attachment
- User Manual (this document)



Image: The Dr. Scholl's DR6624 Toe-Touch Foot Spa as packaged in its retail box. The image displays the foot spa unit, emphasizing its heat, bubbles, and massage capabilities. The box also features two individuals running, suggesting active lifestyles that benefit from foot care.

## SETUP

1. **Placement:** Place the foot spa on a firm, level surface. Ensure the area is clear and there is no risk of tripping over the power cord.
2. **Filling:** Fill the foot spa with warm water up to the indicated fill line. Do not overfill. You may add foot bath salts or essential oils designed for foot spas, following their specific instructions.
3. **Attachments:** If desired, place the removable reflexology foot roller attachment into its designated slot in the basin. The three stationary massage attachments are integrated into the basin.
4. **Power Connection:** Ensure your hands are dry. Plug the power cord into a standard electrical outlet (120V AC).

## OPERATING INSTRUCTIONS

1. **Power On:** Once plugged in and filled with water, gently place your feet into the foot spa. Use your toe to press the power button located on the control panel.
2. **Select Mode:** The toe-touch controls allow you to select different modes:
  - **Bubbles:** Press the bubble button to activate the invigorating bubble action.
  - **Massage:** Press the massage button to activate the soothing vibration massage.
  - **Heat:** The smart heat feature will automatically work to maintain the water temperature. There is no separate heat button to press.
  - You can combine bubbles and massage for a comprehensive experience.
3. **Using Attachments:**
  - For the integrated stationary massage attachments, simply rest your feet on them to experience targeted massage.
  - For the removable reflexology foot roller, gently roll your feet back and forth over it to stimulate pressure points.
4. **Duration:** Use the foot spa for a comfortable duration, typically 15-30 minutes.
5. **Power Off:** When finished, use your toe to press the power button again to turn off the unit. Remove your feet from the spa.

## MAINTENANCE AND CLEANING

1. **Draining:** After each use, unplug the unit. Carefully pour out the water from the foot spa, preferably over a sink or drain.
2. **Cleaning:** Wipe down the basin and exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or harsh chemicals. For stubborn residue, a mild soap solution can be used.
3. **Rinsing:** Rinse the basin thoroughly with clean water to remove any soap residue.
4. **Drying:** Allow the foot spa to air dry completely before storing. Ensure no water remains in the unit.
5. **Storage:** Store the foot spa in a cool, dry place, away from direct sunlight and moisture. Do not wrap the power cord around the unit tightly, as this can damage the cord.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power outlet not active; unit damaged.	Ensure power cord is securely plugged into a working outlet. Test the outlet with another appliance. If still not working, contact customer support.
No bubbles or massage.	Mode not selected; unit malfunction.	Ensure the correct toe-touch button for bubbles or massage has been pressed. If still no function, ensure unit is powered on.
Water is not warm or does not stay warm.	Initial water temperature too low; smart heat feature malfunction.	Start with warm water. The smart heat feature maintains temperature, it does not heat cold water. If water cools significantly, contact customer support.

Problem	Possible Cause	Solution
Excessive splashing.	Overfilled; vigorous movement.	Ensure water is filled only to the indicated fill line. Avoid vigorous movement of feet during operation. The hood acts as a splash guard.

## SPECIFICATIONS

---

- **Model:** DR6624
- **Brand:** Scholl
- **ASIN:** B0002U2YL6
- **Units:** 1.0 Count
- **Power:** Standard Household AC (Voltage not specified, typically 120V for US products)
- **Features:** Smart Heat, Bubbles, Massage, Toe-Touch Controls, Accunode Basin, 3 Stationary Massage Attachments, Removable Reflexology Foot Roller, Splash Guard Hood.

## WARRANTY AND SUPPORT

---

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included with your purchase or visit the official Dr. Scholl's website. Please have your model number (DR6624) and ASIN (B0002U2YL6) ready when contacting support.

No official product videos from the seller were available for embedding in this manual.