

Logitech X-530

Logitech X-530 5.1 Speaker System User Manual

Model: X-530 (P/N: 970114-0403)

1. INTRODUCTION

The Logitech X-530 5.1 Speaker System is designed to deliver immersive, consistent surround sound for your games, movies, and music. Featuring a powerful subwoofer for distortion-free bass and five satellite speakers utilizing Logitech's patented FDD2 technology, this system ensures a clear, uniform sound field without the 'hot spots' often found in conventional dual-driver designs. Enjoy dynamic audio with dedicated controls for master volume and subwoofer level.

2. PACKAGE CONTENTS

Before you begin, please ensure all components are present in your package:

- One Subwoofer
- Five Satellite Speakers (four for front/rear, one for center channel)
- Audio Cables (color-coded for easy connection)
- Power Cable



This image displays the complete Logitech X-530 5.1 Speaker System, featuring a central subwoofer unit, four tall satellite speakers, and one horizontal center channel speaker. All components are black with silver speaker cones, designed for a comprehensive surround sound experience.

3. SETUP

3.1 Speaker Placement

Optimal speaker placement is crucial for the best 5.1 surround sound experience:

1. **Front Left and Right Satellites:** Place these speakers equidistant from your listening position, on either side of your monitor or TV.
2. **Center Channel Satellite:** Position this speaker directly in front of you, typically above or below your monitor/TV, ensuring dialogue is clear and intelligible.
3. **Rear Left and Right Satellites:** Place these speakers behind your listening position, ideally at ear level, to create an enveloping surround sound field. Satellite speaker stands rotate for easy wall mounting.
4. **Subwoofer:** The subwoofer can be placed on the floor, preferably in a corner or near a wall, to enhance bass response. Experiment with placement to find the best sound for your room.

3.2 Connections

Follow these steps to connect your speaker system:

1. **Connect Satellite Speakers to Subwoofer:** Plug the color-coded cables from each satellite speaker into the corresponding jacks on the back of the subwoofer. Ensure the front, rear, and center speakers are connected to their correct ports.

2. **Connect Subwoofer to Audio Source:** Use the provided audio cables to connect the subwoofer to your PC, music player, DVD player, or game console. The system supports 5.1 channel input for true surround sound. Ensure your audio source (e.g., sound card) is configured for 5.1 output.
3. **Connect Power:** Plug the power cable into the subwoofer and then into a standard electrical outlet.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

The power switch is conveniently located on the right front satellite speaker. Press it to turn the system on or off.

4.2 Volume Control

- **Master Volume:** Adjust the overall system volume using the large knob on the right front satellite speaker.
- **Subwoofer Level:** Control the bass intensity using the dedicated subwoofer level knob, also located on the right front satellite speaker.

4.3 Headphone Jack

For private listening, plug your headphones into the headphone jack located on the right front satellite speaker. This will automatically mute the speakers.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Logitech X-530 speaker system, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the speaker surfaces. Avoid using abrasive cleaners or solvents, as they may damage the finish.
- **Ventilation:** Ensure the subwoofer and satellite speakers have adequate ventilation. Do not block any vents or place the speakers in enclosed spaces that could lead to overheating.
- **Cable Management:** Keep cables tidy and untangled to prevent damage and ensure a clean setup. Avoid placing heavy objects on cables.
- **Environment:** Keep the speakers away from excessive moisture, direct sunlight, and extreme temperatures.

6. TROUBLESHOOTING

If you encounter issues with your speaker system, refer to the following common problems and solutions:

- **No Sound:**

- Ensure the power cable is securely plugged into both the subwoofer and a working electrical outlet.
- Verify the system is powered on (power indicator light should be on).
- Check that all audio cables are correctly connected from the subwoofer to your audio source and from the satellites to the subwoofer.
- Increase the master volume on the speaker system and on your audio source (PC, DVD player, etc.).
- If using headphones, unplug them from the headphone jack.

- **Distorted or Unclear Sound:**

- Reduce the master volume or the volume on your audio source.
- Check for loose cable connections.
- Ensure the audio source is not sending an overdriven signal.

- **Uneven Sound or Missing Channels:**

- Confirm that your audio source is configured for 5.1 surround sound output.
- Verify that each satellite speaker is connected to its correct, color-coded port on the subwoofer.
- Test each channel individually if your sound card software allows.

- **Weak or No Bass:**

- Increase the subwoofer level using its dedicated control knob.
- Ensure the subwoofer is properly connected.
- Adjust the subwoofer's placement in the room; sometimes moving it closer to a wall or corner can enhance bass.

7. SPECIFICATIONS

Brand	Logitech
Model Name	X-530
Speaker Type	Satellite, Subwoofer
Special Feature	Subwoofer
Recommended Uses For Product	Volume
Compatible Devices	Projector, Laptop, MP3 Player, Television, Desktop, Tablet, Smartphone
Surround Sound Channel Configuration	5.1
Color	Black
Included Components	Five satellite speakers, one center channel, one subwoofer

Product Dimensions	14"D x 16.8"W x 13"H
Item Weight	17 Pounds
Is Waterproof	FALSE
Warranty Type	Limited
Number of Items	1
Control Method	Touch
Speaker Size	5.25 Inches
Power Source	Corded Electric
Signal-to-Noise Ratio	99 dB
Woofer Diameter	5.25 Inches
Specific Uses For Product	Gaming
UPC	097855021656
Speaker Maximum Output Power	70 Watts
Connectivity Technology	Wired
Audio Output Mode	Surround
Mounting Type	Wall Mount

8. WARRANTY INFORMATION

The Logitech X-530 5.1 Speaker System comes with a limited warranty. Please refer to the warranty card included with your product or visit the official Logitech website for detailed terms and conditions regarding warranty coverage, duration, and claims procedures.

9. SUPPORT

For further assistance, technical support, or to access additional resources, please visit the official Logitech support website or contact Logitech customer service. You can find contact information and FAQs on their website.



[Logitech X-530 5.1 Speaker Repair Guide: Fixing Popping and Static Noise](#)

A step-by-step guide to troubleshoot and repair the Logitech X-530 5.1 speaker system, addressing common issues like popping and static noise by modifying the internal wiring.

lang:en score:34 filesize: 2.21 M page_count: 11 document date: 2016-01-23



[\[pdf\] Installation Guide Instructions Guide](#)

Setup Installation Instalación Logitech® X 530 Logitech آرمانيكا Armanica Thank you for purchasing the speaker system from Your speakers are easy to use Read these instructions Keep and produce great sound To discover more products or if have questions about your visit us on web at logitech 1 Subwoofer 2 Rear right — black plug 3 left yellow 4 x530 installation guide armanica ir image data product 80 Setup Installation Instalacin Logitech **X-530** IMPORTANT SAFETY INFORMATION CAUTION ELECTRIC SHOCK HAZARD Safety Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions. Unplug the speakers from the computer and from the electrical outlet before cleaning...


lang:en score:34 filesize: 121.82 K page_count: 4 document date: 2014-07-12



[\[pdf\] User Manual Installation Guide Instructions](#)

x530 Manual AMR indd g ecx images amazon Setup Installation Instalación Logitech® X 530 Thank you for purchasing the speaker system from Logitech Your speakers are easy to use and produce great sound To discover more products or if have questions about your visit us on itech @ sp eaker 2 English Safety 1 Read these instructions Keep Heed all warnings web at logitech Subwoofer Rear right — black plug 3 left yellow 4 B000FKP2VW 689b1eaa 9aac 4a9e 9989 08a25092cdf0 G 30 CE Electronica Manuals eu ssl stream manualsonline 6 Setup Installation Instalacin Logitech **X-530** IMPORTANT SAFETY INFORMATION CAUTION ELECTRIC SHOCK HAZARD Safety Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions. Unplug the speakers from the computer and from the electrical outlet before cleaning...

lang:en score:30 filesize: 333.6 K page_count: 10 document date: 2005-05-06



[pdf] Guide

038 067 Home Ent 03 06 indd Yamaha YST SW315 Subwoofer 250 Watt User guide 1209425 archive org manualzz id

38 HOME ENTERTAINMENT HOME THEATER SYSTEMS 800.947.1185

212.444.6685 813 HOME QUICK ENTERTAINMENT DIAL DAV-FX10 5.1 Home

Theater DVD Dream System Five-disc, slot-loading DVD/CD/SA-CD 1,000 total watts of power 6 speaker system Sony s Precision Cinema Progressive circuitry S-Master Digita...

lang:en score:14 filesize: 4.18 M page_count: 30 document date: 2006-01-23



[pdf] Instructions Documentation Declaration of Conformity

Microsoft Word Couverture notice1 page doc IS97410 MARQUE LOGITECH REFERENCE HP 5 1 X530

CODIC 1122509 NOTCOMP fc darty notices DOCUMENTATION |||

MARQUE: LOGITECH REFERENCE : HP 5.1 X530 CODIC: 1122509 Setup

Installation Instalacin Logitech **X-530** Scurit CONSIGNES DE SCURIT

IMPORTANTES ATTENTION RISQUE D ELECTROCUTION Veuillez lire ces

instructions. Conservez ces instructions. Tenez compte de tous les avertissements.

Suivez toutes ...

lang:fr score:14 filesize: 190.89 K page_count: 5 document date: 2009-12-29



[pdf] Specifications Datasheet Warranty

Microsoft Office User MK540 ADVANCED WIRELESS KEYBOARD AND MOUSE COMBO mk540

advanced wireless combo data sheet logitech content dam en business |||

MK540 ADVANCED WIRELESS KEYBOARD AND MOUSE COMBO WIRELESS MOUSE AND KEYBOARD COMBO A wireless keyboard and ambidextrous mouse that deliver familiarity, precision, and comfort for your users--and reliable plug-and-play capabilities for IT. IDEAL FOR Those who want more advanced features in a combo ...

lang:en score:14 filesize: 140.53 K page_count: 2 document date: 2021-06-23

[illegible][illegible]

Video control on the Z311 speaker does **work** when headsets are connected. When you have headsets connected to the Z311 speaker's control port, you'll need to use the source device (smartphone, tablet, computer, etc.) connected to the volume.

Windows 8 and Windows 10 support for Logitech speakers

Updated: 02/24/2015 05:29 PM

If you purchased your product before the Windows 8 release, you can check the list below to see if it's been identified to work with Windows 8 and Windows 10.

NOTE: To check support for other Logitech products, see answer [24423](#).

What if my product isn't listed?

If your product isn't listed and you want to purchase it:

- BEFORE the Windows 8 release:** The product isn't supported on Windows 8 or Windows 10.
- AFTER the Windows 8 release:** Check the product's Support page. Downloads tab for certain software support.
- TIP:** For newer product support, check the product packaging and web page.

Speakers that work with Windows 8 and Windows 10

NOTES:

- Audio USB products use drivers that are native to modern Windows operating systems, enabling them to functionally without additional drivers.
- The products marketed in analog form only, or a combination of 3.5 mm audio connectors, Analog RCA, or FireWire/Thunderbolt I/O ports. For these devices, Windows 8/10 OS support depends on power source and port functionality.
- Bluetooth connection requires a Bluetooth controller on the host device.

[Logitech MK545 Advanced Wireless Keyboard and Mouse Combo - Product Specifications](#)

Explore the Logitech MK545 Advanced Wireless Keyboard and Mouse Combo, featuring a comfortable, full-size keyboard with spill-resistant design and a precision mouse with customizable buttons. This combo offers reliable plug-and-play connectivity and long battery life, ideal for enhanced productivity.

lang:en score:13 filesize: 138.19 K page count: 2 document date: 2021-06-23

[\[pdf\]](#) Documentation

Logitech Reach webcam 1920 x 1080 pixels USB C Graphite Feb 21 2025 · Marque 190 530 mm 4050 g
Résolution vidéo maximale 529583476 secomp fr media xcont 577 91 3 |||

Logitech Reach webcam 1920 x 1080 pixels USB-C Graphite Marque : Logitech Nom
du produit : Reach Code produit: 960-001684 Full HD, 300 x 550 mm / 70 x 130 mm,
f2.0, 3.7 mm, FoV 78, 0.915 m, 550 x 190 x 530 mm, 4050 g Logitech Reach.

Resolution video maximale: 1920 x 1080 pixels, Type HD de la caméra...

lang:en score:12 filesize: 112.37 K page count: 2 document date: 2025-02-21



[Computer Shopper Magazine: Your Guide to PC Shopping and Tech Reviews - January 2007](#)

The January 2007 issue of Computer Shopper magazine offers comprehensive guides on buying PCs, notebooks, and components, along with reviews of the latest technology, software, and accessories from leading brands like Dell, HP, Intel, AMD, and Apple.

lang:en score:11 filesize: 42.18 M page_count: 132 document date: 2017-10-19



[\[pdf\] Installation Guide Instructions](#)

5ddaaff12d159 notice facile file 2019 11 |||

Setup Installation Instalacin Logitech **X-530** IMPORTANT SAFETY INFORMATION CAUTION ELECTRIC SHOCK HAZARD Safety Read these instructions. Keep these instructions. Heed all warnings. Follow all instructions. Unplug the speakers from the computer and from the electrical outlet before cleaning...

lang:en score:11 filesize: 337.1 K page_count: 10 document date: 2005-08-20



[Productos de alta calidad para el hogar y el entretenimiento](#)

Descubra una amplia gama de productos de alta calidad, desde electrónica y artículos para el hogar hasta juguetes y accesorios para niños. Encuentre las últimas novedades y ofertas.

lang:de score:11 filesize: 1.88 M page_count: 33 document date: 2019-03-01

FAQ - Stereo Speakers Z120


Using both connections with the Z120 speakers

Your Stereo Speaker Z120 comes with two attached cables:

• USB cable

• 3.5mm auxiliary cable

The USB cable is used only to supply power to the speakers. The 3.5mm auxiliary cable is for audio. Both cables need to be connected to use the speaker's 3+2+1 Hz design.



Windows 8 and Windows 10 product support and device compatibility

If you purchased your product before the Windows 8 release, you can check the list below to see if it's been identified to work with Windows 8 or Windows 10.

NOTE: To check support for other Logitech products, see answer [388001348136](#).

What if my product isn't listed?

If your product isn't listed and you purchased it:

• BEFORE the Windows 8 release - The product isn't supported on Windows 8 or Windows 10.

• AFTER the Windows 8 release - Check the product's support page > Downloads tab for current software.

TIP: For more product support, check the product packaging and web pages.

Speakers that work with Windows 8 and Windows 10

NOTE:

[pdf] Frequently Asked Questions Accessories

Rajaraman Dhanu FAQ Logitech Z120 Compact PC Stereo Speakers 3 5mm Audio Input USB Powered Integrated Controls Cable Management Solution Computer Smartphone Tablet Music Player White Black Amazon co uk Computers Accessories 81ZI4vDeVXL m media amazon images I |||

FAQ - Stereo Speakers Z120 Using both connections with the Z120 speakers Your Stereo Speaker Z120 co ... es X-140 Speakers S-0264A Analog Yes Yes X-240 2.1 Speaker System S-0285A Analog Yes Yes **X-530** 5.1 Speaker System S-0114A Analog Yes Yes X-540 5.1 Speaker System S-0223A Analog Yes ...

lang:en score:11 filesize: 487.23 K page_count: 3 document date: 2021-04-26