

Step2 754300

Step2 Naturally Playful Playhouse Climber and Swing Set Extension

Model: 754300

Brand: Step2

INTRODUCTION

The Step2 Naturally Playful Playhouse Climber and Swing Set Extension is designed to provide a versatile outdoor play experience for children. This playset features a roomy upper deck with a balcony railing, a 5.5-foot slide, and a secret playhouse below. It also includes two strap swings, offering multiple activities in one compact unit.

This product is constructed from durable, double-wall plastic, engineered for long-term outdoor use and easy maintenance. The design promotes physical development, including strength, coordination, balance, and confidence, while the integrated playhouse encourages imaginative and cooperative play.

SAFETY INFORMATION

Important Safety Warnings:

- **CHOKING HAZARD:** Contains small parts. Adult assembly is required.
- **Age Recommendation:** Suitable for children aged 3 to 8 years.
- **Weight Capacity:** The climber has a maximum weight capacity of 250 lbs. Each swing has a maximum weight capacity of 75 lbs.
- **Ground Anchors:** Two strap swings include ground anchors. Ensure these are properly installed to secure the playset.
- **Supervision:** Always supervise children during play to prevent accidents.



SIGNATURE EVERTOUGH PLASTIC IS FADE, WEATHER AND TEMPERATURE RESISTANT

Safe Zone Requirement: This playset requires a safe zone of 484 square feet for proper and safe operation. Ensure adequate clear space around the entire playset.

INCLUDED COMPONENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Two-story climber with door
- Two strap swings
- Slide
- A-frame support
- Ground anchors



Playset Components: An overview of all parts included in the Step2 Naturally Playful Playhouse Climber and Swing Set Extension, laid out for inspection prior to assembly.

SETUP AND ASSEMBLY

Assembly of the Step2 Naturally Playful Playhouse Climber and Swing Set Extension is required. This process should be undertaken by adults. Follow the provided visual instructions carefully. While the playset includes basic tools, a personal hex nut and ratchet set with a longer extension piece may facilitate easier and more secure assembly.

Assembly Tips:

- When attaching the slide, it may be necessary to tip the base of the playset back approximately 30 degrees to allow the slide to slip into place. Ensure the grooves on the slide align with the base.
- If attaching the swing set to the playhouse section, do not install the red top piece on the playhouse until the swing set pole is in place, as it may need to be removed later.
- Pay close attention to the orientation of the metal swing set pole. The round holes should face UP and the oval holes should face DOWN. Incorrect installation will require partial disassembly.
- Securely install all ground anchors to ensure the stability of the swing set.

OPERATING INSTRUCTIONS

The Step2 Naturally Playful Playhouse Climber and Swing Set Extension offers multiple play areas for children aged 3 to 8 years. Encourage children to explore each feature safely.

Climber and Slide

Children can access the upper deck via the integrated ladder. The ladder features sturdy steps designed for small hands and feet. Once on the upper deck, children can use the 5.5-foot slide to descend. The slide is designed for a smooth and safe ride.



Climbing the Ladder: A child demonstrates climbing the playset's ladder, which leads to the upper deck and slide.



Two Levels of Play: The playset features two distinct levels for varied play, including climbing to the upper deck.

Swings

The playset includes two strap swings. Ensure children are seated properly and hold onto the chains securely while swinging. Always ensure the area around the swings is clear before use.



Enjoying the Swings: Two children using the strap swings, demonstrating proper seating and grip.

Secret Playhouse

Below the main deck is a secret playhouse with a functional door and crawl-through portals. This area is ideal for imaginative games and provides a shaded space for children to interact.



Exiting the Playhouse: A child emerges from the playset's secret playhouse, highlighting the functional door.



Inside the Playhouse: A child enjoys the enclosed space of the secret playhouse, visible through an archway.

SAFE ZONE:



REQUIRES 484 SQUARE FEET

Interactive Playhouse: Two children engaging with each other through the playhouse windows, demonstrating the multi-level interaction.

MAINTENANCE

The Step2 Naturally Playful Playhouse Climber and Swing Set Extension is designed for low maintenance. The double-wall plastic construction is resistant to weather and fading, and its molded-in color will not chip, crack, or peel.

- **Cleaning:** Wipe surfaces clean with a damp cloth and mild soap as needed. Avoid abrasive cleaners.
- **Inspection:** Periodically inspect all components, especially connections and ground anchors, for wear or damage. Tighten any loose bolts or fasteners.
- **Weather Resistance:** The EverTough plastic material is designed to withstand various weather conditions, ensuring durability and color retention over time.



Weather-Resistant Material: A close-up view of the playset's durable plastic, showing its ability to repel water and resist outdoor elements.



EverTough Plastic: The playset is made from Step2's signature EverTough plastic, known for its resistance to fading, weather, and temperature changes.

SPECIFICATIONS

Feature	Detail
Brand	Step2
Model Number	754300
UPC	733538754397
Material Type	Plastic
Item Dimensions (D x W x H)	31.89" x 56.69" x 38.58"
Item Weight	25.65 Kilograms
Manufacturer Minimum Age	36 Months

Manufacturer Maximum Age	96 Months
Climber Maximum Weight Capacity	250 lbs
Swing Maximum Weight Capacity (each)	75 lbs
Assembly Required	Yes

TROUBLESHOOTING

If you encounter any issues with your playset, please consider the following:

- **Stability Issues:** Ensure all ground anchors are fully installed and secured. Verify that all connections are tight.
- **Missing or Damaged Parts:** Refer to the 'Included Components' section and contact customer support if any parts are missing or damaged upon arrival.
- **Assembly Difficulties:** Review the assembly instructions carefully. If issues persist, contact customer support for assistance.

WARRANTY INFORMATION

The Step2 Naturally Playful Playhouse Climber and Swing Set Extension is covered by a **2 Year Limited Warranty** from the manufacturer. Please retain your proof of purchase for warranty claims. For specific details regarding warranty coverage and procedures, refer to the documentation included with your product or contact Step2 customer support.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues, please contact Step2 Customer Support:

Phone: 1-800-347-8372

Please have your model number (754300) and date of purchase ready when contacting support.