



[Manuals.plus](#) /

> [Cuisinart](#) /

> Cuisinart DLC-005AGTXT1 Replacement Food Processor Work Bowl Instruction Manual

Cuisinart DLC-005AGTX-1

Cuisinart DLC-005AGTXT1 Replacement Food Processor Work Bowl

MODEL: DLC-005AGTX-1

Introduction

This manual provides instructions for the Cuisinart DLC-005AGTXT1 Replacement Food Processor Work Bowl. This work bowl is designed as a direct replacement part for specific Cuisinart food processor models, ensuring continued functionality of your appliance.

Important Compatibility Information

This replacement work bowl (Model DLC-005AGTX-1) is specifically designed for use with Cuisinart DFP-14 food processor models.

Crucially, this work bowl requires the Cuisinart lid model DFP-14NWBCT1 to function correctly. If you do not possess this specific lid, it must be purchased separately (ASIN B015RDQV8O) as this work bowl will not operate without it.

It is also compatible with various Cuisinart DLC-7 series models, including DLC-7, DLC-7E, DLC-7FPC, DLC-7M, DLC-7P, and DLC-7SP.

Verify your existing food processor model and lid compatibility before installation.

Setup and Installation



This image displays the transparent Cuisinart replacement work bowl. It features a gray handle on the right side and a central shaft for blade attachment. A 'Liquid Max Fill' line is visible on the interior base, indicating the maximum liquid capacity.

1. Ensure your food processor is unplugged from the power outlet before beginning installation.
2. Place the replacement work bowl onto the motor base of your Cuisinart food processor. Align the base of the work bowl with the motor base and rotate until it securely locks into position.
3. Once the work bowl is securely in place, you can attach the appropriate blade or disc assembly onto the central shaft.
4. Finally, place the compatible lid (DFP-14NWBCT1) onto the work bowl and rotate it until it locks into place, engaging the safety interlock mechanism.
5. The food processor is now ready for use.

General Operation Guidelines

The work bowl is designed to hold ingredients during food processing. Observe the "Liquid Max Fill" line indicated on the bowl for liquids to prevent overflow.

Always ensure the work bowl and lid are correctly assembled and locked onto the motor base before operating the food processor. The safety interlock prevents operation if components are not properly secured.

Do not overfill the work bowl beyond its capacity to ensure efficient processing and prevent strain on the motor.

Care and Cleaning

Proper cleaning extends the life of your work bowl.

- **Hand Washing:** Wash the work bowl with warm, soapy water. Use a non-abrasive sponge or cloth. Rinse thoroughly and dry completely before storage.
- **Dishwasher Safe:** The work bowl is dishwasher safe. Place it on the top rack for best results. Avoid using harsh detergents that may cause clouding over time.

Ensure all food residues are removed, especially from the handle and locking mechanisms.

Troubleshooting Common Issues

Work Bowl Does Not Lock onto Motor Base:

Ensure the work bowl is correctly aligned with the motor base. Rotate it firmly until it clicks into place. Check for any obstructions on the base or bowl.

Lid Does Not Lock onto Work Bowl:

This work bowl requires lid model DFP-14NWBCT1. If using a different lid, it may not fit. Ensure the lid is properly aligned with the work bowl's locking tabs and rotated until the safety interlock engages. Some older lids may require minor modifications to fit newer bowls, as noted by some users.

Food Processor Does Not Turn On:

Verify that the work bowl and lid are both securely locked into their respective positions. The food processor has a safety interlock system that prevents operation if components are not correctly assembled. Ensure the unit is plugged into a functional power outlet.

Product Specifications

- **Model Number:** DLC-005AGTX-1
- **Brand:** Cuisinart
- **Material:** Polycarbonate (PC)
- **Color:** Multicolor (appears clear)
- **Capacity:** 343 Cubic Inches (approximately 14 cups for DFP-14 models)
- **Item Weight:** 16 ounces
- **Care:** Hand Wash, Dishwasher Safe
- **Compatibility:** Cuisinart DFP-14, DLC-7, DLC-7E, DLC-7FPC, DLC-7M, DLC-7P, DLC-7SP.
Requires lid DFP-14NWBCT1.

Customer Support

For further assistance, replacement parts, or warranty inquiries, please contact Cuisinart customer service. Refer to your original food processor manual for specific contact details or visit the official Cuisinart website for support information.