

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Tupperware](#) /

› [Tupperware Grate 'n Measure Grater Instruction Manual](#)

Tupperware tupperware

Tupperware Grate 'n Measure Grater Instruction Manual

Model: tupperware | Brand: Tupperware

INTRODUCTION

The Tupperware Grate 'n Measure Grater is a versatile kitchen tool designed for efficient grating and precise measurement. Its integrated measuring bin collects grated ingredients directly, minimizing mess and ensuring accuracy for your recipes. This manual provides essential information for the safe and effective use, maintenance, and care of your grater.

SAFETY INFORMATION

- Always handle the stainless steel grater blade with extreme care as it is very sharp.
- Keep fingers away from the grating surface during use.
- Do not allow children to use the grater unsupervised.
- Ensure the grater is stable on a flat surface before beginning to grate.
- This product is **not dishwasher safe**. Hand wash only to preserve its integrity and sharpness.

PARTS IDENTIFICATION

The Tupperware Grate 'n Measure Grater consists of two primary components:

- **Stainless Steel Grater Blade:** The sharp surface used for grating.
- **Measuring Bin with Handle:** The transparent container that collects grated food and features measurement markings up to 2 1/2 cups (600mL). This bin also serves as the base and handle for stability and ease of use.



Image: The Tupperware Grate 'n Measure Grater, highlighting its two main components: the stainless steel grater blade and the translucent measuring bin with an integrated handle. The grater is shown in its assembled state, ready for use.

SETUP

The Tupperware Grate 'n Measure Grater comes pre-assembled and is ready for immediate use after a quick initial cleaning.

- 1. Unpack:** Carefully remove the grater from its packaging.
- 2. Initial Cleaning:** Before first use, disassemble the grater by gently separating the stainless steel blade from the measuring bin. Wash both parts thoroughly with warm, soapy water. Rinse completely and dry.
- 3. Reassemble:** Align the grater blade with the slots on the measuring bin and snap them securely together. Ensure the grater is firmly attached to the bin before use.

OPERATING INSTRUCTIONS

Using your Tupperware Grate 'n Measure Grater is straightforward and efficient:

- 1. Positioning:** Place the grater on a stable, flat surface. The measuring bin acts as a stable base, collecting the grated food directly.
- 2. Grating:** Hold the food item firmly and carefully rub it against the stainless steel grater blade using a downward motion. Apply gentle, even pressure.
- 3. Measuring:** As you grate, the food will fall into the transparent measuring bin. The bin has clear measurement markings (up to 2 1/2 cups or 600mL) on its side, allowing you to accurately measure the quantity of grated ingredients without needing a separate measuring cup.
- 4. Emptying:** Once you have achieved the desired quantity, simply detach the grater blade from the measuring bin. The grated contents can then be easily poured out.



Image: The Tupperware Grate 'n Measure Grater positioned next to small glasses containing various grated ingredients such as cheese, carrots, and chocolate, demonstrating its versatility for different food types.

MAINTENANCE & CLEANING

Proper cleaning and maintenance will ensure the longevity and performance of your Tupperware Grate 'n Measure Grater.

- **Disassembly:** The grater is designed to come apart easily for thorough cleaning. Gently separate the stainless steel grater blade from the measuring bin.
- **Hand Washing:** Wash both components immediately after each use with warm, soapy water. Use a brush to carefully clean the grater blade, avoiding direct contact with the sharp edges.
- **Rinsing:** Rinse all parts thoroughly under running water to remove any soap residue.
- **Drying:** Dry all parts completely before reassembling or storing to prevent water spots and maintain hygiene.
- **Important:** This grater is **not dishwasher safe**. High heat from dishwashers can damage the plastic components and dull the stainless steel blade over time.
- **Storage:** Store the grater in a dry place. Its compact design allows for easy storage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Grater not stable during use.	Not placed on a flat surface; components not fully assembled.	Ensure the grater is on a stable, flat countertop. Verify that the grater blade is securely snapped into the measuring bin.
Difficulty cleaning the blade.	Food particles stuck in grating holes.	Rinse immediately after use. Use a stiff brush (e.g., a vegetable brush) and warm, soapy water to dislodge particles. Avoid using abrasive scrubbers.
Plastic measuring bin appears cloudy or scratched.	Abrasive cleaning materials; dishwasher use.	Always hand wash with a soft sponge or cloth. Avoid harsh chemicals or abrasive cleaners. Do not put in dishwasher.

SPECIFICATIONS

Feature	Detail
Product Name	Tupperware Grate 'n Measure Grater
Model Number	tupperware
Brand	Tupperware
Color	White/Silver (Note: Actual product color may vary, e.g., purple as seen in some images)
Material	Stainless Steel (blade), Plastic (bin)
Product Dimensions (L x W x H)	8.75"L x 4.5"W x 8.75"H (22cm x 11cm x 22cm)
Item Weight	Approximately 9.5 ounces (269 grams)
Measuring Capacity	2 1/2 cups (600mL)
Dishwasher Safe	No (Hand wash recommended)
UPC	696737567420
ASIN	B0006IEVBK



Image: A visual representation of the Tupperware Grate 'n Measure Grater with its key dimensions clearly marked, showing its height, width, and length.

WARRANTY AND SUPPORT

Specific warranty information for the Tupperware Grate 'n Measure Grater is not provided in the product details. For any warranty claims or product support, please refer to the official Tupperware website or contact Tupperware customer service directly. Keep your purchase receipt as proof of purchase.

You can visit the official Tupperware store on Amazon for more information: [Tupperware Amazon Store](#)

OFFICIAL PRODUCT VIDEOS

There are no official product videos from the seller available in the provided product information. Customer-uploaded videos may exist on the product page, but are not included in this manual as per guidelines for official seller content.

