

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Anne Klein](#) /

› Anne Klein Women's Two-Tone Bracelet Watch Model 10/4899SVTT Instruction Manual

Anne Klein 10/4899SVTT

Anne Klein Women's Two-Tone Bracelet Watch Model 10/4899SVTT Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the proper setup, operation, maintenance, and troubleshooting of your Anne Klein Women's Two-Tone Bracelet Watch, Model 10/4899SVTT. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

SETUP

1. Setting the Time

1. **Pull out the crown:** Gently pull the small knob (crown) on the side of the watch case outwards until it clicks.
2. **Adjust the hands:** Rotate the crown in either direction to move the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position to start the watch movement.

2. Adjusting the Bracelet

The bracelet features removable links for size adjustment. For minor adjustments, two extenders are included. For more significant adjustments, it is recommended to consult a professional jeweler to add or remove links to ensure a proper and comfortable fit.



Figure 1: The Anne Klein Women's Two-Tone Bracelet Watch on a wrist, illustrating the fit and style. The image also shows various wrist sizes for reference.

OPERATING INSTRUCTIONS

Your Anne Klein watch is equipped with a reliable quartz movement, providing accurate analog time display. Once the time is set as described in the "Setup" section, the watch will continuously keep time. No further daily adjustments are typically required unless the time needs to be reset due to travel or daylight saving changes.

The watch face features Roman numerals for hour markers, offering a classic aesthetic.





Figure 2: Front view of the Anne Klein Women's Two-Tone Bracelet Watch, highlighting the rectangular case, silver-tone sunray dial, gold-tone hands, and Roman numeral hour markers.

MAINTENANCE

1. Cleaning Your Watch

To maintain the appearance of your watch, wipe it regularly with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

2. Battery Replacement

The watch is powered by one D battery (included). When the watch stops or the time becomes inaccurate, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure proper sealing and water resistance.

3. Water Resistance

This watch is water resistant to 30 meters (99 feet). This means it can withstand splashes or brief immersion in water, such as during hand washing or light rain. It is **not suitable** for swimming, bathing, showering, or any activities involving prolonged water immersion or high-pressure water exposure.



Figure 3: Side view of the Anne Klein Women's Two-Tone Bracelet Watch, illustrating the watch's profile and the position of the crown for time adjustment.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Inaccurate time:** Reset the time as per the "Setting the Time" instructions. If the issue persists, the battery may be low or the movement may require servicing.
- **Bracelet discomfort:** Adjust the bracelet using the removable links or consult a jeweler for professional sizing.

SPECIFICATIONS

Model Number	10/4899SVTT
Case Dimensions	16mm rectangular case
Crystal	Faceted mineral crystal lens
Dial	Silver-tone sunray dial with gold-tone hands and Roman numeral markers
Bracelet	Two-tone open link bracelet with jewelry clasp and two extenders
Inner Band Circumference	7 inches
Movement	Quartz movement with analog display
Water Resistance	30 meters (99 feet) - <i>Not suitable for swimming or bathing.</i>
Battery	1 D battery (included)
Material	Metal
Product Dimensions	5.91 x 5.91 x 5.91 inches; 4.59 ounces





Figure 4: Back view of the Anne Klein Women's Two-Tone Bracelet Watch, detailing the case back and the jewelry clasp mechanism.

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video 1: A closer look at the Anne Klein Women's Two-Tone Bracelet Watch, showcasing its design and features.

WARRANTY AND SUPPORT

For warranty information, product support, or service inquiries, please refer to the documentation included with your purchase or visit the official Anne Klein website. Keep your proof of purchase for any warranty claims.



Figure 5: The Anne Klein watch box, which typically contains warranty information and product documentation.

