

Infantino 203038-09

Infantino 3-in-1 Discovery Seat & Booster Instruction Manual

Model: 203038-09

INTRODUCTION

The Infantino 3-in-1 Discovery Seat & Booster is a versatile product designed to grow with your child, offering three modes of use: a seated positioner, a snack time booster, and a table booster seat. It features engaging activities and a light-up piano to stimulate your child's senses and support development.

Key Features:

- **3-in-1 Versatility:** Functions as a seated positioner, snack time booster, and table booster seat.
- **Interactive Play:** Includes 6 engaging activities and a light-up piano with 20 sounds and songs to support sensory and fine motor skill development.
- **Comfort & Hygiene:** Features a comfortable, washable seat cushion and a removable snack tray with a built-in cup holder.
- **Safety:** Equipped with a secure 3-point harness and security straps for booster mode.

Battery Warnings:

- Batteries must be replaced by an adult.
- Remove all batteries from toys that will not be used for a long period to prevent battery leakage and product damage.
- Do not mix different types of batteries or old, new, and used batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Non-rechargeable batteries must not be recharged.
- Rechargeable batteries must be removed from the toy before charging (if removable).
- Rechargeable batteries must only be charged under the supervision of an adult.
- Batteries must be inserted with correct polarity.
- Exhausted batteries must be removed from the toy.
- Batteries must be recycled or disposed of properly.

NOTE: Inspect the toy before each use and discard if damaged or broken. Remove all plastic packaging fasteners or wires before giving any toy to a child.

SETUP AND ASSEMBLY

The Infantino 3-in-1 Discovery Seat & Booster requires some assembly. Please refer to the detailed assembly instructions included in your product packaging for step-by-step guidance. Ensure all components are securely attached before use.

Unboxing Tips:

- If you cannot find the seat cushion, check between a cardboard divider within the packaging.
- If you cannot find the straps, check beneath the booster seat.



Easy to wipe clean

Image: The Infantino 3-in-1 Discovery Seat & Booster with text overlays providing unboxing tips for locating the seat cushion and straps.

OPERATING INSTRUCTIONS

The Infantino 3-in-1 Discovery Seat & Booster offers three distinct modes to accommodate your child's growth and various activities.

Three Ways to Use:

1. **Seated Positioner:** Use on the floor to provide a secure and engaging space for your baby to sit and play with the interactive toys and light-up piano.
2. **Snack Time Booster:** Attach to a dining chair using the security straps to elevate your child for meal or snack times. The removable tray with a cup holder provides a convenient surface.
3. **Table Booster Seat:** As your child grows, remove the activity tray to use the seat as a simple booster at the table, allowing them to join family meals comfortably.



Image: Visual representation of the three ways to use the Infantino Discovery Seat: as a seated positioner, a snack time booster, and a table booster seat. A close-up of the light-up piano is also shown.

Interactive Play:

The seat includes a removable activity tray with 6 engaging activities and a light-up piano that plays 20 different sounds and songs. Encourage your child to explore the various textures, sounds, and movements to foster their sensory and motor development.

Unboxing Tips

Can't find the seat cushion?

Check between a cardboard divider within the packaging



Can't find the straps?

Check beneath the booster



Image: A baby seated in the Infantino Discovery Seat, engaging with the activity tray, which includes a built-in cup holder and snack tray.

CARE AND MAINTENANCE

Proper care ensures the longevity and hygiene of your Infantino Discovery Seat & Booster.

Cleaning Instructions:

- Clean the seat and tray surfaces only with **sponge or damp cloth**.
- **Do not immerse the product in water.**
- The seat cushion is **washable** for easy cleaning. Refer to the care label on the cushion for specific washing instructions.

Front View



Image: A baby seated in the booster, illustrating the product's ease of cleaning.

TROUBLESHOOTING

If you encounter any issues with your Infantino 3-in-1 Discovery Seat & Booster, please refer to the following common solutions:

- **No Sound/Lights from Piano:** Ensure batteries are correctly installed with the proper polarity and are not depleted. Replace batteries if necessary, following the battery warnings in the Safety Warnings section.
- **Difficulty with Assembly:** Re-check the assembly instructions provided in the packaging. Ensure all parts are aligned correctly and fasteners are tightened. Refer to the "Unboxing Tips" in the Setup section if parts seem missing.
- **Seat Not Secure:** For booster modes, ensure the security straps are properly attached to the adult chair and tightened according to the instructions. Always check for stability before placing your child in the seat.

For further assistance, please contact Infantino customer support.

PRODUCT SPECIFICATIONS

Brand	Infantino
Model Number	203038-09
Color	Multicolored
Material	Plastic
Product Dimensions (Approx.)	19.2" W x 10.5" H x 9.5" D (488 mm W x 267 mm H x 241 mm D)
Age Range (Description)	Children (6 months - 3 years)
Maximum Recommended Weight	15 kg (33 lb)
Portable	Yes
Assembly Required	Yes
UPC	773554030389



Image: Front view of the seat with height and width dimensions.



Image: Top view of the seat with width and depth dimensions.

WARRANTY AND SUPPORT

For information regarding product warranty, please refer to the warranty card included with your purchase or visit the official Infantino website. Infantino is committed to providing high-quality products and customer satisfaction.

If you require technical support, have questions about assembly, or need assistance with any aspect of your Infantino 3-in-1 Discovery Seat & Booster, please contact Infantino customer service through their official website or the contact information provided in your product packaging.

Always ensure you have your product model number (203038-09) and proof of purchase available when contacting support.

© 2023 Infantino. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question