

[Manuals.plus](#) /

› [OttLite](#) /

› OttLite L139AB 13 Watt Desk Lamp User Manual

OttLite L139AB

OttLite L139AB 13 Watt Desk Lamp User Manual

Model: L139AB

INTRODUCTION

Thank you for choosing the OttLite L139AB 13 Watt Desk Lamp. This lamp is designed to provide clear, natural daylight illumination, reducing eyestrain and enhancing visual clarity for various tasks. Its compact and adjustable design makes it suitable for many environments.

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the lamp to ensure safe operation and to prevent injury or damage.

- Do not operate the lamp with a damaged cord or plug.
- Do not use the lamp in wet or damp conditions.
- Always unplug the lamp from the electrical outlet before cleaning or replacing the bulb.
- Keep the lamp away from heat sources and direct sunlight.
- This lamp is for indoor use only.
- Use only the specified OttLite 13-watt replacement bulb (Type E).

PACKAGE CONTENTS

Verify that all components are present in your package:

- OttLite L139AB Desk Lamp Unit
- 13 Watt OttLite Fluorescent Tube (Type E)
- User Manual (this document)

SETUP INSTRUCTIONS

Follow these steps to set up your OttLite L139AB Desk Lamp:

1. **Unpack the Lamp:** Carefully remove all components from the packaging.
2. **Place the Lamp:** Position the lamp on a stable, flat surface. Ensure the base is secure.
3. **Unfold the Lamp:** Gently unfold the lamp arm and shade to the desired position. The lamp is designed to turn on automatically when unfolded past a certain angle.
4. **Connect to Power:** Plug the power cord into a standard electrical outlet.





Figure 1: OttLite L139AB Desk Lamp in open position.



Figure 2: The lamp features a 360-degree swivel base and multi-position shade for optimal light angle adjustment.

OPERATING INSTRUCTIONS

The OttLite L139AB lamp is designed for simple operation:

- **Turning On:** To turn the lamp on, simply unfold the lamp arm and shade. The lamp will illuminate once it reaches an open position (approximately 30 degrees or more from its folded state).
- **Adjusting the Light:** The lamp features a 360-degree swivel base and a multi-position shade. Adjust these components to direct the light precisely where needed. The height can be adjusted from 11.5 inches to 19.5 inches.
- **Turning Off:** To turn the lamp off, fold the lamp arm and shade back into its closed, compact position. There is no separate on/off switch; the lamp's operation is controlled by its folding mechanism.





Figure 3: The lamp folds into a compact design for portability and storage.

MAINTENANCE

Cleaning

Always unplug the lamp before cleaning. Use a soft, dry cloth to wipe down the lamp. Do not use abrasive cleaners or solvents, as these may damage the finish.

Bulb Replacement

The OttLite L139AB uses a 13-watt fluorescent tube (Type E) rated to last up to 10,000 hours. When replacement is needed:

1. **Unplug the Lamp:** Ensure the lamp is unplugged from the power source and has cooled down.
2. **Remove Old Bulb:** Carefully grasp the fluorescent tube and pull it straight out from its socket. Do not twist.
3. **Insert New Bulb:** Align the pins of the new OttLite 13-watt Type E replacement bulb with the slots in the socket. Gently push the bulb straight into the socket until it is secure.
4. **Test:** Plug the lamp back in and test its operation.



Figure 4: OttLite 13-watt Type E replacement bulb.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in. Lamp not fully unfolded. Bulb is loose or faulty. No power from outlet.	Ensure power cord is securely plugged into a working outlet. Fully unfold the lamp arm and shade until it clicks into place. Check if the bulb is properly seated. Replace bulb if necessary. Test the outlet with another appliance.

Problem	Possible Cause	Solution
Light flickers.	Bulb is loose.	Ensure the bulb is securely seated in the socket.
	Bulb is nearing end of life.	Replace the bulb with a new OttLite 13-watt Type E bulb.
Lamp makes buzzing sound.	Loose bulb.	Ensure the bulb is securely seated.
	Internal component issue.	If buzzing persists, discontinue use and contact customer support.

SPECIFICATIONS

Model Number	L139AB
Brand	OttLite
Lamp Type	Desk Lamp
Light Source Type	Fluorescent
Wattage	13 Watts
Bulb Type	Type E (OttLite 13-watt tube)
Bulb Base	E26
Color	Black
Material	Plastic, Metal
Product Dimensions (Folded)	4.25"D x 4.75"W x 10.75"H
Adjustable Height	11.5 inches to 19.5 inches
Base Dimensions	5 inches (diameter, approximate)
Item Weight	2.8 Pounds
Switch Type	Integrated with folding mechanism
Power Source	Corded Electric
Voltage	110 Volts
Special Features	Reduces eyestrain, adjustable lighting, portable design, 360-degree swivel base, multi-position shade.



Figure 5: Product dimensions.

PRODUCT INFORMATION VIDEO

Your browser does not support the video tag.

Video 1: This video demonstrates the OttLite 508 Technology, highlighting how it provides a balanced light for true color and reduced eyestrain. It shows comparisons between standard lighting and OttLite illumination for various tasks like reading and crafting.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official OttLite website or contact their customer service directly. Keep your purchase receipt as proof of purchase.

Online Support: Visit the [OttLite Store on Amazon](#) for more product information and resources.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question