

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Altec Lansing](#) /
- › [Altec Lansing 2.1 Music/Gaming Speakers User Manual](#)

## Altec Lansing VS2221

# Altec Lansing 2.1 Music/Gaming Speakers User Manual

Model: VS2221

## INTRODUCTION

Thank you for choosing the Altec Lansing VS2221 2.1 Music & Gaming Speaker System. This system is designed to provide high-quality audio for your music and gaming experiences, featuring a powerful subwoofer and two satellite speakers for a rich, immersive sound. Its distinctive styling complements any setup, and the SFX Technology enhances the stereo image for a broader soundstage.

This manual provides detailed instructions for setting up, operating, and maintaining your speaker system. Please read it carefully before use to ensure optimal performance and longevity of your product.

## WHAT'S IN THE BOX

Upon unpacking your Altec Lansing VS2221 speaker system, please ensure all the following components are present:

- 1 x Subwoofer
- 2 x Satellite Speakers
- Power Cable (integrated or separate, depending on model revision)
- Audio Input Cable (3.5mm stereo jack)

2PACK



Image: Altec Lansing VS2221 2.1 Speaker System showing the subwoofer and two satellite speakers.

## SETUP

---

1. **Placement:** Position the subwoofer on the floor, preferably near a wall or in a corner for enhanced bass response. Place the satellite speakers on either side of your monitor or listening area, ensuring they are equidistant from your listening position for optimal stereo imaging. The satellites are shielded for use near video monitors.
2. **Connect Satellite Speakers:** Connect the cables from the satellite speakers to the corresponding output jacks on the back of the subwoofer. Ensure a secure connection.
3. **Connect Audio Source:** Connect the 3.5mm audio input cable from the subwoofer to the audio output jack (headphone jack or line-out) of your computer, gaming console, MP3 player, or other audio device.

4. **Connect Power:** Plug the power cable from the subwoofer into a standard AC power outlet.

## OPERATING INSTRUCTIONS

- **Power On/Off:** Locate the power button/switch, typically on one of the satellite speakers or the subwoofer. Press it to turn the system on or off. An indicator light will usually illuminate when the system is powered on.
- **Volume Control:** Adjust the master volume using the dedicated volume knob. Turn clockwise to increase volume and counter-clockwise to decrease.
- **Subwoofer Level:** The subwoofer may have a separate control knob to adjust its bass level independently. Adjust this to your preference for optimal bass response.
- **SFX Technology:** The VS2221 features SFX Technology for a wider stereo image. Locate the SFX switch and toggle it to experience the enhanced soundstage for music and games.

## MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Avoid using liquid cleaners or abrasive materials, as they may damage the finish.
- **Ventilation:** Ensure the subwoofer and satellite speakers have adequate ventilation. Do not block any vents or place the speakers in enclosed spaces that could lead to overheating.
- **Cable Management:** Keep cables tidy and untangled to prevent damage and ensure proper connectivity. Avoid sharp bends or kinks in the cables.
- **Storage:** If storing the speakers for an extended period, disconnect them from power and audio sources, and store them in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speakers.	Speakers not powered on. Volume turned down. Audio cable disconnected or faulty. Incorrect audio source selected on device.	Ensure power is on and indicator light is lit. Increase master volume. Check all audio connections. Try a different cable. Verify audio output settings on your device.
Distorted or unclear sound.	Volume too high. Subwoofer level too high. Poor audio source quality. Interference from other devices.	Reduce master volume. Adjust subwoofer level. Try a different audio source. Move speakers away from mobile phones, Wi-Fi routers, or other electronic devices.

Problem	Possible Cause	Solution
Static or crackling noise (especially when adjusting volume).	Dust or wear in volume potentiometer.  Electrical interference.	Rotate the volume knob fully back and forth several times to clear dust. If persistent, professional service may be required.  Ensure power cables are not running parallel to audio cables. Try plugging into a different power outlet.

## SPECIFICATIONS

Feature	Detail
Brand	Altec Lansing
Model Name	VS2221
Speaker Type	Computer, Satellite, Subwoofer
Surround Sound Channel Configuration	2.1
Connectivity Technology	Auxiliary
Audio Output Mode	Stereo
Speaker Maximum Output Power	6 Watts
Power Source	AC
Item Weight	9 Pounds
Package Dimensions	11.5 x 11.5 x 9.8 inches
Compatible Devices	Desktop, Gaming Console, Home Theater, MP3 Player, Smartphone, Tablet, Television
UPC	021986941149







## WARRANTY AND SUPPORT

Altec Lansing products are designed for reliability and performance. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official Altec Lansing website. Keep your purchase receipt as proof of purchase for warranty claims.

For further assistance, you may contact Altec Lansing customer support through their official channels.



## Related Documents - VS2221

	<p><a href="#">Altec Lansing ACS65i Amplified Speaker System User Guide</a></p> <p>User guide for the Altec Lansing ACS65i amplified speaker system. This document provides detailed instructions on setup, operation, safety precautions, specifications, and warranty information for multimedia computer audio applications.</p>
	<p><a href="#">Altec Lansing ATP3 Computer Speaker System User Guide and Setup</a></p> <p>Comprehensive user guide for the Altec Lansing ATP3 computer speaker system, covering specifications, setup instructions, safety precautions, and control usage.</p>
	<p><a href="#">Altec Lansing ACS56 Computer Speaker System User Guide and Warranty</a></p> <p>Comprehensive guide to the Altec Lansing ACS56 computer speaker system, covering specifications, setup, operation, safety instructions, and a one-year limited warranty.</p>
	<p><a href="#">Altec Lansing ABT385 Power Duo Bluetooth Tower Speakers Quick Start Guide</a></p> <p>A concise guide to setting up and using the Altec Lansing ABT385 Power Duo Bluetooth Tower Speakers, covering assembly, audio inputs, remote control, Bluetooth pairing, and specifications.</p>
	<p><a href="#">Altec Lansing ACS495 User Guide</a></p> <p>User guide for the Altec Lansing ACS495 computer speaker system, detailing setup, operation, and specifications.</p>
	<p><a href="#">Altec Lansing ACS33BW Three-Piece Powered Audio System User Guide</a></p> <p>Comprehensive user guide for the Altec Lansing ACS33BW three-piece powered audio system, covering setup, connections, specifications, and troubleshooting. Includes safety information and warranty details.</p>




[\[pdf\]](#) User Manual Instructions Guide

H0379 R02 AMCAS VS2221 MAN qxd Christopher King Altec Lansing user manual 414053 archive org manualsbase id

**VS2221** User s guide Gua del usuario Mode d emploi Guia do Usurio The lightning flash with arrowhead, within an equilateral triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the product s enclosure that may be of sufficient magnitude to constitute...

lang:en **score:52** filesize: 264.46 K page\_count: 20 document date: 2005-01-07




[\[pdf\]](#) User Manual Guide

ManualsLib Makes it easy to find manuals online! Search through 700 000 online and instruction user service guides owners installation Provided By MANUALSLIB COM manualslib acerpower apm6 0204447e32abd881aaddf4ba449dbdc9 data2 1 14 1331 acer |||

Aspire T160/E360 AcerPower M6 Service Guide Service guide files and updates are available on the AIP ... com manuals search engine Chapter 6 Partname 2.0 SPEAKER, VS2220, 230V, A PLUG TYPE 2.1 SPEAKER, **VS2221**, 230V, E PLUG TYPE EUROPE EXCLUDE UK 2.1 SPEAKER, **VS2221**, 230V, UK PLUG TYPE 2.1 SPEAKER, V...

lang:en **score:46** filesize: 9.57 M page\_count: 164 document date: 2012-04-27




[\[pdf\]](#) Guide

Product guide 2005 Front ai PRODUCT GUIDE alteclansing 80 e4

PRODUCT For all of life s soundtracks. www.alteclansing.com LINE Powered Audio VS2220 **VS2221** VS4121 VS4221 Sound Qualities 2-Piece System 2.0 Solid value. Trusted performance. Quality stereo sound at an affordable price. 3-Piece System 2.1 Solid value. Trusted performance. Quality stereo ...

lang:en **score:40** filesize: 7.81 M page\_count: 6 document date: 2005-01-11



[\[pdf\]](#) User Manual Guide

B3 1 SG Book book Peter Yao Aspire T160 E360 AcerPower M6 aspire t160 e360 service guide 6371fb00b1413606260579 theretroweb motherboard manual |||

Aspire T160/E360 AcerPower M6 Service Guide Service guide files and updates are available on the AIP ... 104.003 SP.S1006.002 118 Chapter 6 Partname 2.0 SPEAKER, VS2220, 230V, A PLUG TYPE 2.1 SPEAKER, **VS2221**, 230V, E PLUG TYPE EUROPE EXCLUDE UK 2.1 SPEAKER, **VS2221**, 230V, UK PLUG TYPE 2.1 SPEAKER, V...

lang:en score:38 filesize: 9.93 M page\_count: 164 document date: 2005-11-16




[\[pdf\]](#)

US VS2221 SELL SHEET PA qxd Christopher King alteclansing 80 altecm

Powered AUDIO STEREO The power to... CONNECT Get more out of your CD player, MP3 player, Video Gam ... nd in every room of your house... With Powered Speakers you can plug and play just about anywhere **VS2221** 2 1 S p e a k e r s Subwoofer Powered AUDIO STEREO TM More Boom For Your Buck Whether ...

lang:en score:38 filesize: 250.74 K page\_count: 2 document date: 2005-01-04



[\[pdf\]](#) User Manual Guide

B3 1 SG Book book Peter Yao 6d9573c0 1343 453d 90e1 c6bca9c18c81 dl owneriq net 6

Aspire T160/E360 AcerPower M6 Service Guide Service guide files and updates are available on the AIP ... 104.003 SP.S1006.002 118 Chapter 6 Partname 2.0 SPEAKER, VS2220, 230V, A PLUG TYPE 2.1 SPEAKER, **VS2221**, 230V, E PLUG TYPE EUROPE EXCLUDE UK 2.1 SPEAKER, **VS2221**, 230V, UK PLUG TYPE 2.1 SPEAKER, V...

lang:en score:17 filesize: 9.97 M page\_count: 164 document date: 2005-11-16