

KMC Card Box 1000

KMC Card Box 1000 Instruction Manual

Model: Card Box 1000

INTRODUCTION

The KMC Card Box 1000 is designed for the secure storage and organization of trading cards. This durable plastic box provides a practical solution for protecting your valuable card collections from dust, moisture, and physical damage. Its robust construction ensures longevity and reliable performance for hobbyists and collectors.

SETUP

The KMC Card Box 1000 requires no assembly. It is ready for use directly out of its packaging.

1. **Unpacking:** Carefully remove the card box from its packaging.
2. **Inspection:** Inspect the box for any signs of damage during transit. If damage is found, contact customer support.
3. **Preparation:** Ensure the interior of the box is clean and dry before placing cards inside.



Image: KMC Card Box 1000 with its lid open, revealing the internal compartments designed for organizing trading cards. The clear plastic allows visibility of contents.

OPERATING INSTRUCTIONS

Using your KMC Card Box 1000 is straightforward:

1. **Opening the Box:** Gently lift the lid using the designated edges. The box features a lift-off lid mechanism.
2. **Storing Cards:** Place your trading cards, either sleeved or unsleeved, into the compartments. The box is designed to accommodate standard-sized trading cards.
3. **Organizing:** Utilize the internal compartments to sort cards by type, rarity, or game.
4. **Closing the Box:** Align the lid with the base and press down gently until it sits securely. The lid provides a sealed enclosure to protect contents.



Image: An overhead view of the KMC Card Box 1000, open and ready for card placement. The internal dividers are visible, indicating multiple storage sections.

MAINTENANCE

To ensure the longevity and optimal condition of your KMC Card Box 1000:

- **Cleaning:** Wipe the exterior and interior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents, as these may damage the plastic.
- **Drying:** Ensure the box is completely dry before storing cards to prevent moisture damage.
- **Storage:** Store the box in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.

TROUBLESHOOTING

Common issues and their solutions:

- **Lid not closing securely:**
 - Ensure no cards or objects are obstructing the lid's path.
 - Check for any debris along the edges of the box or lid.
- **Cards not fitting:**
 - Verify that the cards are standard trading card size (2.5" x 3.5").
 - If using sleeves, ensure they are not excessively bulky.

- **Box appears warped or damaged:**
 - Avoid exposing the box to high temperatures or heavy loads.
 - If the damage affects functionality, consider replacing the unit.

SPECIFICATIONS

Brand	KMC
Model Number	FBA_LYSB0007N7P8K-TOYS
Material	Plastic
Color	Clear
Dimensions (L x W x H)	10.63" x 7.87" x 8.8" (approx. 27 cm x 20 cm x 22.3 cm)
Item Weight	22.68 g (approx. 0.05 lbs)
Number of Compartments	Multiple (as shown in product images)
Opening Mechanism	Lift-Off Lid
Recommended Use	Trading Card Storage
Assembly Required	No




Image: The KMC Card Box 1000 displayed with its height and width measurements, providing a visual reference for its size.

WARRANTY INFORMATION

KMC products are manufactured to high standards. For specific warranty details, please refer to the product packaging or contact KMC customer support directly. General warranty terms typically cover manufacturing defects under normal use conditions.

CUSTOMER SUPPORT

For further assistance, questions, or to report issues, please contact KMC customer support. Visit the official KMC website

for contact information or refer to the details provided on the product packaging.

Online Resources: [KMC Brand Store on Amazon](#)

© 2024 KMC. All rights reserved.

This manual is for informational purposes only. KMC reserves the right to make changes to product specifications without prior notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question